

HP X.25/9000 User's Guide

HP-UX 11i v3

Edition 8



Manufacturing Part Number: J2793-90072

February 2007

© Copyright 2007 Hewlett-Packard Development Company, LP.

Legal Notices

© Copyright 2007 Hewlett-Packard Development Company, L.P.

Confidential computer software. Valid license required from HP for possession, use or copying. Consistent with FAR 12.211 and 12.212, Commercial Computer Software, Computer Software Documentation, and Technical Data for Commercial Items are licensed to the U.S. Government under vendor's standard commercial license.

The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

UNIX is a registered trademark of The Open Group.

1. About the X.25 Product

Introduction	16
Application (L7), Presentation (L6), and Session (L5) Levels	18
Transport Level (L4)	19
Packet/network Level (L3)	20
Data link (L2) and Physical (L1) Levels	21

2. Installation

Before You Install the Software	24
Hardware Requirements	24
Installing Multiple X.25 Interface Cards	24
Hardware Compatibility	24
OS Platform and Version Compatibility	25
Memory	25
Software Requirements	27
Installing the X.25 Link Software	28

3. Configuration

Configuring the X.25 Link	30
Using SMH	30
Using SMH's On-line Help	31
Configuring an X.25 Address	31
Configuring X.25 Virtual Circuits (VCs)	34
Configuring an Internet Address	35
Verifying Level 3 Values	39
Verifying Level 2 Values	44
Configuring Remote System Access	48
Configuring X.25 over LLC2	54
Configuration Files	54
Starting and Stopping Configuration	60
Sample setup and Configuration	61
One Lan and Two Boxes configuration	62
Configuring Two Lans, with One Box Per Lan	65
Troubleshooting LLC2 Configuration	69
Configuring PAD Services	71
Add/Modify PAD Terminal Emulation (Local to Remote)	71
Add/Modify PAD Support Server (Remote to Local)	72
Add/Modify PAD Printers Server	73

Contents

Add/Modify UUCP Server	73
Add/Modify X.3 Parameters	74
Configuring the High Availability Feature	76
X.25 Cluster Definition	77
X.25 Commands to be Configured in High Availability Packages	77
X.25 Package Definition	77
X.25 High Availability Configuration	78
Checking the Configuration	79
Configuring the High Availability Feature for X.25 over LLC2	81
Unique MAC Address Requirement	81
Local Failover	82
Configuring XOL HA for Local Failover Without ServiceGuard	83
Remote Failover	86
Configuring XOL HA for Remote Failover Using Service Guard (SG)	86
XOL Cluster Definition	88
X.25 Commands Used in the SG Package Control Scripts:	88
XOL Package Definition	89
Remote Failover with Local Failover Support Using Service Guard	91
Verifying the X.25 Link	96

4. OLA/R Overview and Concepts

Introduction	98
Important Terms and Concepts	99
Planning and Preparation	100
Card Compatibility	100
On-Line Addition	100
On-Line Replacement	100
Critical Resources	101
Failover Actions / Single Points of Failure	102
How to On-line Replace (OLR) a J3525A PCI Card using SMH	103
How to On-line Add (OLA) a J3525A PCI Card using SMH	107

5. Diagnostic Utilities

Using Diagnostic Utilities	112
Before Using the Diagnostic Utilities	114
x25check and x25server	115

Example 1: Running x25check Interactively (No Parameters)	115
Example 2: Running x25check With an X.121 Address	117
Example 3: Running x25check With a Data Packet	117
x25stat	118
Example 1: Displaying the Current Configuration	118
Example 2: Displaying Global Statistics	119
Example 3: Displaying Virtual Circuit Data Packet Counters	123
Example 4: Displaying Global X.25 Level 3 Statistics	124
Example 5: Displaying X.25 Level 1 and 2 Statistics	124
Example 6: Displaying Virtual Circuit Status	126
Example 7: Displaying Current IP to X.25 Address Mapping	127
x25mibstat	128

6. PAD Services

Introduction	130
CCITT Recommendations	130
PAD services and the HP 9000 host	131
Remote PAD Support (x29server)	132
Overview	132
Call Acceptance Mechanism and System Security	133
Supported Remote PAD Terminals	135
Configuring Remote PAD Support	135
Configuring pad_spt Parameters	135
pad_spt Parameters	136
Launching Applications Automatically	138
Remote PAD Printer Support (x29printd)	139
Overview	139
System Requirements	140
Configuring Remote PAD Printers	141
Configuring the UNIX Line-printer Spooler for x29printd	143
Examples	144
x29printd and lpsched Operation	144
Printer Configuration	144
Verifying the Configuration	145
UUCP Support (x29uucpd)	146
Overview	146
Configuring UUCP PAD Support	147
Configuring the x29hosts file	148

Contents

pad_uucp Parameters	148
Configuring System and Device Files for UUCP	150
Local PAD Emulation (padem)	156
Command Mode	156
Data Transfer Mode	157
Configuring Local PAD Emulation	157
Parameter Descriptions	157
PAD Commands	160
X.28 PAD Command Set	160
Extended Command Set	161
Configuring X.3 Profile Parameters	163
Configuration Set Syntax	163
Parameter Values	164
Modifying Parameters	164
Default X.3 Parameters	165
X.3 Parameter Descriptions	165

7. Tracing and Logging Utilities

Introduction	176
nettl	178
Syntax	178
Parameters	178
Examples	180
netfmt	181
Syntax	181
Parameters	181
Examples	182
Creating a Filter File	183
Filter File Examples	186
strace	187
Syntax	187
Parameters	187
Examples of the strace Command	192
Examples of strace Output	193
strerr	195
Syntax	195

Parameters	195
 8. Troubleshooting	
Troubleshooting Your X.25 Link	198
Troubleshooting Flowcharts and Procedures	199
Flowchart 2 – Procedures and Notes	200
Note 2-1 – x25stat	200
Note 2-2 – eisa_config	200
Flowchart 3 – Procedures and Notes	203
Note 3-1 – Hardware Check	203
Flowchart 4 – Procedures and Notes	204
Note 4-1 – x25check	204
Note 4-2 – Exit	204
Flowchart 5 – Procedures and Notes	205
Note 5-1 – ping	206
Note 5-2 – Checking your IP over X.25 Configuration	206
Note 5-3 – Exit	206
Recovering From a Power Failure	208
For Systems With a Backup Power Supply	208
For Systems With No Backup Power Supply	208
Reporting Problems	209
Back-to-back Configuration on the Same Host	211
Configuration and Troubleshooting Commands	212
Command Summary	212
Examples of x25init	214
IP-to-X.121 Address Mapping Table	214
Example	216
File Mapping Parameters	216
 A. Using Non-English Subscription Forms	
Subscription Form Translations	220
 B. X.25 Configuration Files and Examples	
X.25 Configuration Files	226
Example Files	228
The x25init_def File	228
The x25init_smpl File	231
The x3config File	233

Contents

The x29hosts File	236
The Network Type File (x25_networks)	237

C. Diagnostic Messages

Introduction	240
Diagnostic Message Example	241
Cause Code Settings	242
Packet Codes.....	243
RESTART Packet Codes.....	243
RESET/CLEAR Packet Codes	243
X.25 Diagnostic Messages	244

Tables

Table 2-1.	26
Table 3-1. Field Descriptions	33
Table 3-2. Field Descriptions	35
Table 3-3. Configure Internet Address Field Descriptions	37
Table 3-4. IP Address and Default Subnet Masks	37
Table 3-5. Modify IP over X.25 Defaults Field Descriptions	39
Table 3-6. Verify Level 3 Values Field Descriptions	40
Table 3-7. Switched VC Flow Control Field Descriptions	42
Table 3-8. Permanent VC Flow Control Field Descriptions	42
Table 3-9. Modify Throughput Class Settings Field Descriptions	43
Table 3-10. Throughput Classes and Line Speeds	44
Table 3-11. Verify Level 2 Values Field Descriptions	46
Table 3-12. Add Internet Connectivity Field Descriptions	50
Table 3-13. Provide X.25 Information Field Descriptions	52
Table 3-14. Additional XOL specific configuration parameters	55
Table 4-1. Terms used in this section	99
Table 4-2. Three Possible Critical Resource Analysis (CRA) Outcomes	104
Table 4-3. Three Possible Critical Resource Analysis (CRA) Outcomes	108
Table 5-1. Available Diagnostic Utilities	112
Table 5-2. Level 3 State	120
Table 5-3. Level 2 Link State	121
Table 5-4. Level 1 Link State	122
Table 5-5. Statistics for WAN Output	122
Table 5-6. VC State	123
Table 5-7. Statistics for WAN Output	126
Table 5-8. Example Statistics for x25mibstat	128
Table 6-1.	148
Table 6-2. X.3 Parameter Descriptions	166
Table 6-3.	166
Table 6-4.	167
Table 6-6.	168
Table 6-5.	168
Table 6-7.	169
Table 6-8.	170
Table 6-9.	170

Tables

Table 6-10.	171
Table 6-12.	172
Table 6-13.	172
Table 6-11.	172
Table 6-14.	173
Table 6-15.	173
Table 6-16.	174
Table 7-1. Available Tracing and Logging Utilities	176
Table 7-2. Tracing Masks.	179
Table 7-3. Filter File Options.	184
Table 7-4. Filter File family Options.	185
Table 7-5. Single-port Subnet Interface Codes	188
Table 7-6. Dual-port Subnet Interface Codes	189
Table 7-7. Output Format	190
Table 7-8.	191
Table 7-9.	191
Table 7-10. Output Format	192
Table 7-11.	193
Table 8-1. Troubleshooting Commands.	198
Table A-1. French TRANSPAC Subscription Form	220
Table A-2. Using Your ITAPAC (Italian) Subscription Form.	221
Table A-3. Using your DATEX-P (German) Subscription Form	222
Table A-4. Using your IBERPAC (Spanish) Subscription Form	222
Table B-1. /etc/x25 directory	226
Table B-2. /etc directory	226
Table B-3. /var/x25/log/x25server directory	227
Table B-4. /var/x25/log directory	227
Table B-5. Home directory	227
Table B-6.	228
Table B-7.	231
Table B-8.	236
Table B-9.	238
Table C-1. No Additional Information.	244
Table C-2. Packet Type Invalid	244
Table C-3. Packet Not Allowed	245

Table C-4. Timer Expired.246

Table C-5. Call Setup, Call Clearing, or Registration Problem247

Table C-6. CATEGORY - Miscellaneous251

Table C-7. International Problem and Maintenance251

Table C-8. DTE-Specific Signals251

Table C-9. OSI Network Service Problem.253

Table C-10. Higher Level Initiated254

Tables

Figure 1-1. X.25 Link Architecture	17
Figure 3-1.	32
Figure 3-2.	34
Figure 3-3. Configure Internet Address	36
Figure 3-4. Modify IP Over X.25 Defaults	38
Figure 3-5. Verify Level 3 Values	40
Figure 3-6.	41
Figure 3-7.	43
Figure 3-8.	45
Figure 3-9. Add Internet Connectivity Dialog	49
Figure 3-10.	51
Figure 3-11. One LAN, Two Boxes Configuration	62
Figure 3-12. Two Lans, One Box per Lan configuration	66
Figure 3-13. Before the Failover	83
Figure 3-14. After the Failover	84
Figure 3-15. Before the Failover	87
Figure 3-16. After the Failover	88
Figure 5-1. Scope of X.25 Diagnostic Utilities	113
Figure 6-1. PAD Support Protocols	131
Figure 6-2. PAD Services as a Pipe	132
Figure 6-3. Remote PAD Support	133
Figure 6-4.	134
Figure 6-5. Remote Printer Support	140
Figure 6-6. Remote Printer Support	147
Figure 6-7.	156
Figure 7-1. The Scope of X.25 Tracing and Logging Utilities	177
Figure 7-2.	188
Figure 8-1. Flowchart 1	200
Figure 8-2. Flowchart 2 – Initialization Check.	202
Figure 8-3. Flowchart 3 – Hardware Check	203
Figure 8-4. Flowchart 4 – X.25 Configuration Check.	205
Figure 8-5. Flowchart 5 – IP Over X.25 Check.	207
Figure 8-6.	211

Figures

1 About the X.25 Product

Introduction

The Hewlett-Packard X.25 link for HP 9000 systems provides networking link hardware and software to allow HP computer systems to communicate with other HP and non-HP computers over X.25 packet switching networks.

The X.25 link implements the *CCITT X.25 Recommendations* and contains the components necessary to connect an HP 9000 to a public or private packet switching network conforming to the *CCITT X.25 Recommendation (1980, 1984 or 1988)*, or to another system in a back-to-back configuration.

The information in this manual applies to HP 9000 Series 700 and 800 systems that use single, dual, or quad-port communications hardware. Any differences are specifically noted.

NOTE


In a diskless cluster, X.25 software is only supported on the server system. It is not supported on client systems for this type of environment.

The following diagram illustrates the X.25 link architecture where:

- solid white boxes represent the product's integral components.
- lightly shaded boxes represent the product's protocol components.
- heavily shaded boxes represent optional components (external to the product) that can be added to the product.

Each component depends on the component(s) below it and must be installed and running in order to support higher-level components.

Figure 1-1 X.25 Link Architecture



Application (L7), Presentation (L6), and Session (L5) Levels

The X.25 link does not provide any components for the general support of the application and presentation levels (levels 7 and 6, respectively), although X.25/9000 PAD Services do provide some of the functionality of these levels.

User-written application programs, Internet Services/Berkeley Services (via BSD Sockets) and NS (via NetIPC Sockets), are accessed by means of TCP or UDP Transport Level (level 4) protocols.

For application level services, you can install OSI Services to run over the X.25 network (for more information, refer to OSI Services documentation). The OTS/9000 product provides access to X.25 for OSI Services. You can install application level services such as Internet/Berkeley Services and Network Services (for more information, refer to the documentation for these products).

BSD IPC (Berkeley Software Distribution InterProcess Communication) allows direct programmatic access to the X.25 packet level (level 3), or TCP/UDP at the transport level (level 4), for user-written application programs.

NetIPC sockets also provides a programmatic interface to TCP/UDP at the transport level.

Transport Level (L4)

At the transport level (level 4), the X.25 link provides TCP (based on the DARPA standard) and UDP. These Transport level protocols are used by Internet/Berkeley Services, by NS, and by user application programs that access the TCP/UDP and IP protocols.

The TCP protocol is a connection-based protocol. TCP verifies that all data is delivered without duplication to its destination. The UDP protocol, unlike TCP, has no concept of a connection. Messages are sent as a unit with source and destination information in the header.

The X.25 link provides a BSD to PLP (Packet Level Protocol) translator to allow access to PLP at level 3 for user-written application programs via BSD IPC.

The X.25 link also provides an OTS to PLP translator to allow access to PLP at level 3 for OSI Services via Xport OSI.

Packet/network Level (L3)

At the packet/network level (L3), X.25 link provides direct X.25 programmatic access via BSD IPC. For full details on X.25 programmatic access, refer to the *X.25/9000 Programmer's guide* (part number: J2793-90065).

The X.25 link also provides IP access to TCP or UDP Transport protocols for programs such as Internet/Berkeley Services and NS, allowing communication over X.25 in accordance with RFC 877.

Data link (L2) and Physical (L1) Levels

At the data link level (level 2), the X.25 link provides the LAP-B (Link Access Procedure-Balanced) protocol. LAP-B is a data link protocol, specified by the 1980 CCITT X.25 recommendations, that determines frame exchange procedures.

At the physical level (level 1), the X.25 link provides support for X.21, X.21bis, and V.35 interfaces (depending on your particular communications hardware). These sets of recommendations define the standards for X.25 at the physical level and apply specifically to connections to a packet switching network. X.21bis (equivalent to V.24 and RS-232) is applicable to X.25 physical interfaces with transmission speeds up to 64 kb/s. V.35, RS-449, X.21, and RS-530 supports transmission speeds up to 2 Mb/s. Other standards may also be supported as they become available.

About the X.25 Product

Data link (L2) and Physical (L1) Levels

2 Installation

Before You Install the Software

Before installing the X.25 link software, check the requirements below to make sure that all required software and hardware has been correctly installed and configured.

NOTE

This product is only supported on the system that is acting as a server. It is not supported on client systems.

Hardware Requirements

This section describes the hardware requirements of the J2793B X.25 software for HP 9000 server systems.

If you have not already done so, install the X.25 interface card as described in the hardware installation guide for your X.25 product. If you are installing multiple X.25 cards, check the requirements in “Installing Multiple X.25 Interface Cards” below.

If a modem connection is required, connect the X.25 card to the modem or the modem eliminator according either to the modem vendor’s specification sheet, or the instructions provided by the network provider.

Installing Multiple X.25 Interface Cards

When installing multiple X.25 cards,

- Always install the cards in adjacent slots in ascending slot order.
- Always install X.25 cards with the system shut down.
- Do not skip slots between X.25 cards.

Hardware Compatibility

- HP 9000 PCI bus

The High Availability feature can run on:

- PCI hardware cards, Product Numbers J3525A (2-ports)

OS Platform and Version Compatibility

The version of the X.25 link software you're installing must be compatible with the version of HP-UX you're running (for example, HP-UX version 11i v3 for B.11.31.01)

- Disk space required to install: 7 Mb
- Software install with system up or down? Up
- Single-user state required or recommended? No
- Reboot? Yes

Memory

Your X.25 link supports a high number of virtual circuits operating at high baud rates. Since both X.25 and the BSD sockets API may store a certain amount of data for each socket/circuit, HP recommends that you check that your system has enough memory to handle the number of VCs you plan to use. A few guidelines to help you are provided below.

Related Parameters

- Level 3 window size (W in formulas below) as configured in the `x25config` file
- Level 3 packet size (P in formulas below) as configured in X.25 configuration file
- Socket buffer size (B in formulas below) used in your applications (`setsockopt()` system call). The default is 4 Kb.

Evaluation Formulas The following formulas can be used to evaluate X.25 memory requirements:

Memory for each VC (MVC) in bytes:

$$\text{MVC} = (B \times 3) + (2 \times (W + 1) \times P)$$

Total Memory (TM) for X.25 in bytes:

$$\text{TM} = \text{sum (MVC)} + \text{Number of cards} \times 5120$$

NOTE

These figures are only for protocol and API requirements. You should also consider the memory required by your applications.

Shortcut Method Assuming $B = P$ for all VCs, TM can be rounded to:

- If $B < 512$, $TM = \text{approx. } (1,536 + (2 \times W + 2) \times B) \times \text{No. of VCs}$
- If $B \geq 512$, $TM = \text{approx. } (2 \times W + 5) \times B \times \text{No. of VCs}$

The following table (in bytes/VC) provides a quick guide:

Table 2-1

		Buffer Size (B) = Packet Size (P) in bytes					
		128	256	512	1024	2048	4096
Window (W) size	1	2 K	2.5 K	3.5 K	7 K	14 K	28 K
	2	2.3 K	3 K	4.5 K	9 K	18 K	36 K
	3	2.5 K	3.5 K	5.5 K	11 K	22 K	44 K
	4	2.8 K	4 K	6.5 K	13 K	26 K	52 K
	5	3 K	4.5 K	7.5 K	15 K	30 K	60 K
	6	3.3 K	5 K	8.5 K	17 K	34 K	68 K
	7	3.5 K	5.5 K	9.5 K	19 K	38 K	76 K

Example 2-1

Example:

A system has two X.25 cards configured as follows:

Card 1:

Window = 2

Packet size = 1024

Socket buffer size = 4096 (default)

200 VCs are used

Card 2:

Window = 4

Packet size = 128

Socket buffer size = 4096 (default)

400 VCs are used

$$\begin{aligned} \text{TM} = & (4096 \times 3) + (2 \times 3 \times 1024) \times 200 \\ & + ((4096 \times 3) + (2 \times 5 \times 128)) \times 400 \\ & + (2 \times 5120) \end{aligned}$$

$$\text{TM} = 9,123,840 \text{ (8.7 Mb)}$$

Software Requirements

Before installing the X.25 link product, make sure that the software listed below has been correctly installed on your system. Refer to the related publication if you need more information about any of these products. If you cannot find the software or information you need, contact your HP representative.

- HP-UX operating system version 11i v3 – see *Installation and Update for HP Integrity Servers and HP 9000 servers*.
- Internet Services – see *HP-UX Internet Services Administrator's Guide: HP-UX 11i v3*

Installing the X.25 Link Software

Follow the steps below to install the X.25 link software:

Step 1. Insert the software media (tape or disk) in the appropriate drive.

Step 2. Type: `swinstall`.

(See the man page on `swinstall` for more information on this command).

Step 3. Click on OK on the “Specify Source” window.

Step 4. Highlight J2793B in the “Software Selection” dialog, then select Mark For Install from the Actions menu to install all file sets in the bundle.

If you want to select only certain file sets, double-click on the product name to access the file sets that you want to mark for installation (each time you double-click, you go down one level in the bundle structure).

Step 5. When you have marked the product components you want to install, select Install (analysis) from the “Actions” menu.

Step 6. When you have successfully completed the analysis, click on OK from the Analysis dialog to load the X.25 file sets.

The `swinstall` utility loads the file sets, runs the customized scripts for the file set, and builds the kernel. Estimated time for processing: 8 to 10 minutes.

If the kernel build is not successful, the `swinstall` program returns you to a new shell. The cause of the failure will appear at the end of the `/var/adm/sw/swinstall.log` file.

3 Configuration

Configuring the X.25 Link

This section describes how to configure your X.25 link using HP System Management Homepage(SMH).

HP SMH provides Graphical User Interface (GUI), Terminal User Interface (TUI) and Command Line Interface (CLI) for managing HP-UX. You can access these interfaces using the `smh` command (`/usr/sbin/smh`).

If the `DISPLAY` environment variable is set, HP SMH opens in the default web browser. If the `DISPLAY` environment variable is not set, HP SMH opens in the TUI. For more information, see the HP-UX 11i v3 release notes and the SMH product online help.

In SMH, the term “card” refers to a particular X.25 interface. Dual-port cards have two interfaces. In this context, an interface is the same as a port.

NOTE

System Administration Manager (SAM) is deprecated on HP-UX 11i v3 and replaced with the enhanced HP System Management Homepage (HP SMH). Users who attempt to start SAM from the command line interface are automatically redirected to the SMH user interface. SMH can be run directly in a web browser window by entering `http://hostname:2301`. In the Graphical User Interface (GUI), after logging in, the SMH main menu is displayed. Select Tools > networking and communications > network interface cards > choose X.25. For more information on SMH, see the HP System Management Homepage Release Notes (Part Number:381383-009) on <http://docs.hp.com>.

Using SMH

Follow the steps below to start SMH and display the “Configure X.25 Card” window:

- Step 1.** Make sure that you are logged in as root. Then, at the HP-UX prompt, enter:

```
smh
```

(To run SMH in the background, type: **smh &**).

- Step 2.** At the SMH main window, select “Tools” menu. SMH displays numerous object lists.
- Step 3.** Double-click on the Network Services Configuration menu. SMH displays an object list that shows all network interfaces (devices) installed in your system.

SMH displays each port (for multi-port cards) as a unique interface with its hardware path and name. Interfaces are listed in order of their slot number.

- Step 4.** Highlight the X.25 device that you want to configure on the object list and select Configure from the Actions menu, or double-click the device you want.

The “Configure X.25 Software” window displays. If you are modifying a device that is already configured, the window is entitled, “Configure X.25 Card.”

NOTE

Refer to Appendix A, Using Non-English Subscription Forms, for the English equivalents of the French, Italian, German, and Spanish fields that appear on non-English subscription forms.

Using SMH's On-line Help

The SMH on-line Help provides information (descriptions, formatting, and ranges) for all fields. You can access the SMH on-line Help system by:

- Clicking on the Help button in a dialog or message box to display information about how to use the dialog, or about the message.
- Pressing **F1** to display information about the object selected by the cursor (for example, a data entry field).
- Selecting an item from the Help menu (located on the menu bar). You can display information about the current SMH dialog, keyboard navigation within SMH, using the SMH Help system, and the version of SMH you are currently running.

Configuring an X.25 Address

Follow the steps below to configure an X.25 address:

- Step 1.** From the “Configure X.25 Software” window, select Configure X.25 Address. The following dialog appears:

Figure 3-1

Configure X.25 Address (epeire)

Card Type: X.25
Card Name: x25_0
H/W Path: 96

Configuration Filename: /etc/x25/x25config_0

X.25 Address: 250205

Programmatic Access Name: interface0

Network Carrier Type:

- DTE_80
- DTE_84
- DCE_80
- DCE_84**
- AUSPAC
- DATANET1

OK Cancel Help

NOTE

The SMH windows and dialogs shown on these pages are intended only as examples. The information that appears in your SMH dialogs, such as the Card Name and Programmatic Access Name, depends on your particular communications hardware.

- Step 2.** Enter or modify the field values as required (refer to the field descriptions below).

Table 3-1 Field Descriptions

Configuration File name	<p>Name of the file that will contain the parameters for configuring the interface (a physical port). If you are configuring more than one interface, specify a unique configuration file for each interface.</p> <p>The configuration file must be named <code>x25config_npx</code>, where <i>n</i> represents the communications card number (use 0 for the first card, increasing the value by 1 for each additional card up to 255), <i>p</i> is a place marker, and <i>x</i> is the port number (1 to 4). Note that <i>p</i> and <i>x</i> are only required for systems with dual-port or quad-port cards.</p>
X.25 Address	<p>Address assigned to each local X.25 interface (card or port) by the network carrier. X.25 checks it for diagnostic and identification purposes only. This address is sometimes referred to as the X.121 address. Use the value given on your subscription form.</p>
Programmatic Access Name	<p>Name given to the interface you are configuring (used for X.25 level 3 programmatic access).</p>
Network Carrier Type	<p>Type of network to which the X.25 interface is attached (as it appears on your subscription form). A complete list of possible networks is shown below. The default is DTE_84.</p>
X.25 Packet Address	<p>This field appears (with its default value) only if you select TRANSPAC as the Network Carrier Type.</p>

Network types

You *must* select a Network Carrier Type that matches the type of network to which you are connected.

Configuring the X.25 Link

DCE_80	DCE_84	DCE_88	DTE_80
DTE_84	DTE_88	AUSPAC	DATANET1
DATAPAC	DATEXP_AUSTRIA	DATEXP_DEUTSCHE	DCS
DDN	DDXP	HPPPN	ITAPAC
LUXPAC	PSS	TELENET	TRANSPAC
TYMNET	IBERPAC	TELEPAC	DATAPAK

Step 3. Click on OK to return to the “Configure X.25 Card” window when you have finished configuring the X.25 Address.

Configuring X.25 Virtual Circuits (VCs)

Follow the steps below to configure X.25 virtual circuits:

Step 1. From the “Configure X.25 Card” window, select Configure Virtual Circuits. The following dialog appears:

Figure 3-2

	Quantity	Starting Logical Circuit ID
Permanent:	0	0
Switched (inbound):	0	0
Switched (two-way):	2	1
Switched (outbound):	0	0

OK Cancel Help

Step 2. Enter or modify field values as required (refer to the field descriptions below).

When you configure the Quantity column (starting with the number of Permanent VCs), SMH automatically fills in the starting Logical Circuit Identification (LCI) as you **Tab** between fields.

Table 3-2 **Field Descriptions**

Permanent - Quantity	Number of Permanent VCs. Use the value given on your subscription form.
Switched (inbound) - Quantity	Number of Switched (inbound) VCs. Use the value given on your subscription form.
Switched (two-way) - Quantity	Number of Switched (two-way) VCs. Use the value given on your subscription form.
Switched (outbound) - Quantity	Number of Switched (outbound) VCs. Use the value given on your subscription form.

- Step 3.** Click on OK to return to the “Configure X.25 Card” window when you have finished configuring X.25 Virtual Circuits.

Configuring an Internet Address

Follow the steps below to configure an Internet address:

- Step 1.** From the “Configure X.25 Card” window, select `Configure Internet Address`. The following dialog appears:

Figure 3-3 **Configure Internet Address**

Configure Internet Address (X.25) (hpatm159)

Configure IP Address?

☒ Yes

☐ No

Internet Address:

Subnet Mask:

IP Address Alias:

Comments: (optional)

The “Configure Internet Address” dialog gives you a **yes** or **no** option to configure an IP address for this port.

Step 2. Choose Yes or No to configure an IP address.

If you select **No**, you indicate that no IP address is associated with this X.25 port. When you select **No**, all other fields in this dialog disappears.

If you select **Yes**, you must fill in the other required fields in this dialog.

Step 3. Enter or modify field values as required (refer to the following field descriptions).

Table 3-3 Configure Internet Address Field Descriptions

Internet Address	The identifier by which this interface (port) is known on the network. It consists of four sets of integer values (0 to 255) separated by periods (for example, 192.2.3.6). The IP address must be unique for each X.25 interface. It must also specify a different subnet from the IP address of any other X.25 or LAN interface on this system. To obtain an IP address, see your system administrator, network administrator, or HP representative.
Subnet Mask	<p>The subnet mask (like IP addresses) is composed of four integers (0 to 255) separated by periods. The subnet mask is used for routing.</p> <p>When you enter an IP address, SMH places a default subnet mask in the subnet mask field, depending on the class of IP address you enter. You may use the default or enter another one if required. Table 3-4, “IP Address and Default Subnet Masks,” shows the IP addresses listed by class and their default subnet masks).</p>
IP Address Alias	The symbolic name (in alphanumeric format) by which this network interface will be known on the network. Use the Add/Modify Host Name Aliases button to add or modify aliases.

Table 3-4 IP Address and Default Subnet Masks

IP Address	Class	Default Subnet Mask
A.*.*.* (A between 1 and 127)	A	255.0.0.0

Table 3-4 IP Address and Default Subnet Masks (Continued)

IP Address	Class	Default Subnet Mask
A.B.*.* (A between 128 and 191) (B between 0 and 254)	B	255.255.0.0
A.B.C.* (A between 192 and 239) (B,C between 0 and 254)	C	255.255.255.0
A.B.C.* (A between 240 and 254) (B,C between 0 and 254)	D	Not Allowed

The Internet address is composed of two addresses: the network address and the subaddress. Zero (0) and -1 are not allowed in the subaddress.

- Step 4.** If required, click on Modify IP over X.25 Defaults to modify the Idle Timer, Hold Timer, MTU Size and System Max. IP Connections defaults.

Figure 3-4 Modify IP Over X.25 Defaults

Modify IP Over X.25 Defaults (hpatm159)

Idle Timer (seconds): 600

Hold Timer (seconds): 300

MTU Size (octets): 2048

System Max. IP Connections: 256

Restore Defaults

OK Cancel Help

Enter or modify field values as required (refer to the field descriptions below).

Table 3-5 Modify IP over X.25 Defaults Field Descriptions

Idle Timer	Sets the number of seconds a circuit stands idle before it is cleared by IP. The range is 0 to 32767. The default is 600.
Hold Timer	Sets the number of seconds a circuit may be inactive before it is designated as inactive. Inactive circuits may be cleared when all other circuits are unavailable and a connection request is received by IP. <i>Do not set the hold timer to a value greater than the idle timer.</i> The range is 0 to 32767. The default is 300.
MTU Size	The maximum transmission unit size in octets (bytes). The range is 20 to 8192. The default is 2048. For DDN configured interfaces, it must be less than or equal to 1007.
System Max. IP Connections	The maximum number of IP connections that can be simultaneously active for the whole system. This is a global parameter. The default value for this parameter is 256 connections.

- Step 5.** Click on OK to return to the “Configure X.25 Card” window when you have finished configuring the Internet address.

Verifying Level 3 Values

If you subscribe to a public network, the network provider will supply the appropriate settings for most level 3 parameters. These settings will differ depending on the network provider and the type of service to which you subscribe. Refer to your Network Subscription Form for the correct values for your configuration.

Follow the steps below to verify level 3 values:

- Step 1.** At the “Configure X.25 Card” window, select Verify Level 3 Values. The following dialog appears:

Figure 3-5 **Verify Level 3 Values**

The screenshot shows a dialog box titled "Verify Level 3 Values (hpatm159)". It contains four groups of radio buttons for configuration options. In each group, the "No" option is selected. The options are: "Fast Select Accepted" (Yes/No), "Flow Control Negotiation" (Yes/No), "Reverse Charge Accepted" (Yes/No), and "Throughput Class Negotiation" (Yes/No). Below these groups are two buttons: "Modify Flow Control Settings..." and "Modify Throughput Class Settings...". At the bottom of the dialog are three buttons: "OK", "Cancel", and "Help".


Step 2. Enter or modify field values as required (refer to the field descriptions below).

Table 3-6 **Verify Level 3 Values Field Descriptions**

Fast Select Accepted	If fast select is enabled (Yes), up to 128 octets of information can be transferred in call request and clear packets. The default is No (disabled). See your subscription form.
Flow Control Negotiation	The default is No (disabled). Use the value given on your subscription form.
Reverse Charge Accepted	If reverse charge is enabled (Yes), reverse charge calls can be accepted by the application. If reverse charge is disabled (No), X.25 rejects reverse charge calls automatically. The default is No. Use the value given on your subscription form.
Throughput Class Negotiation	Throughput class refers to line speed. If it is enabled (Yes), the Switched VC Negotiated value is used; if disabled (No), no throughput class negotiation is accepted. The default is No.

Step 3. Click on Modify Flow Control Settings to modify Switched and Permanent VC flow control settings. The following dialog appears:

Figure 3-6



Step 4. Select either Modulo-8 or Modulo-128 to set level 3 Modulo parameters. The default is Modulo-8.

The valid window-size values for Modulo-8 range from 1 to 7. For Modulo-128, the valid window-size values range from 1 to 127.

NOTE

Flow Control Negotiation must be enabled on the “Verify Level 3 Values” dialog to allow the use of the negotiated flow control fields. If you do not enable Flow Control Negotiation, the Default Packet Size and Default Window Size values will be used.

Enter or modify field values as required (refer to the field descriptions below).

Table 3-7 Switched VC Flow Control Field Descriptions

Default Packet Size: Inbound & Outbound	Maximum packet size to be used over an SVC. The range is 16 through 4096 octets. The default is 128 for inbound and outbound packets. Use the value given on your subscription form.
Default Window Size: Inbound & Outbound	Maximum number of default packets that can be transmitted without acknowledgment over an SVC. The range is 1 through 7 for Modulo-8, and 1 through 127 for Modulo-128. (We recommend a value greater than 7 for Modulo-128). The default is 2 for inbound and outbound transmission. Use the value given on your subscription form.
Negotiated Packet Size: Inbound & Outbound	Maximum packet size to be used over an SVC. The range is 16 through 4096 octets. The default is 128 for inbound and outbound packets.
Negotiated Window Size: Inbound & Outbound	Maximum number of default packets that can be transmitted without acknowledgment over an SVC. The range is 1 through 7 for Modulo-8, and 1 through 127 for Modulo-128. (We recommend a value greater than 7 for Modulo-128). The default is 2 for inbound and outbound transmission.

Table 3-8 Permanent VC Flow Control Field Descriptions

Packet Size: Inbound & Outbound	Maximum packet size to be used over a PVC. The range is 16 through 4096 octets. The default is 128 for inbound and outbound packets. Use the value given on your subscription form.
Window Size: Inbound & Outbound	Maximum number of packets that can be transmitted without acknowledgment over a PVC. The range is 1 through 7 for Modulo-8, and 1 through 127 for Modulo-128. (We recommend a value greater than 7 for Modulo-128). The default is 2 for inbound and outbound transmission.

Step 5. Click on **Modify Throughput Class Settings** to modify Switched and Permanent VC throughput class settings. The following dialog appears:

Figure 3-7

Modify X.25 Throughput Class Defaults (epeire)

Inbound
Class : Speed (bps)

Outbound
Class : Speed (bps)

Switched VC Default:

11 : 19200

11 : 19200

Switched VC Negotiated:

11 : 19200

11 : 19200

Restore Defaults

OK

Cancel

Help

Step 6. Enter or modify field values as required (refer to the field descriptions below).

Table 3-9 **Modify Throughput Class Settings Field Descriptions**

Switched VC Default: Inbound and Outbound	CCITT class number. If Throughput Class negotiation is disabled, this value replaces the Switched VC Negotiated field value. The range is 3 through 13 and the default is 11. See the table after these field descriptions listing the CCITT class numbers and the corresponding line speed Baud rate. Use the value given on your subscription form.
---	---

Table 3-9 Modify Throughput Class Settings Field Descriptions

Switched VC Negotiated: Inbound and Outbound	CCITT class number. If Throughput Class negotiation is enabled, this value is used as the opening bid for outbound calls and as a counter offer when the inbound opening bid is higher. The range is 3 through 13, and the default is 11. See the table below for CCITT class numbers and corresponding line speed Baud rate. Use the value given on your subscription form.
--	--

Table 3-10 Throughput Classes and Line Speeds

CCITT class number	Line speed Baud rate (bps)
3	75
4	150
5	300
6	600
7	1200
8	2400
9	4800
10	9600
11	19200
12	48000
13	64000

- Step 7.** Click on OK to return to the “Configure X.25 Card” window when you have finished verifying level 3 values.

Verifying Level 2 Values


Follow the steps below to verify level 2 values:

NOTE

If you subscribe to a public network, the network provider will provide the appropriate settings for all level 2 parameters. These settings will differ depending on the network provider and the type of service to which you subscribe. Refer to your Network Subscription Form for the correct settings for your configuration.

- Step 1.** At the “Configure X.25 Card” window, select Verify Level 2 Values. The following dialog appears:

Figure 3-8



Select either Modulo-8 or Modulo-128 to set the Level 2 Modulo values. The default is Modulo-8.

The valid window-size values for Modulo-8 range from 1 to 7. For Modulo-128, the valid window-size values range from 1 to 127.

- Step 2.** Enter or modify field values as required (refer to the field descriptions below). Use the **Help** button to display information and instructions for each field.

Table 3-11 **Verify Level 2 Values Field Descriptions**

k - Level 2 Window Size	Maximum number of frames that can be transmitted without an acknowledgment. The range is 1 through 7 for Modulo-8 and 1 through 127 for Modulo-128. The default is 7. Use the value given on your subscription form.
T1 - Retransmission Timer	Maximum number of milliseconds to wait for an acknowledgment before retransmitting a frame. The range is 100 to 12000. The default is 3000. Use the value given on your subscription form.
T3 - Idle Timer	Maximum number of milliseconds that a line can be idle before it is declared disconnected. This value should be greater than or equal to the Retransmission Timer (T1) times the Retransmission Count (N2). The range is 1000 to 240000. The default is 60000. Use the value given on your subscription form.
N1 - Frame Size	Maximum number of octets that can be transmitted in a single frame. The range is 149 (minimum) through 4103. The default is 149.
N2 - Retransmission Count	Maximum number of times a given frame can be transmitted before an error condition is identified. The range is 0 through 255. The default is 20.

NOTE

Because the timer values count the amount of time between unacknowledged frames, you may need to increase the values of T1 (Retransmission Timer) and T3 (Idle Timer) if you use Modulo-128 with a window size greater than seven.

- Step 3.** Click on **OK** to return to the “Configure X.25 Card” dialog when you have finished verifying level 2 values.

- Step 4.** Click on **OK** to complete X.25 software configuration and save your changes. Your X.25 interface (port) should appear in the object list with status **Enabled** (no problem found and link connected correctly). If not, carefully repeat the steps in this chapter until the configuration is enabled.

If your port is not connected to a running network, it will display as configured.

You have completed the interface configuration.

- Step 5.** Select **Exit** from the **File** menu if you have no need to configure access to other systems or to PAD services. Then exit SMH.

If you need to configure access to other systems or configure PAD services, stay in SMH and continue with the instructions in “Configuring Remote System Access” (to configure access to other systems) and in “Configuring PAD Services” (to configure PAD services).

NOTE

Your system will *not* reboot when you exit. Your configuration is effective immediately without the need to create a new kernel.

If you want to control Services (Internet/Berkeley Services or Network Services (NS)), refer to the documentation set for those products.

Configuring Remote System Access

Follow the steps below to configure access to other hosts and systems that use TCP/IP protocol. (The procedures in this section are optional. Your X.25 link software does not require that you configure access to other systems).

NOTE

System Administration Manager (SAM) is deprecated in the 11iv3 release of HP-UX. HP System Management Homepage (HP SMH), an enhanced version of SAM, is introduced for managing HP-UX.

Step 1. If you have not already done so, type **smh** at the HP-UX prompt.

Step 2. At the SMH main window, select “Tools”. Numerous object lists are displayed.

Step 3. At the “Networking and Communications” window, highlight **Hosts** and click on **OPEN**. Highlight **Local Hosts** and click on **OPEN**.

SMH displays all remote system names and IP addresses that have already been configured.


Step 4. Select **Add** from the **Actions** menu. The following dialog appears:

NOTE

The appearance of the “Add Internet Connectivity” dialog may be slightly different from the example below depending on the version of the X.25 software you are running.

Figure 3-9

Add Internet Connectivity Dialog



The dialog box is titled "Add Internet Connectivity (epeire)". It contains three input fields: "Internet Address:" with a text box and an "Add Aliases..." button to its right; "Remote System Name:" with a text box; and "Comments:" with a text box and the label "(optional)" to its right. At the bottom, there are four buttons: "OK", "Apply", "Cancel", and "Help".

Step 5. Enter or modify field values as required (refer to the field descriptions below). Use the **Help** button for information and instructions for each field.

A **Provide X.25 Information** button may appear on this dialog depending on the Internet address you configure. If it does, follow the instructions in Step 6. SMH may also decide that a gateway is required, again depending on the Internet address you configure (see the on-line Help for more information on gateways and the gateway dialog).

Table 3-12 **Add Internet Connectivity Field Descriptions**

Internet Address	Identifier by which the remote system is known on the network. It is composed of four integers (0 to 255) separated by periods (for example, 192.2.3.6). Use the Add Aliases button to assign one or more aliases (in alphanumeric format) to the IP Address for easier referencing. When you exit this field, SMH determines whether a gateway is needed for the connection, or whether you need to provide X.25 information for the remote system. If the Provide X.25 Information button is displayed, follow the instructions in Step 6 below.
Remote System Name	Name assigned to the remote system to which you want to connect.
Comments	Use this field to add useful information about the remote system (for example, the name and telephone number of the user).

Step 6. If the Provide X.25 Information button is displayed, you must use it to configure X.25 information about the remote system. When you click on Provide X.25 Information, the following dialog appears:

Figure 3-10

Provide X.25 Information (epeire)

Remote System Name:
Internet Address: 192.1.1.4

X.25 Address:

Choose type of Virtual Circuit

☐ Switched VC

☐ Permanent VC (PVC)

☐ Request reverse charging

☐ Accept reverse charging

☐ Closed user group(CUG)

Step 7. Enter or modify field values as required (refer to the field descriptions below).

If you add more VCs to an interface in the future, you must stop the interface with `x25stop` or with SMH's `Disable Card` function and restart it as an IP interface with SMH's `Enable Card` function or with the following command:

```
x25init -c [configuration_file]-a [ipmapfile]
```

Table 3-13 **Provide X.25 Information Field Descriptions**

X25 Address	X.25 address (sometimes referred to as the X.121 address) of the remote system. The X.25 address assigned by the network provider uniquely identifies the node in an X.25 network. The address consists of a maximum of 15 digits. You must complete this field.
Switched VC	Enable this field if a switched virtual circuit (SVC) will be used for this connection. When Switched VC is enabled (default), three additional fields can be configured: Request reverse charging, Accept reverse charging, and Closed user group (refer to the field descriptions below).
Permanent VC	Enable this field if a permanent virtual circuit (PVC) will be used for this connection. When Permanent VC is enabled, two additional fields can be configured: PVC Number and Local Programmatic Access Name.
Request reverse charging	Enable this field if the local system will make collect calls to the remote system. If this field is disabled, no collect calls can be made.
Accept reverse charging	Enable this field if you want the local system to accept collect calls from the remote system. If this field is disabled, no collect calls will be accepted.
Closed user group	Enable this field if you subscribed to a closed user group (CUG) and you want to use the CUG with this connection. Do not select this item if you did not subscribe to a CUG or if you do not want this connection to belong to a CUG. If you enable this field, an additional field (CUG Number) appears. Enter the number of the CUG to be associated with this connection.

- Step 8.** Click on Apply or OK. The Apply button leaves you in the current dialog so you can configure other remote systems; the OK button returns you to the Internet Addresses (& Routes) object list. SMH updates the object list to include the remote system you configured regardless of which button you used.

NOTE

You can modify or remove remote systems and modify default gateways by highlighting the Remote System Name on the object list and selecting Modify, Remove, or Modify Default Gateway from the Actions menu.

- Step 9.** Select Exit from the File menu.

Remote system access for your X.25 link is now configured.

Configuring X.25 over LLC2

This section describes how to configure X.25 over LLC2. Configuring X.25 over LLC2 allows X.25 layer 3 to connect to DLPI instead of LAP-B and provides the X.25 functionality on top of LAN cards such as Ethernet, FDDI, and TokenRing.

NOTE

In this document, an XOL interface on the peer or local system is referred to as “box”.

Configuration Files

To configure the LLC2 feature, the following configuration files must be added or updated manually:

- Generic X.25 configuration file
- LLC2 specific configuration file

Generic X.25 Configuration file

The generic X.25 configuration file is used with a few additional XOL specific parameters to configure X.25 over LLC2 (XOL). To support the XOL HA feature, some of the existing parameter names are modified and a few new parameters are introduced.

NOTE

The parameters introduced in an earlier release of X.25 are supported. However, HP recommends that you migrate to the new parameters. Migration is required for XOL HA support.

Table 3-14 lists the XOL specific parameters that must be defined while configuring an XOL interface.

Table 3-14 Additional XOL specific configuration parameters

Field	Format	Value
device	Device name string.	Name of the LAN card where the XOL interface is configured.
XOL_logical_port_id (replaces lan_box_id)	Integer 0-n	The XOL logical port identifier for the XOL interface on the given LAN card.
XOL_destination_macaddr (replaces the MAC address in the lan_box_addr)	One hexadecimal value. This value must be prefixed with 0x.	The destination MAC address to which the XOL interface is connected.
XOL_DSAP	One hexadecimal value. This value must be prefixed with 0x.	The destination SAP value of the peer XOL interface. Set the value of DSAP to any even value in the range 0x70 - 0x7e, both inclusive.
XOL_SSAP	One hexadecimal value. This value must be prefixed with 0x.	The source SAP value of the local XOL interface. Set the value of SSAP to any even value in the range 0x70 - 0x7e, both inclusive. If the value for SSAP is not provided, then SSAP takes the value of DSAP.

Table 3-14 Additional XOL specific configuration parameters (Continued)

Field	Format	Value
standby_device**	Device name string	Name of the standby LAN device used for local failover. For more details about this parameter, see “Configuring the High Availability Feature for X.25 over LLC2” on page 81. Required only for local failover support.
XOL_floating_macaddr**	One hexadecimal value; must be prefixed with 0x	The unique MAC address for the LAN card in the LAN subnet. For more details about this parameter, see “Configuring the High Availability Feature for X.25 over LLC2” on page 81. Required only for local failover support.

** Required for HA feature

NOTE

The configuration parameters may be specified in the old format. However, HP recommends that you use the new format while specifying the configuration parameter. XOL is not supported over APA (Auto Port Aggregation).

Following are two sample files. Example 3-1 provides a sample file that has the old parameters in the old format. Example 3-2 provides a sample file that has the new parameters in the new format.

Example 3-1 Sample File with the Old Parameters in the Old Format

```
device          lan00x7c
lan_box_id      1
lan_box_addr    0x080009c4728a 0x7e
```

Example 3-2 Sample File with the New Parameters in the New Format

```
device          lan0
XOL_logical_port_id      1
XOL_destination_macaddr  0x080009c4728a
XOL_DSAP 0x72
XOL_SSAP 0x7C
standby_device lan1
XOL_floating_macaddr 0x0060B0A4EBE5
```

A sample generic configuration file is available for reference. It is available in the `/etc/x25` directory and the filename is `x25init_llc2_smpl`.

Specific Configuration File

This file is an X.25 over LLC2 specific configuration file and contains information about every LAN. This file is unique to the host.

Following is the syntax of this file:

```
lan<#>      <number of boxes>
```

Following is a sample configuration file:

```
lan0        3
lan1        1
```

Following is an example of an XOL configuration file that is installed in `/etc/x25` directory. Following are the assumptions: The X.121 address of the local XOL interface is 7111 and that of the remote XOL interface is 7222.

Example 3-3 LLC2 Configuration

```
#
# Likely runstring: x25init -c x25init_llc2_smpl
X.121 7111          # X.121 address
```

Configuring X.25 over LLC2

```

X.121_packet  ' '  "      # use a null (i.e. length 0) packet address
(TransPacaddressing)

name interface0      # interface name for Level 3 access
device lan0          # device to initialize

XOL_logical_port_id 0      # logical port id for lan interface
XOL_DSAP 0x7E           # destination SAP id
XOL_SSAP 0x7E           # source SAP id
XOL_destination_macaddr 0x080009c4728a # Remote mac address
# Following needed only for Local High Availability feature
#standby_device lan1 # standby lan card for local failover.
#XOL_floating_macaddr 0x0060B0A4EBE5 # Unique Mac address to be assigned to the
lan card before bringing the XOL interface up.

# Level 2 Parameters
#
t1      3000
t3      60000
framesize      149
n2      20
l2window      7
# Level 3 Parameters
#      virtual circuit parameters
#      logical channel id, start num [1-4095], type, how many
lci 1 pvc 5      # 5 permanent VCs
lci 255 insvc 5      # 5 one-way incoming SVCs
lci 2048 svc 6      # 6 two-way switched VCs
networktype TRANSPAC # CCITT 1984, DTE (see /etc/x25/x25_networks)
fast_select enabled      # allow incoming calls with call user data
reverse_charge enabled    # allow incoming calls requesting reverse charges
def_inpacketsize 128      # default packetsize
def_outpacketsize 128     # default packetsize

```

```
def_inwindow 7          # default window size
def_outwindow 7         # default window size
def_inthruputclass 19200 # default thruput class
def_outthruputclass 19200 # default thruput class
flowcontrol on          # flow control negotiation allowed
neg_inpacketsize 128     # offered packet size if using flow control negotiation
neg_outpacketsize 128    # offered packet size if using flow control negotiation
neg_inwindow 7          # offered window size if using flow control negotiation
neg_outwindow 7 # offered window size if using flow control negotiation
thruputclass on
neg_inthruputclass 19200 # offered thruput class if using thruput class
negotiation
neg_outthruputclass 19200 # offered thruput class if using thruput class
negotiation
pvc_inpacketsize 128     # packet size for PVCs
pvc_outpacketsize 128    # packet size for PVCs
pvc_inwindow 7          # window size for PVCs
pvc_outwindow 7         # window size for PVCs
# IP Related Parameters
IP 15.4.64.120 255.255.248.0 # IP address and subnet mask
mtu 1024              # max transmission unit 1024 octets
hold 300              # 5 minute hold timer
idle 600              # 10 minute idle timer
```

NOTE

For an XOL configuration, L3 packet sizes greater than 1024 are not supported.

If the XOL interface on the host is connected to a router supporting X.25 over LLC2, the router must be configured with the correct routing entries. For example, if an XOL interface on the host is connected to a CISCO router and the XOL configuration on the host is identical to the configuration in the previous example, the following configuration is required:

- To enable the cmns, complete the following steps:

Step 1. Run the following command at the CISCO console:

```
Configure Terminal
```

Step 2. Run the following command at the CISCO console:

```
Interface fastethernet 1/0
```

Step 3. Run the following command at the CISCO console:

```
cmns enable
```

Step 4. Run the following command at the CISCO console:

```
<Ctrl+Z>
```

- To add routing entries to X.25 routing table, complete the following steps:

Step 1. Run the following command at the CISCO console:

```
Configure Terminal
```

Step 2. Run the following command at the CISCO console:

```
x25 route ^ 7111 interface FastEthernet1/10 mac  
0011.0a80.31d6
```

Step 3. Run the following command at the CISCO console:

```
x25 route ^ 7222 interface FastEthernet1/10 mac  
0800.09c4.728a
```

Step 4. Run the following command at the CISCO console:

```
<Ctrl+Z>
```

Starting and Stopping Configuration

Starting

To initialize the x25overllc2 devices, execute the x25init command with the -L option at the command prompt.

The syntax for execution is:

```
x25init -c <config_file> -L <llc2_config_file>
```

`config_file` is the generic X.25 product configuration file and `llc2_config_file` is the LLC2 specific configuration file.

A sample invocation is as shown below:

```
x25init -c x25init_def -L llc2_conf_def
```

This command is executed once per box. It can be executed with different `<x25init_llc2_sampl>` file but with the same `<llc2_conf_def>` file.

Stopping

To stop the communication with one box, the `x25stop` command is executed with the `-L` option. The syntax for execution is:

```
x25stop -d <lan#> -L <XOL_logical_port_id>
```

`<XOL_logical_port_id>` is the XOL logical port identifier for the XOL interface on the given LAN card.

NOTE

SMH support is not available for configuring X.25 over LAN(LLC2). Also, the `x25init` command needs to be executed manually if the system is rebooted.

For a detailed description of the configuration, see *x25overllc2* (7). For more information on how to configure High Availability, see “Configuring the High Availability Feature” on page 76.

For more information on LLC2, see *x25init* (1M), *x25stop* (1M), and *x25stat* (1M) manpages.

NOTE

To configure a Highly Available XOL interface, See “X.25 High Availability Configuration” on page 78.


Sample setup and Configuration

The X.25 over llc2 supports one or more XOL interfaces. Following are the two example configurations:

One Lan and Two Boxes configuration

A graphical representation of the above configuration with some arbitrary values for the MAC addresses and lan-ids is shown below:

Figure 3-11 **One LAN, Two Boxes Configuration**



To connect HOST to BOX 0

To implement the above configuration, the following configuration files need to be created on the **HOST** system.

- Generic X.25 configuration file, **x25_host_box_0**
- LLC2 configuration file, **llc2_lan_0**

The generic X25 configuration file has to be created in the **/etc/x25** directory using the example configuration file, **/etc/x25/x25init_def**.

The file `x25_host_box_0` should contain all the mandatory level 2 and level 3 parameters. Along with them it should contain the following entries:

```
device lan 0
XOL_logical_port_id 0
XOL_destination_macaddr 0x080009411371
XOL_DSAP 0x70
XOL_SSAP 0x70
```

The LLC2 specific configuration file, `llc2_lan_0` is created in the `/etc/x25` directory with the following entries:

```
lan0          2
```

To connect HOST to BOX 1

To configure HOST to communicate with BOX1, the generic configuration file named `/etc/x25/x25_host_box_1` has be created as follows:

Apart from the mandatory level2 and level3 parameters the following parameters have to be added:

```
device lan 0
XOL_logical_port_id 1
XOL_destination_macaddr 0x080009C4728A
XOL_DSAP 0x7E
XOL_SSAP 0x7E
```

The LLC2 specific configuration is `/etc/x25/llc2_lan_0`.

To start and stop above configuration:

Starting:

Execute the following commands at the command prompt:

```
x25init -c x25_host_box_0 -L llc2_lan_0
```

Stopping:

To stop the configuration execute the following commands:

```
x25stop -d lan0 -L 0 # stop XOL interface with logical port id 0 on lan0
x25stop -d lan0 -L 1 # stop XOL interface with logical port id 1 on lan0
```

To Connect Box 0 to HOST

Configuring X.25 over LLC2

To implement the above configuration, the following configuration files need to be created on the BOX 0.

- Generic X.25 configuration file, `x25_box_0_host`
- LLC2 configuration file, `llc2_lan_1`

The generic X25 configuration file has to be created in the `/etc/x25` directory using the example configuration file, `/etc/x25/x25init_llc2_smpl`.

```
device lan1
XOL_logical_port_id 0
XOL_destination_macaddr 0x080009DBEA7
XOL_DSAP 0x70
XOL_SSAP 0x70
```

The file `x25_box_0_host` must contain all the mandatory level 2 and level 3 parameters. Along with them it should contain the following entries:

The LLC2 specific configuration file, `llc2_lan_1` is created in the `/etc/x25` directory with the following entries:

```
lan1          1
```

To start and stop above configuration:

Starting:

Execute the following commands at the command prompt:

```
x25init -c x25_box_0_host -L llc2_lan_1
```

Stopping:

To stop the configuration execute the following commands:

```
x25stop -d lan1 -L 0 # stop XOL interface with logical port id 0 on lan1
```

To Connect Box 1 to HOST

To implement the above configuration, the following configuration files need to be created on the BOX 1.

- Generic X.25 configuration file, `x25_box_1_host`
- LLC2 configuration file, `llc2_lan_2`

The generic X25 configuration file has to be created in the `/etc/x25` directory using the example configuration file, `/etc/x25/x25init_llc2_smpl`.

The file `x25_box_1_host` must contain all the mandatory level 2 and level 3 parameters. Along with them it must contain the following entries:


```
device lan2
XOL_logical_port_id 0
XOL_destination_macaddr 0x080009DBEA7
XOL_DSAP 0x7E
XOL_SSAP 0x7E
```

The LLC2 specific configuration file, `llc2_lan_2` is created in the `/etc/x25` directory with the following entries:

```
lan2          1
```

To start and stop above configuration:

Starting:

Execute the following commands at the command prompt:

```
x25init -c x25_box_1_host -L llc2_lan_2
```

Stopping:


To stop the configuration execute the following commands:

```
x25stop -d lan2 -L 0 # stop XOL interface with logical port id 0 on lan2
```

Configuring Two Lans, with One Box Per Lan

A graphical representation of the above configuration with some arbitrary values for the MAC addresses and lan-ids is as shown:

Figure 3-12 **Two Lans, One Box per Lan configuration**



To Configure Host to LAN0 to Box0

To configure the Host to LAN 0, BOX 0 communication the following configuration files need to be created.

- Generic X.25 configuration file, x25_lan_0_box_0
- LLC2 configuration file, llc2_lan_0_lan_1

The x25_lan-0_box_0 file will contain all the level 3 and level2 parameters. It also contains the following entries:

```
device lan0
XOL_logical_port_id 1
XOL_destination_macaddr 0x080009411371
XOL_DSAP 0x70
XOL_SSAP 0x70
```

The LLC2 configuration file, `llc2_lan_0_lan_1` will have the following entries:

```
lan0          1
lan1          1
```

To configure Host to LAN 1 to BOX 1

To configure the Host to LAN 1 to BOX 1 communication, the following configuration file need to be created.

- X.25 generic configuration file, `x25_lan_1_box_1`
- LLC2 configuration file, `llc2_2_lan_0_lan_1`

The `x25_lan_1_box_1` file is created in the `/etc/x25` directory. It will contain all the level 2 and level 3 parameters. It will also contain the following entries:

```
device lan1
XOL_logical_port_id 1
XOL_destination_macaddr 0x080009C4728A
XOL_DSAP 0x7E
XOL_SSAP 0x7E
```

There is only one LLC2 specific configuration file per Host. The file is `llc2_lan_0_lan_1`.

To Start and Stop above configuration:

Starting:

After reconfiguring the kernel of the two boxes execute the following commands at the command prompt:

```
x25init -c x25_lan_0_box_0 -L llc2_lan_0_lan_1
x25init -c x25_lan_1_box_1 -L llc2_lan_0_lan_1
```

Stopping:

To stop the configuration, execute the following commands at the command prompt:

```
xstop -d lan0 -L 1 # stop XOL interface with logical port id 1 on lan0
xstop -d lan1 -L 1 # stop XOL interface with logical port id 1 on lan1
```

To Connect Box 0 to HOST

To implement the above configuration, the following configuration files need to be created on the BOX 0.

- Generic X.25 configuration file, x25_box_0_host.
- LLC2 configuration file, llc2_lan_2

The generic X25 configuration file has to be created in the /etc/x25 directory using the example configuration file, /etc/x25/x25init_llc2_smpl.

The file x25_box_0_host must contain all the mandatory level 2 and level 3 parameters. Along with them it must contain the following entries:

```
device lan2
XOL_logical_port_id 0
XOL_destination_macaddr 0x080009DBEA7
XOL_DSAP 0x70
XOL_SSAP 0x70
```

The LLC2 specific configuration file, llc2_lan_2 is created in the /etc/x25 directory with the following entries:

```
lan2          1
```

To start and stop above configuration:

Starting:

Execute the following commands at the command prompt:

```
x25init -c x25_box_0_host -L llc2_lan_2
```

Stopping:

To stop the configuration execute the following commands:

```
x25stop -d lan2 -L 0 # stop XOL interface with logical port id 0 on lan2
```

To Connect Box 1 to HOST

To implement the above configuration, the following configuration files need to be created on the BOX 1.

- Generic X.25 configuration file, x25_box_1_host.
- LLC2 configuration file, llc2_lan_3

The generic X25 configuration file has to be created in the `/etc/x25` directory using the example configuration file, `/etc/x25/x25init_llc2_smpl`.

The file `x25_box_0_host` should contain all the mandatory level 2 and level 3 parameters. Along with them it should contain the following entries:

```
device lan3
XOL_logical_port_id 0
XOL_destination_macaddr 0x080009DBEA7
XOL_DSAP 0x7E
XOL_SSAP 0x7E
```

The LLC2 specific configuration file, `llc2_lan_2` is created in the `/etc/x25` directory with the following entries:

```
lan3          1
```

To start and stop above configuration:

Starting:

Execute the following commands at the command prompt:

```
x25init -c x25_box_0_host -L llc2_lan_3
```

Stopping:

To stop the configuration execute the following commands:

```
x25stop -d lan3 -L 0 # stop XOL interface having logical port id 0 on lan3
```

Troubleshooting LLC2 Configuration

Symptom: Unable to connect to the remote node.

Causes:

- Hardware address of the remote node is wrongly configured in the configuration file.
- The SAP value is incorrectly configured.
- The LCI value is incorrectly configured.

Action:

- Check the remote node's hardware address using `lanscan`. Use the same hardware address in the generic X.25 configuration file. If you modify the hardware address to correct the error then, re-initialize the card using `x25init`.
- If the nodes are connected back to back, check if the SAP's are identical for both the nodes in the generic X.25 configuration file.
- If the nodes are connected back to back and one of the machines is configured for inbound connections only and the other machine is configured for outbound connections only then, the starting LCI for both the nodes must be identical in the generic X.25 configuration file.

Configuring PAD Services

This section contains step-by-step instructions for configuring PAD services. Skip this section if you don't need to configure PAD services.

The procedures in this section are optional. Your X.25 link software does not require you to configure PAD services.

You can use SMH to add or modify the following:

- PAD terminal emulation (local to remote)
- PAD support server (remote to local)
- PAD printer server
- PAD UUCP server
- X.3 sets of parameters

See Chapter 6, PAD Services, for detailed reference information on PAD services.

This section assumes that SMH is running and that you are starting from the main window. If this is not the case, type `smh` at the HP-UX prompt before continuing.

Remember to use the **Help** button (in the SMH window) to display information and instructions for the content of each field.

Add/Modify PAD Terminal Emulation (Local to Remote)

Follow the steps below to add or modify PAD terminal emulation for a remote system:

- Step 1.** At the SMH main window, highlight “Networking and Communications” and select **Open** Item from the Actions menu.
- Step 2.** At the “Networking and Communications” window, highlight **X.25 PAD Services** and select **Open** Item from the Actions menu.
- Step 3.** Highlight **Terminal Emulator** and select **Open** Item from the Actions menu.

SMH displays an object list that shows all remote systems currently configured for PAD terminal emulation.

- Step 4.** Select **Add** from the **Actions** menu to configure PAD terminal emulation for an unlisted remote system, or highlight a remote system from the list and select **Modify**.
- Step 5.** Enter or modify field values as required.
- Step 6.** Click on **Apply** to apply the new settings and to add additional system connections. Click on **OK** to save changes and exit this dialog.
- Step 7.** Select **Exit** from the **List** menu to return to the “X.25 PAD Services” dialog.

NOTE

If you enabled **Reverse Charge Requested**, you must also configure the PAD support server. See “**Add/Modify PAD Support Server (Remote to Local)**” for step-by-step instructions for configuring the PAD support server.

- Step 8.** Select the next PAD service you need to configure from the list on the “X.25 PAD Services” dialog.

Add/Modify PAD Support Server (Remote to Local)

Follow the steps below to add or modify a PAD support server for a local terminal or system:

- Step 1.** At the SMH main window, highlight “**Networking and Communications**” and select **Open Item** from the **Actions** menu.
- Step 2.** At the “**Networking and Communications**” window, highlight **X.25 PAD Services** and select **Open Item** from the **Actions** menu.
- Step 3.** Highlight **Support Server** and select **Open Item** from the **Actions** menu.

SMH displays an object list that shows all terminals/systems currently configured for access via X.25.

- Step 4.** Select **Add** from the **Actions** menu to configure a terminal/system that is not listed for access via X.25, or highlight a terminal/system from the list and select **Modify**.

- Step 5.** Enter or modify field values as required.
- Step 6.** Click on **Apply** to apply the new settings and to add additional PAD support servers. Click on **OK** to save changes and exit this dialog.
- Step 7.** Select **Exit** from the **List** menu to return to the “X.25 PAD Services” dialog.
- Step 8.** Select the next PAD service you need to configure from the list on the “X.25 PAD Services” dialog.

Add/Modify PAD Printers Server

Follow the steps below to add or modify remote PAD printers:

- Step 1.** At the SMH main window, highlight “Networking and Communications” and select **Open Item** from the **Actions** menu.
- Step 2.** At the “Networking and Communications” window, highlight **X.25 PAD Services** and select **Open Item** from the **Actions** menu.
- Step 3.** Highlight **Printers Server** and select **Open Item** from the **Actions** menu.

SMH lists all remote printers that your system can currently access via X.25.

- Step 4.** Select **Add** from the **Actions** menu to configure access to an unlisted remote printer, or highlight a remote printer from the list and select **Modify**.
- Step 5.** Enter or modify field values as required.
- Step 6.** Click on **Apply** to apply the new settings and to add additional PAD printers. Click on **OK** to save changes and exit this dialog.
- Step 7.** Select **Exit** from the **List** menu to return to the “X.25 PAD Services” dialog.
- Step 8.** Select the next PAD service you need to configure from the list on the “X.25 PAD Services” dialog.

Add/Modify UUCP Server

Follow the steps below to add or modify a UUCP server:

- Step 1.** At the SMH main window, highlight “Networking and Communications” and select `Open` Item from the `Actions` menu.
- Step 2.** At the “Networking and Communications” window, highlight `X.25 PAD Services` and select `Open` Item from the `Actions` menu.
- Step 3.** Highlight `UUCP Server` and select `Open` Item from the `Actions` menu.
SMH lists all remote systems currently configured for X.25 PAD UUCP connectivity.
- Step 4.** Select `Add` from the `Actions` menu to configure PAD UUCP connectivity for an unlisted remote system, or highlight a remote system from the list and select `Modify`.
- Step 5.** Enter or modify field values as required.
- Step 6.** Click on `Apply` to apply the new settings and to add additional PAD UUCP connections. Click on `OK` to save changes and exit this dialog.
- Step 7.** Select `Exit` from the `List` menu to return to the “X.25 PAD Services” dialog.
- Step 8.** If necessary, select the next PAD service you need to configure from the list.

In order for PAD UUCP connectivity to function correctly, UUCP must also be configured. If you have not already done this, you can configure UUCP by returning to the “Networking and Communications” window, highlighting `UUCP` and selecting `Open` Item from the `Actions` menu. From this dialog you can configure `UUCP Devices` and/or `UUCP Remote Systems` (see the on-line Help or UUCP documentation for more information).

Add/Modify X.3 Parameters

Follow the steps below to add or modify X.3 parameters. Refer to Chapter 6, PAD Services, for detailed descriptions of the X.3 parameters.

NOTE

The X.3 values that you configure here are *initially* downloaded to the PAD. As the terminal characteristics of your session change, the X.25 software automatically downloads new values for certain parameters. Do not be alarmed if the values of some parameters are different from the values you initially specified.

Step 1. At the SMH main window, highlight “Networking and Communications” and select `Open` Item from the `Actions` menu.

Step 2. At the “Networking and Communications” window, highlight `X.25 PAD Services` and select `Open` Item from the `Actions` menu.

Step 3. Highlight `X.3 Sets of Parameters` and select `Open` Item from the `Actions` menu.

SMH displays an object list showing all X.3 sets or profiles currently configured.

Step 4. Select `Add` from the `Actions` menu to configure an unlisted X.3 set, or highlight an X.3 set from the list and select `Modify`.

When you select `Add`, SMH displays the “Set X.3 Default Values” dialog. This dialog lets you set defaults for PAD terminal emulation, PAD support server, PAD printers server, or PAD UUCP server.

Step 5. Enter or modify field values as required. Click on `Help` for information and instructions for each field. A full description of X.3 parameters are provided in Chapter 6, “PAD Services.”

Step 6. Click on `Apply` to apply the new settings and to add additional X.3 sets. Click on `OK` to save changes and exit this dialog.

Step 7. Select `Exit` from the `List` menu.

Configuring the High Availability Feature

The X.25 link software provides integration of the X.25/Streams solution to the High Availability HP MC/ServiceGuard feature on HP 9000 Series 800 Systems, allowing local and remote failure recovery.

This feature requires that the HP MC/ServiceGuard product (B3936AA) has been installed and that the X.25 software uses switches that support Hunt Group Facility allowing multiple DTEs to share a common X.121 address.

You should be familiar with the HP MC/ServiceGuard product prior to installation. For more information on Serviceguard, see *Managing MC/ServiceGuard*.

The High Availability features include:

- **Local Failure:** Support of local failure for an X.25 link is provided by a PDN using existing X.25 functionality. If a local X.25 PSI card fails, the calling DTE will see the link go down.

The Hunt Group facility results in all incoming calls being directed to the remaining “good” X.25 PSI card in the system.

- **Remote Failure:** HP MC/ServiceGuard, uses the `x25ifstate` command to monitor the X.25 status. If the monitor detects that the X.25 link it is monitoring has gone down, all it has to do is exit.

HP MC/ServiceGuard detects that the monitor service belonging to the package has disappeared, stops the package, and starts the migration towards a second system.

The X.121 address of the first package is taken over by the second system from the X.25 configuration file.

X.25 Cluster Definition

To configure a High Availability cluster, use SMH to define all cluster systems by giving their:

NODE_NAME

NETWORK_INTERFACE

HEARTBEAT_IP

X.25 Commands to be Configured in High Availability Packages

Start X.25 link

```
x25init -c x25config -a ipmap -d x25dev(see x25init (1m))
```

Stop X.25 link

```
x25stop -d x25dev(see x25stop (1m))
```

Monitor X.25 link

```
x25ifstate -d x25dev -H(see x25ifstate (1m))
```

X.25 Package Definition

An X.25 package is needed for each HA X.25 node. This package allows HP MC/ServiceGuard to automatically:

- start the X.25 link (x25init command) when the X.25 package starts
- start a process (x25ifstate command) to monitor the state of the X.25 link
- stop the failed X.25 package before migrating to a backup node

To define each X.25 package, you need:

Package Name:

to identify the X.25 package. Use a name such as x25pkg1.

Service Name:

to monitor the X.25 link to be managed

Service Command:


to monitor the X.25 link status. It could be either a script based on `x25ifstate` or the `x25ifstate` command directly, depending on your configuration.

Package Control Script Location:

location of the script to start/stop the X.25 link and execute the service(s).

X.25 High Availability Configuration

General Solution for Local and Remote Failover



Example 3-4

One EXAMPLE of Remote Failure

The only file that contains the X.25 commands to run for High Availability is the `/etc./cmcluster/pkg*/control.sh` file (one per X.25 package).

```
# SERVICE NAMES AND COMMANDS
SERVICE_NAME [0] =pkg1.Service_Name_01 (same SERVICE_NAME as in pkg conf)
SERVICE_CMD [0] ="/usr/sbin/x25ifstate -d /dev/x25_1 -H -t 5"
SERVICE_RESTART [0] = " "
```

#add below the service names which define the applications that rely on the X.25 card

```
# e.g.# SERVICE_NAME [1] = <other name>
# SERVICE_CMD [1] = <other monitor>
# START OF CUSTOMER DEFINED FUNCTIONS
function customer_defined_run_cmds
{
#ADD customer defined run commands
: # do nothing instruction, because a function must contain at least one command.
x25init -c /etc/x25/x25config_1 -a /etc/x25/ip_to_x121_map
sleep 5
test_return 51
}
function customer_defined_halt_cmds
{
#ADD customer defined halt commands
: # do nothing instruction, because a function must contain some command.
#stopping the specific X.25 card means the signal modem will be down
x25stop -d /dev/x25_1
test_return 52
}
```

Checking the Configuration

Check that your configuration is correct using `x25server`, `x25check`, and `ping`.

x25server Run the `x25server` command. This starts a background process that waits for packets from an `x25check` command and sends a reply.

x25check Execute the `x25check` command, using your X.121 address:

```
$ x25check 250207
```

```
X25CHECK (c) COPYRIGHT Hewlett-Packard Company 1988.
Test Starts on .. Wed Dec 8 09:15:01 1993
```

```
Initialization of the test...
CALL packet sent ...
```

```
The following figures have been measured on the network:
Set up time : 267 ms
Remote Connection Succeeded
```

Execute the `x25check` command again, but this time with data packets:

Configuring the High Availability Feature

```
$ x25check 250207 -s 32 -n 1
```

```
X25CHECK (c) COPYRIGHT Hewlett-Packard Company 1988.
```

```
Test Starts on .. Wed Dec 8 09:15:47 1993
```

```
Initialization of the test...
```

```
CALL packet sent ...
```

```
DATA packet sent ... DATA packet received
```

The following figures have been measured on the network:

```
Set up time : 286 ms
```

```
Transit time : 245 ms
```

```
Remote Connection Succeeded
```

If your system has multiple X.25 cards, you may need to specify the particular interface in order for x25check to work properly. For example, to run x25check on the second port of the first card (interface x25_0p2), you would use the following format:

```
x25check 250207 -i interface0p2
```

ping command Run the ping command to check your IP over X.25 connection. You can use either an IP address, or the alias for the local node (defined in the hosts file). The following example sends 6 packets of 100 bytes:

```
ping hpindla 100 -n 6
```

```
PING hpindla: 100 byte packets
```

```
100 bytes from 15.128.131.152: icmp_seq=1. time=321. ms
```

```
100 bytes from 15.128.131.152: icmp_seq=2. time=320. ms
```

```
100 bytes from 15.128.131.152: icmp_seq=3. time=319. ms
```

```
100 bytes from 15.128.131.152: icmp_seq=4. time=318. ms
```

```
100 bytes from 15.128.131.152: icmp_seq=5. time=320. ms
```

```
100 bytes from 15.128.131.152: icmp_seq=6. time=321. ms
```

```
--hpindla PING Statistics--
```

```
6 packets transmitted, 6 packets received, 0% packet loss
```

```
round-trip (ms) min/avg/max = 318/319/321
```

You can then check your IP over X.25 connection to a remote host using its IP address or alias.

If ping does not run successfully on the local node address, refer to Chapter 8, “Troubleshooting.”

Configuring the High Availability Feature for X.25 over LLC2

This section describes how to configure the local and remote failover features for X.25 over LLC2 (XOL) interface. It also describes the local, remote, and a combination of local and remote failover.

WARNING

The failover is not transparent and results in loss of data and existing connections. After a failover, the XOL connections must be re-established.

Unique MAC Address Requirement

XOL High Availability (XOL HA) is based on sharing a unique MAC address for the primary and standby LAN cards, whichever is active. The use of a unique MAC address makes the card swap transparent from the XOL router side or peer system, which sees the same MAC address associated with the active interface.

NOTE

To avoid MAC address collision, the system administrator must identify an unused, unique MAC address in their LAN subnet. The `lanadmin` command is used to change the MAC address of the card. After failover, the failed LAN card is reconfigured with its factory default MAC address. XOL is not supported over APA (Auto Port Aggregation).

Before you run the `lanadmin` command to set up the unique MAC address, you may test whether the MAC address chosen by you is selected by running the `linkloop` command. For more information, see `linkloop (1m)`. The uniqueness of the MAC address is verified on the LAN cards currently active in the LAN segment. The `linkloop` command sends an OK message if the MAC address is already in use.

NOTE

The routing table of the router connected to the host system must be updated with the unique MAC address identified by the user. If the XOL router supports the Hunt Group facility for XOL HA, the unique MAC address may not be required to achieve the HA functionality for XOL interface. For more information on Hunt Group facility, see “Configuring the High Availability Feature for X.25 over LLC2” on page 81.

WARNING

When several highly available XOL interfaces are configured on a given LAN card, failover of all the highly available XOL interfaces to the standby LAN card occurs immediately after one XOL interface fails. This is because the same unique MAC address is used by all XOL interfaces on the given LAN card.

Local Failover

NOTE

You need not install ServiceGuard for Local failover.

For local failover to happen, you must define a standby LAN card in the X.25 configuration file. The primary X.25 configuration file is used to configure the XOL interface on the standby LAN card after the local failover. As a result, the standby LAN card inherits all the configuration parameters from the primary interface, including the XOL logical port-id (also called box-id). The XOL interface starts first on the primary LAN card. If this XOL interface fails, an attempt is made to restart it on the standby LAN card. If the XOL interface fails on the standby LAN card, an attempt is made to failover back to the primary LAN card. This failover succeeds only if the primary LAN card is back UP and operational. Otherwise, the XOL interface goes down.


For more information on how to use this local failover functionality, see “Configuring XOL HA for Local Failover Without ServiceGuard” on page 83.

Configuring XOL HA for Local Failover Without ServiceGuard

In Figure 3-13, system A has two LAN cards, namely, lan0 (the primary LAN card) and lan1 (the standby LAN card). The standby LAN card provides local failover for the XOL interface with X.121 address 1111. The user supplied, unique MAC address that is specified in the XOL configuration file as a value for the field XOL_floating_macaddr, for that LAN segment is uMAC.

The XOL interface with X.121 address 1111 is brought up on lan0 on system A (uMAC is automatically assigned to lan0 on system A when the XOL interface is initialized).

Figure 3-13 Before the Failover




When the lan0 (the primary LAN card) fails, the XOL interface stops on lan0, and a XOL interface is brought up automatically on lan1 (the standby LAN card on system A) using the same configuration file. An attempt is made to configure lan0 with the factory default MAC address, and uMAC is assigned to lan1 on system A during the local failover. The

Configuring the High Availability Feature for X.25 over LLC2

X.25 connection must be re-established on the XOL interface. When the card lan0 comes up later, it is configured with the factory default MAC address.

Figure 3-14 After the Failover



To configure XOL local failover, complete the following steps:

NOTE

The XOL HA feature is enabled by default in HP-UX 11i v3. Therefore, the -enableXOLHA option is no longer required.

- Step 1.** To configure the standby device and the unique MAC address in the configuration file of the XOL primary interface, modify the following syntax:

```
Standby_device <standby LAN card name> # used for local failover
```

```
XOL_floating_macaddr <unique MAC address>
```

NOTE

Local failover is automatically enabled by defining a `standby_device` in the configuration file. If you do not require the local failover feature for this interface, you must de-configure the `standby_device` by removing or commenting the line in the configuration file. The standby XOL interface inherits the configuration of the primary XOL interface during failover because the same configuration file is used to configure the XOL interface.

Example 3-5**Configuring Standby Device and Unique MAC Address**

If the assumptions in the XOL configuration file are the following:

- The primary LAN card is `lan0`
- The standby LAN card is `lan1`
- The MAC address is `0x0060B0A4EbE5`

Then, the XOL HA parameters take the following values:

```
standby_device lan1
```

```
XOL_floating_macaddr 0x0060B0A4EBE5
```

NOTE

In the event of a failover, the `XOL_floating_macaddr` is moved from the primary LAN card to the standby LAN card. HP recommends that you use the primary and standby LAN cards only for the XOL links configured with HA feature.

- Step 2.** To initialize the XOL HA interface with local failover support, run the following command:

```
x25init -c <XOL_config_file> -L <llc2_conf_def>
```

Remote Failover

NOTE

Remote failover, with or without local failover, requires the installation of the ServiceGuard product on the system. For more information on HP MC/ServiceGuard product, see *Managing MC/ServiceGuard* document.


In the ServiceGuard cluster, the remote failover works between LAN cards on different nodes. Each LAN card has an XOL interface which is defined by the same configuration filename used in the SG package. The `x25ifstate` command monitors the XOL interface status. When the XOL interface fails, the `x25ifstate` command exits. HP MC/ServiceGuard detects that the monitor service belonging to the package has exited and stops the package. HP MC/ServiceGuard then starts the same package on the standby node of the ServiceGuard cluster, which starts the XOL interface on the LAN card on the standby node.

For more information on using the remote failover functionality with Service Guard, see “Configuring XOL HA for Remote Failover Using Service Guard (SG)” on page 86.

Configuring XOL HA for Remote Failover Using Service Guard (SG)


In Figure 3-15, primary system A and standby system B are part of the SG cluster and provide remote failover of an XOL interface with X.25 address 1111. The unique, user supplied MAC address is uMAC for that LAN segment. It is initially assigned to the card lan0 on primary system A.

Figure 3-15 Before the Failover



If the SG package for XOL detects an error in the XOL interface, the package is stopped on the primary system and the equivalent package starts on the standby system. When the SG package is stopped on system A, the XOL interfaces (and optionally applications) on the failed LAN card are stopped. An attempt is made to configure LAN card on system A with the factory default MAC address. When the SG package starts on system B, the LAN card on system B is configured with the unique MAC (uMAC) address, and the XOL interfaces (and optionally applications) starts on it. When the failed LAN card on system A comes up later, it is configured with the factory default MAC address.

Figure 3-16 After the Failover



XOL Cluster Definition

You must define the cluster by providing the system names that are part of SG cluster.

X.25 Commands Used in the SG Package Control Scripts:

- To set the MAC address, run the following command:
`lanadmin -A <MAC address> <PPA>`
- To start XOL interface, run the following command:
`x25init -c /etc/x25/x25config_llc2 -L /etc/x25/llc2_conf_def`
- To monitor the XOL interface, run the following command:
`x25ifstate -d /dev/x25_011 -H`
- To stop the XOL interface, run the following command:


```
x25stop -d /dev/x25_011
```

XOL Package Definition

An XOL SG package is required to configure a highly available XOL interface on all nodes in the SG cluster. This package allows HP MC/Service Guard to automatically:

- Assign a unique MAC address (using the `lanadmin` command) to the LAN card in use.
- Start the X.25 link (`x25init` command) when the X.25 package starts.
- Run the command `x25ifstate` to monitor the state of the XOL interface.
- Stop the XOL interface when the monitoring command detects a failure.

To define the X.25 package, you require the following attributes:

Package Name Identifies the X.25 package, for example, `xol_pkg1`.

Service Name Monitors the XOL interface to be managed, for example, `xol_SG_service1`

Service Command Monitors the XOL interface status, for example, `x25ifstate`

To configure XOL remote failover, complete the following steps:

NOTE

The XOL HA feature is enabled by default in HP-UX 11i v3. Therefore, the `-enableXOLHA` option is no longer required.

NOTE

When the XOL interface goes down, the service command (x25ifstate) exits. The SG performs a package failover to the standby node configured in the SG cluster.

The SG package file that contains the X.25 commands is /etc./cmcluster/pkg*/control.sh file (one per XOL package). Following is a sample SG package file:

Example 3-6 XOL SG package for remote failover

```
# SERVICE NAMES AND COMMANDS

SERVICE_NAME [0] =pkg1.Service_Name_01 (same SERVICE_NAME as in pkg conf)
SERVICE_CMD [0] ="/usr/sbin/x25ifstate -d /dev/x25_011 -H "
SERVICE_RESTART [0] = " "

# Unique MAC address in the subnet (LAN segment), which is
# not in use. This will be the Active MAC address on the
# active node in the cluster.

Supplied_MAC = 0x0060B0A4EBE5

# START OF CUSTOMER DEFINED FUNCTIONS
function customer_defined_run_cmds
{
# START of customer defined run commands.
/usr/sbin/x25stop -d /dev/x25_011
sleep 2
/usr/sbin/lanadmin -A $Supplied_MAC 0
/usr/sbin/x25init -c /etc/x25/x25config_llc2_1 -L /etc/x25/llc2_conf_def
sleep 5
test_return 51
# END of customer defined run commands
```

```
}  
  
function customer_defined_halt_cmds  
{  
# START of customer defined halt commands.  
/usr/sbin/x25stop -d /dev/x25_011  
Sleep 2  
test_return 52  
# END of customer defined halt commands  
}
```

Remote Failover with Local Failover Support Using Service Guard

This is a combination of local failover and remote failover. For information on the local and remote failovers, see “Configuring XOL HA for Local Failover Without ServiceGuard” on page 83 and “Configuring XOL HA for Remote Failover Using Service Guard (SG)” on page 86. If the interface cannot be activated on either the primary or the standby LAN card at a given time on the local node, the SG package initiates the remote failover to the LAN card on the standby node in the SG cluster.

NOTE

On any given LAN card, the combination of highly available and not highly available XOL interfaces is not supported. Either all or none of the interfaces must be configured with HA (for local or remote failover) on any given LAN card. This is because the same unique MAC address is used by all XOL interfaces on the given LAN card.

To support remote failover with local failover, complete the following steps:

NOTE

Enabling or disabling of HA feature for XOL interface is system wide. Before enabling or disabling the HA feature on a system, all existing XOL interfaces must be stopped. The XOL HA feature is enabled by default on 11i v3.

- Step 1.** To configure the standby device and the unique MAC address in the configuration file of the XOL primary interface, modify the following syntax:

```
Standby_device <standby LAN card name> # used for local failover
```

```
XOL_floating_macaddr <unique MAC address>
```

NOTE

Local failover is automatically enabled if a “standby_device” is defined in the configuration file. If you do not want the local failover feature for this interface, you must de-configure the standby_device by removing or commenting the line in the configuration file. The XOL interface inherits the configuration of the primary XOL interface during failover because the same configuration file is used to configure the XOL interface.

Example 3-7**Configuring Standby Device and Unique MAC Address**

If the assumptions in the XOL configuration file are the following:

- The primary LAN card is lan0
- The standby LAN card is lan1
- The MAC address is 0x0060B0A4EbE5

Then, the above parameters take the following values:

```
standby_device lan1
```

```
XOL_floating_macaddr 0x0060B0A4EBE5
```

NOTE

In the event of a failover, the `XOL_floating_macaddr` is moved from the Primary LAN card to the standby LAN card. HP recommends that you use the primary and standby LAN cards only for the XOL links configured with HA feature.

Step 2. Configure the SG package. For information on achieving remote failover functionality, see “XOL Package Definition” on page 89.

For remote failover with local failover support, define the XOL package with the following changes:

- In the Start script of the package, stop the monitor if it is running. For details, see Example 3-6 on page 90.
- In the XOL package definition, use `x25HAMonitor` command instead of `x25ifstate` as the service command, as follows:

```
x25HAMonitor -c /etc/x25/x25config_llc2 -L
/etc/x25/llc2_conf_def -m
```

NOTE

The `x25HAMonitor` command helps in failover of the XOL interface between the primary and standby LAN cards (on the local system), if the LAN card (either primary or standby) on which the XOL interface was active fails. The `x25HAMonitor` exits if it does not start the XOL interface on the local system on either the primary or standby LAN card. The SG does a package failover to the standby node configured in the SG cluster.

Step 3. To start the SG package, run the following command

```
cmrunpkg -v <package name>
```

Example 3-8 Remote Failover with Local Failover support

The following two entries must be added to the LLC2 configuration file:

```
standby_device lan2 # lan2 is standby LAN.
XOL_floating_macaddr 0x0060B0A4EBE5 # Unique MAC address in the subnet
```

The SG package file that contains the X.25 commands is
`/etc./cmcluster/pkg*/control.sh` file (one per XOL package).

Configuring the High Availability Feature for X.25 over LLC2

```

# SERVICE NAMES AND COMMANDS

SERVICE_NAME [0] =pkg1.Service_Name_01 (same SERVICE_NAME as in pkg conf)
SERVICE_CMD [0] ="/usr/sbin/x25HAmontior -c x25config_llc2 -L llc2_conf_def -m "
SERVICE_RESTART [0] = " "


# Unique MAC address in the subnet (LAN segment) which is not in use. This will
be the Active MAC address on the active node in the cluster.

Supplied_MAC = 0x0060B0A4EBE5


# START OF CUSTOMER DEFINED FUNCTIONS

function customer_defined_run_cmds
{
# START of customer defined run commands.

/usr/sbin/x25stop -d /dev/x25_110      # primary lan PPA is 1 and
XOL_logical_port_id is 0

sleep 2

/usr/sbin/lanadmin -A $Supplied_MAC 1

/usr/sbin/x25init -c /etc/x25/x25config_llc2_1 -L /etc/x25/llc2_conf_def

sleep 5

# Check and stop the x25HAmontior if already running
# This is needed as Service Guard monitor starts the monitor later

PID=`/usr/bin/ls /var/x25/tmp/x25HAmontior_110.* | /usr/bin/awk -F '.' '{ print
$2 }'`

PROC_NAME=`/usr/bin/ps -e | /usr/bin/grep $PID | /usr/bin/awk '{ print $4 }'`

    if [[ $PROC_NAME = "x25HAmontior" ]]
    then

        /usr/bin/kill $PID

    fi

test_return 51

# END of customer defined run commands
}

```

```
function customer_defined_halt_cmds
{
# START of customer defined halt commands.
/usr/sbin/x25stop -d /dev/x25_110
Sleep 2
# Assuming that lan2 was configured as standby lan
/usr/sbin/x25stop -d /dev/x25_210
Sleep 2
test_return 52
# END of customer defined halt commands
}
```

Verifying the X.25 Link

After completing the installation and configuration instructions, follow these steps to verify your link:

- Step 1.** If you are using IP over X.25, use the `ping` command to check that the IP connection is operating properly. Refer to your man pages for details on the `ping` command. Examples are given below.

To check the connection to and from the network to the IP address (for example, 193.6.3.2), type:

```
ping 193.6.3.2
```

To check the full connection across the network to the remote system's IP address (for example, 193.6.1.1), type:

```
ping 193.6.1.1
```

- Step 2.** If `ping` was unsuccessful, use the `x25check` and `x25server` commands to verify that the X.25 connections are operating properly. Refer to your man pages for detailed information on the these commands.

NOTE

If you have problems with the operation of your X.25 link, repeat the installation process described in Chapter 2, Installation, and the configuration instructions in this chapter, or refer to Chapter 8, Troubleshooting, for troubleshooting information.

4 OLA/R Overview and Concepts

Introduction

The letters O, L, A and R stand for On Line Addition [and] Replacement. This, of course, refers to the ability of a PCI I/O card to be replaced/added to an HP-UX computer system designed to support this feature without the need for completely shutting down, then re-booting the system or affecting other system components. The system hardware uses the per-slot power control combined with operating system support to enable this feature.

Initially, not all add-in cards will have this capability but over time users should see many cards adding this capability to their set of functions.

IMPORTANT

Certain “Classes” of hardware are not intended for access by users. At this time this includes Z-class (SuperDome) systems. HP recommends that these systems only be opened by a qualified HP Engineer. Failure to observe this requirement can invalidate any support agreement or warantee to which the owner might otherwise be entitled.

IMPORTANT

For those wishing to use OLAR, your system may need to update its system firmware. For additional details, please refer to the "Read Before Installing or Updating to HP-UX 11i v3" document.

Important Terms and Concepts

Table 4-1 Terms used in this section

Term	Meaning
OLA/R	All aspects of the OLA/R feature including On-line Addition (OLA) and On-line Replacement (OLR).
Power Domain	A grouping of 1 or more interface card slots that are powered on or off as a unit.
target card / target card slot	The interface card which will be added or replaced using OLA/R, and the card slot it resides in.
affected card / affected card slot	Interface cards and the card slots they reside in and are in the same power domain as the target slot.

IMPORTANT

In many cases, other interface cards and slots within the system are dependent upon the target card. For example:

- If the target card slot is in a power domain and you temporarily stop power to the target card slot, you will also stop power to any other card slots (affected card slots) in that power domain.
- If the target card is a multiple-function card (MFC), suspending or deleting drivers for the target card slot also suspends individual drivers for the multiple hardware paths on that card).

During a card replacement operation, SMH performs a *Critical Resource Analysis*, which checks the target card for critical resources that would be lost when the card is shut down.

Planning and Preparation

For the most part SMH prevents you from performing OLA/R procedures that would adversely affect other areas of the server. This section provides you with important information that can help minimize errors or problems when performing OLA/R procedures.

Card Compatibility

On-Line Addition

When on-line adding an interface card, the first issue that must be resolved is whether the new card is compatible with the system. Each OLA/R-capable PCI slot provides a set amount of power. The replacement card cannot draw more power than is available.

The card must also operate at the slot's bus frequency. A PCI card must run at any frequency lower than its maximum capability, but a card that could only operate at 33 MHz would not work on a bus running at 66 MHz. `rad` provides information about the bus frequency and power available at a slot, as well as other slot-related data.

On-Line Replacement

When on-line replacing an interface card, the replacement card must be identical to the card being replaced. This is referred to as *like-for-like* replacement and should be adhered to because using a similar but not identical card may cause unpredictable results. For example, a newer version of the target card which is identical in terms of hardware may contain an updated firmware version that could potentially conflict with the current driver.

The PCI specification allows a single physical card to contain more than one function. A single-function SCSI bus adapter can not be replaced by a dual-function adapter, even if the additional function on the card was identical to the original SCSI bus adapter.

When the replacement card is added to the system, the appropriate driver for that card must be configured in the kernel before beginning the operation. SMH ensures the correct driver is present. (In most cases, the replacement card will be the same type as a card already in the system, and this requirement will be automatically met.) If you have any

question about the driver's presence, or if you are not certain that the replacement card is identical to the existing card, you can use `ioscan` together with `rad` to investigate.

- During the replacement process, the original driver instance runs in a suspended state. I/O to the card is either queued or failed while the card is suspended. When the replacement card is brought on-line, the driver instance resumes normal operation. The driver instance must be capable of resuming and controlling the replacement card.
- If the necessary driver is not present and the driver is a dynamically loadable kernel module (DLKM), you can load it manually.
- If the driver is static and not configured in the kernel, then the card cannot be On-line Added. The card could be physically inserted on-line, but no driver would claim it.

Critical Resources

Replacing a card that is still operating can have extensive ramifications. Since power to the slot must be off when the old card is removed and the new card is inserted, the effects of shutting down the card's functions must be considered.

This is particularly important if there is no on-line failover or backup card to pick up those functions. For example:

- Which mass storage devices will be temporarily disconnected when the card is shut down?
- Will a critical networking connection be lost?

A critical resource is one that would cause a system crash or prevent the operation from successfully completing if the resource were temporarily suspended or disconnected. For example, if the SCSI adapter to be replaced connects to the unmirrored root disk or swap space, the system will crash when the card is shut down.

During an OLA/R procedure, it is essential to check the targeted card for critical resources, as well as the effects of existing disk mirrors and other situations where a card's functions can be taken over by another card that will not be affected.

Fortunately SMH performs a thorough critical resource analysis automatically, and presents options to you based on its findings. If you determine that critical resources will be affected by the procedure, you

could replace the card when the server is off-line, or if you must take action immediately, you can use `rad` to attempt an on-line addition of a backup card and deletion of the target card.

Failover Actions / Single Points of Failure

In most cases, the system will automatically fail over to the alternate resource when a card is suspended. However, some subsystems might require manual intervention. For example, the Logical Volume Manager (LVM), will automatically redirect I/O for a temporarily disconnected disk resource to a mirror, logging errors as it handles this situation.

- Along those lines, if the resource will be suspended for an extended period of time, a large number of error log entries could result.
- In this type of situation, you may want to manually switch over to a mirror beforehand. When you have completed the OLA/R procedure, the mirror and disk can be resynchronized.

If you suspend a card and the backup takes over, the system can contain a single point of failure. If the backup resource fails before the new card is on-line, the system could potentially crash. This window of vulnerability can be minimized by keeping the period of suspension as short as possible. This requires careful planning, and gathering as much information as possible before actually suspending driver operation and powering-down a card slot.

When an extended suspension period is unavoidable, or when the system is mission-critical, it is desirable to configure a second backup resource if possible.

How to On-line Replace (OLR) a J3525A PCI Card using SMH

WARNING

When performing online replacement, the stack for all the ports of the interface card under consideration will be stopped before replacement. They will be restarted after the replacement. Thus any user application which has open connections will receive DISCONNECT messages. The connections will have to be re-established after successful replacement of the interface card.

- Step 1.** Start SMH.
- Step 2.** From the SMH Areas screen, select PeripheralDevices.
- Step 3.** From the PeripheralDevices screen, select Cards.
- Step 4.** From the I/O Cards screen, view the list of available I/O cards. Select from the possible entries mentioned below:
 - HP J3525A PCI 2-port PSI card
- Step 5.** From the Menu bar, select Actions.
- Step 6.** From the Actions drop-down list, select Replace.
- Step 7.** SMH now performs a Critical Resource Analysis (CRA). That is, now that you have selected to Replace a card, SMH's first step is to confirm that no critical resources will be disabled when the card is taken off-line.

Output messages from the CRA process are presented in the Analyze Critical Resources screen which will be shown before you can proceed. The messages displayed on this screen and the availability to continue on from it (“OK” button activated) depend on the results of the analysis.

Table 4-2 Three Possible Critical Resource Analysis (CRA) Outcomes

Outcome	Notes	Screen Displays	Buttons Activated	User Actions
No critical resources identified.	At this point, you can still cancel the replacement process.	“No affected resources are critical or in-use” and “Critical Resource Analysis complete” messages.	OK and Cancel	Click “Cancel” to halt the operation and cancel the replacement with no change to the system. Or, Remove all cables from the PCI I/O card and click “OK” to take you to the next step.
Critical resource(s) identified.	SMH will not allow the operation to proceed.	Detailed message describing the affected critical resource.	Cancel	Click “Cancel” to halt the operation with no change to the system
Other resources identified.	SMH reports other resources that are in use with no detectable alternates. For these resources, you can cancel or continue the operation based on your knowledge of the current system configuration.	Detailed message describing these resources.	OK and Cancel	Click “Cancel” to halt the operation with no change to the system. Or, Remove all cables from the PCI I/O card and click “OK” to continue operations based on your knowledge of the information being reported.

NOTE

The cables must be removed from the PCI I/O card before proceeding with the OLR operation.

- Step 8.** Once you click the “OK” button on the Analyze Critical Resources screen, SMH begins to take the selected card out of service. SMH requests a suspend operation for the driver of the selected card.
- Step 9.** Once the drivers are suspended, SMH turns off the power to the slot in which the card is located.
- Step 10.** SMH then illuminates the amber attention LED on the slot itself to make the suspended card more easily locatable on the system chassis.
- Step 11.** SMH now requests that the card be replaced via a dialog box. Read the contents of this dialog for any extra information (Expansion cabinets, warnings, etc.). Also at this point, SMH turns off the slot’s green power LED.
- Step 12.** Replace the target card. Please refer to your system manual for removal and insertion of the PCI I/O cards.

NOTE

Do not connect the cables to the card at this point.

- Step 13.** At this point, the amber LED should still be activated, and the green power LED should still be off.

Return to the console, and click the “OK” button on the Replace Card dialog.

WARNING

Pressing the “Cancel” button here will prevent you from easily restoring power to this slot (or Power Domain). If this happens, you must shut-down, then re-boot, the system to restore power.

- Step 14.** Once you click “OK”, SMH first resets the attention LED to it’s normal state.

Step 15. SMH completes the operation by reversing the sequence of actions. That is, SMH will:

- a.** return power to the card slot, and enables power to the Green LED
- b.** identify the new card
- c.** resume driver operations to the card

Step 16. Connect the cables to the card.

How to On-line Add (OLA) a J3525A PCI Card using SMH

NOTE

On-line addition will recognize and claim the interface card only if the X.25/9000 software is already loaded on the system. Also check if the appropriate J3525A drivers are loaded in the kernel.

- Step 1.** Read the information (below) in this step. An understanding of this section is important in order for you to make the correct decision later in the procedure.
1. Enter the SMH I/O Cards area and look for a slot prior to inserting the card.
 - You will see one or more entries marked “empty slot”, one of which you will choose to house the new card.
 - SMH will perform a Critical Resource Analysis prior to bringing the card on-line
- Step 2.** Start SMH.
- Step 3.** From the SMH Areas screen, select Peripheral Devices.
- Step 4.** From the Peripheral Devices screen, select Cards.
- Step 5.** From the I/O Cards screen, view the list of available I/O slots (will read “empty slot”. Select the slot you wish to use.
- Step 6.** From the Menu bar, select Actions.
- Step 7.** From the Actions drop-down list, select Add.
- Step 8.** SMH now performs a Critical Resource Analysis (CRA). That is, now that you have selected to Add a card, SMH’s first step is to confirm that no critical resources will be disabled when the power to the slot is switched off.

Output messages from the CRA process are presented in the Analyze Critical Resources screen which will be shown before you can proceed. The messages displayed on this screen and the availability to continue on from it (“OK” button activated) depend on the results of the analysis.

Table 4-3 Three Possible Critical Resource Analysis (CRA) Outcomes

Outcome	Notes	Screen Displays	Buttons Activated	User Actions
No critical resources identified.	At this point, you can still cancel the replacement process.	“No affected resources are critical or in-use” and “Critical Resource Analysis complete” messages.	OK and Cancel	Click “Cancel” to halt the operation no change to the system. Or, Click “OK” to take you to the next step .
Critical resource(s) identified.	SMH will not allow the operation to proceed.	Detailed message describing the affected critical resource.	Cancel	Click “Cancel” to halt the operation with no change to the system
Other resources identified.	SMH reports other resources that are in use with no detectable alternates. For these resources, you can cancel or continue the operation based on your knowledge of the current system configuration.	Detailed message describing these resources.	OK and Cancel	Click “Cancel” to halt the operation with no change to the system. Click “OK” to continue operations based on your knowledge of the information being reported.

SMH displays a dialog indicating that the selected slot has power disabled and it is now safe to add the card to the desired slot.

- Step 9.** At this point, the amber LED is activated and the green LED is off. Now add the new PCI card. Refer to the system manual for the insertion of the PCI card.

NOTE

Do not connect the cables to the card at this point

Step 10. Once you have inserted the new card, return to the console and click “OK” on the dialog, assuming there is one. At this point, SMH will:

- a.** return power to the card slot and enable power to the Green LED
- b.** attach drivers by running `ioscan` on the new hardware
- c.** update the list of cards and slots on the system shown in the I/O cards area

NOTE

At this point, the OLA is complete. Note that in some cases additional configuration in another area of SMH may also be required. A network interface card, for example, might require network parameter setup in the Network Interface Card portion of the Networking and Communications area.

Step 11. If the OLA is successful, connect the cables to the card.

5 Diagnostic Utilities

Using Diagnostic Utilities

This chapter describes how to use the X.25 diagnostic utilities.


The diagnostic utilities provided with your X.25 link are described briefly in the following table. Refer to Chapter 8, Troubleshooting, if you need help deciding which utility to use.

Table 5-1 **Available Diagnostic Utilities**

Utility	Description	Refer to:
x25check x25server	Tests connectivity up to X.25 level 3 between the local and remote nodes.	man page and this chapter for examples
x25stat	Provides X.25 and IP over X.25 status and configuration VC statistics.	man page and this chapter for examples
x25mibstat	Uses X.25 MIB structure to provide statistical information.	man page
netstat	Provides network statistics and information about network connections.	man page
ping	IP-to-IP connections only. Tests connection to a remote host (to IP level) and reports round-trip communication time.	man page

The following diagram shows the areas of the X.25 product covered by the diagnostic utilities. The X.21bis level is physically integrated in the interface card.

Figure 5-1 Scope of X.25 Diagnostic Utilities



Before Using the Diagnostic Utilities

Some of the diagnostic utilities request or display information about the X.25 interface card using one or more of the naming conventions described below. Keep these conventions in mind when using the diagnostic utilities:

- the name of the *device file*, uses the format `x25_npx`, where *n* represents the card instance number (0 to 15). For systems with multi-port cards only, the *p* is a mandatory place holder and *x* represents the port (interface) number (either 1 or 4).
- the *programmatic access name* (for example, `interfacenpx`)
- the *X.25 interface name* used by `netstat` uses the format `x25_npx`, where *n* represents the card instance number (0 to 15). For systems with multi-port cards only, the *p* is a mandatory place holder and the *x* represents the port (interface) number (either 1 or 4).

The interrupt signal is often used to terminate diagnostic utilities. This chapter assumes you have designated the **Break** key as your interrupt character by setting the `stty` flags, `brkint` and `-ignbrk`. See the man page for `stty` for details.

NOTE

You should be familiar with X.25 data formats in order to understand diagnostic output.

x25check and x25server

These commands are used together to test the connection between a source node and a destination node, up to and including X.25 programmatic access level. x25check is a major tool for debugging the X.25 subsystem and for checking the configuration for that subsystem. x25server is a background process that waits for call requests from x25check. **The x25server must be running before you execute x25check.**

See the man pages for x25check and x25server for syntax and parameter information.

NOTE

The x25server daemon will be killed if all of the X.25 interfaces are deactivated .

Example 1: Running x25check Interactively (No Parameters)

The example below shows x25check used interactively to do three tests.

- The first test (sending a call packet only) is successful and the results are shown. (Generally, when running x25check, first send the CALL packet alone, without data, to verify that a VC has been established between the nodes).
- The second test uses the same destination address to send five data packets. Note that the X.121 address you enter becomes the default value the next time you run the test.
- The third test (to a different X.121 address) is unsuccessful. An error message stating the problem is displayed.

When x25check prompts you for a programmatic access name, press **Return**. The programmatic access name is not used for 712 Series workstations.

```
$ x25check
X25CHECK (c) COPYRIGHT Hewlett-Packard Company 1988.
Test Starts on.. Wed Dec 8 09:13:41 1993
```

Diagnostic Utilities

x25check and x25server

Initialization of the test...

Do you want to send only a CALL packet (no DATA)? (y/n) > **y**
Enter the X.121 Address of the remote node () > **2502057**
Enter the programmatic access name through which you want to check () > **interface2**

Use reverse charging? (y/n) > **y**
Closed user group identification number (Blank or xx or xxxx) >

CALL packet sent ...

The following figures have been measured on the network:
Set up time: 302 ms
Remote Connection Succeeded

Do you want to run the test once again? (y/n) > **y**
Initialization of the test...

Do you want to send only a CALL packet (no DATA)? (y/n) > **n**
Enter the X.121 Address of the remote node (250207)>
Enter the programmatic access name through which you want to check
(interface20) >

CALL packet sent ...
DATA packet sent ... DATA packet received
DATA packet sent ... DATA packet received
DATA packet sent ... DATA packet received
DATA packet sent ... DATA packet received
DATA packet sent ... DATA packet received

The following figures have been measured on the network:
Set up time : 311 ms
Transit time : 120 ms
Remote Connection Succeeded

Do you want to run the test once again? (y/n) > **y**
Initialization of the test...

Do you want to send only a CALL packet (no DATA)? (y/n) > **y**
Enter the X.121 Address of the remote node (250207) > **2502059**
Enter the programmatic access name through which you want to check
(interface20) > **interface3**
Unable to Connect to Remote Node

```
VC_CLEAR Packet was received with
CAUSE   0 :           DTE Originated
DIAG    245 :         Cannot Interpret Diagnostic Code
```

Example 2: Running x25check With an X.121 Address

In the example below, the destination X.121 address of the destination node is specified as a parameter to `x25check`. This example shows a successful test and assumes the `closed_user_group` to be 51.

```
$ x25check 250207 -i interface0 -g 51
```

```
X25CHECK (c) COPYRIGHT Hewlett-Packard Company 1988.
Test Starts on .. Wed Dec 8 09:15:01 1993
```

```
Initialization of the test...
```

```
CALL packet sent ...
```

```
The following figures have been measured on the network:
```

```
Set up time : 267 ms
```

```
Remote Connection Succeeded
```

Example 3: Running x25check With a Data Packet

In this example, a DATA packet is sent following the CALL packet. The size of the DATA packet (in octets) and the number of DATA packets to be sent are specified in addition to the X.121 address of the destination node. This example shows a successful test.

```
$ x25check 250207 -i interface0 -s 32767 -n 1
```

```
X25CHECK (c) COPYRIGHT Hewlett-Packard Company 1988.
Test Starts on .. Wed Dec 8 09:15:47 1993
```

```
Initialization of the test...
```

```
CALL packet sent ...
```

```
DATA packet sent ... DATA packet received
```

```
The following figures have been measured on the network:
```

```
Set up time : 286 ms
```

```
Transit time : 24205 ms
```

```
Remote Connection Succeeded
```

x25stat

This command displays the status, configuration, and VC statistics of an X.25 interface. See the man pages on x25stat for syntax and parameter information.

Example 1: Displaying the Current Configuration

```
x25stat -c -d x25_0
----- X.25 CONFIG -----

General Parameters:
  X.121 Address: 110
  X.121 Pkt Addr: 110
  Programatic Access Name: x25interface_0
Level 1 parameters
  Linespeed: external clock
Level 2 parameters
  t1 [frame timeout]:    3000 ms
  t3 [idle timer]:      12000 ms
  n2 [retransmissions]: 3
  Max. Framesize:       269
  Level 2 Window:       7
Level 3 parameters
  network type: DTE_8
VC parameters ( Low High ) values :
  PVCs      :    0    0
  SVCs In   :    0    0
  SVCs 2ways:    1  64   SVCs Out :    0    0
  Total Number of VCs configured: 64
  Default inbound packet size:    128
  Default outbound packet size:   128
  Default inbound window size:    2
  Default outbound window size:   2
  Default inbound throughput class: 12
  Default outbound throughput class: 12
Facilities settings:
  Fast Select is : DISABLED
  Flowcontrol Neg is : OFF
  Reverse Charging is : DISABLED
```

Example 2: Displaying Global Statistics

See the tables provided after this example under the headings “SUBNETWORK STATISTICS FOR X25” and “STATISTICS FOR LAPB” for help in interpreting the displayed “State” of the X.25 link.

```
x25stat -d x25_0 or
x25stat -g -d x25_0
SUBNETWORK STATISTICS FOR X25
-----
Subnetwork ID   : 0
State           : Connected and resolved DXE
-----
Packet type      TX      RX
-----
Restart Request      0        1
Restart Confirm      1        0
  Calls (out/in)      1        0
  Calls Accepts       0        1
  Reset Request       0        0
  Reset Confirm       0        0
Packets (total)     30       29
Bytes (total)      3840     3712
-----
STATISTICS FOR LAPB
Subnetwork      : 0
Link mode       : LC_LAPBDTE
Link state      : NORMAL
-----
  FRAMES      TX_CMD      TX_RSP      RX_CMD      RX_RSP
-----
Supervisory:
  RR           22          27           0          23
RNR            0           0           0           0
REJ            0           0           0           0
Unnumbered:
  SABM         0           1
  DISC         0           0
DM             0           0
UA             1           0
FRMR          0           0
Information:
  I            33          62
-----
                        TX                        RX
-----
```

x25stat

```

Other:
Bad length                0
Unknown                   0
Erroneous                  0
Discarded                  0
Ignored                    0
Retransmitted              0
-----
Timers:
T1                          0
T4                          0
T4 (N2 times)              0
STATISTICS FOR WAN
-----
Subnetwork Link State : HDLC_ESTB
WAN:
    83 good frames transmitted
    87 good frames received
    0 transmit underruns
    0 receive overruns
    0 CRC/frame errors received
    0 received frames with no buffer
      0 received frames with no flow control
      0 receive buffer overflows

```

The level 3 “State” under the heading “SUBNETWORK STATISTICS FOR x25” can be:

Table 5-2**Level 3 State**

Output on Screen	Description/Meaning
Link not up	X.25 link level 3 is down
Connecting to DXE ^a	Restart packet sent (r2 ^b)
Connected resolving DXE	Restart packet sent (r2)
Random wait started	Waiting before retransmitting a restart after a “collision” (packet sent at the same time as packet received)
Connected and resolved DXE	X.25 link level 3 normal (r1)
DTE RESTART REQUEST	Waiting on restart confirmation

Table 5-2 Level 3 State (Continued)

Waiting link disc reply	Level 2 going down
Buffer to enter WtgRES	Restart sent after retry
Buffer to enter L3restarting	Waiting for restart reply during “link going down” phase
Buffer to enter L_disconnect	Waiting for buffer to clear VCs during “link going down” phase
Unknown	Unable to define error/problem

- a. DXE is DCE or DTE
- b. r2, like r1, is a CCITT definition of a state/condition

The level 2 “Link state” under the heading “STATISTICS FOR LAPB” can be:

Table 5-3 Level 2 Link State

Output on Screen	Description/Meaning
NORMAL	Level 2 up
ADM	DTE - Level 1 disconnected
POLLING	DCE - Level 1 disconnected
START	Level 1 connected
RESET	Level 2 down
OFF	Level 2 down

NOTE T4 under “STASTISTICS FOR LAPB” is only an internal parameter; it is not configurable.

The level 1 “Link state” under the “STATISTICS FOR WAN” heading can be:

Table 5-4 Level 1 Link State

Output on Screen	Description/Meaning
HDLC_ESTB	WAN connection established
HDLC_IDLE	No WAN connection established
HDLC_DISABLED	WAN connection disabled

The output under the heading “STATISTICS FOR WAN” is explained in the table below:

Table 5-5 Statistics for WAN Output

Output on Screen	Description/Meaning
transmit underruns	Shows the number of times a transmission was aborted because the next octets to be transmitted were not provided soon enough for the level 2 firmware
receive overruns	Shows often-received octets were overwritten because they were not processed by the card
received frames with no buffer	No message available in level 1 to copy received data to
received frames with no flow control	Never used
receive buffer overflows	Number of frames that were “too long”
receive aborts	Number of frames that have been aborted

Example 3: Displaying Virtual Circuit Data Packet Counters

The following example shows the output when there is one virtual circuit connected.

Note that the virtual circuit specified in the command line is 64, in decimal. The LCN shown in the example output is displayed as 40, the hexadecimal equivalent of 64.

```
x25stat -t 64 -d x25_0
```

```
PER-VC STATISTICS FOR X25
-----
Subnetwork      : 0
LCN             : 040 (hexadecimal)
User ID        : 213
Call direction  : outward To DTE           : 202
To DTE         : 202
VC state        : 6 - Datatransfer
-----
Packet type      TX      RX
-----
      Call        1        0
    Call confirm  0        1
      Data       422       421
    Interrupt     0        0
      RNR         0        0
      RR          0       421
      Reset       0        0
Reset confirm     0        0
      Clear       0        0
Clear confirm     0        0
-----
Total            423       843
-----
```

The “VC state” under the heading “PER-VC STATISTICS FOR X25” can be:

Table 5-6

VC State

Output on Screen	Description/Meaning
3 - P2	CALL REQUEST sent, but not yet replied

Table 5-6 VC State (Continued)

4 - P3	INCOMING CALL received, but not yet replied
6 - Datatransfer	Connection established
7 - DXE ^a busy	RNR sent
8 - D2	RESET REQUEST sent, but not yet replied
19 - DXE resetting	RESET INDICATION received, but not yet replied
20 - P6	CLEAR REQUEST sent, but not yet replied

a. DXE is DCE or DTE.

Example 4: Displaying Global X.25 Level 3 Statistics

```
x25stat -x -d x25_0
```

```
SUBNETWORK STATISTICS FOR X25
```

```
-----
Subnetwork ID   : 0
State           : Connected and resolved DXE
-----
```

Packet type	TX	RX
Restart Request	0	1
Restart Confirm	1	0
Calls (out/in)	3	0
Calls Accepts	0	3
Reset Request	0	0
Reset Confirm	0	0
Packets (total)	1273	1271
Bytes (total)	162944	162688

Example 5: Displaying X.25 Level 1 and 2 Statistics

```
x25stat -f -d x25_0
```

```
STATISTICS FOR LAPB
```

```
-----
```

Subnetwork : 0
Link mode : LC_LAPBDTE
Link state : NORMAL

FRAMES	TX_CMD	TX_RSP	RX_CMD	RX_RSP
Supervisory:				
RR	45	1045	0	46
RNR	0	0	0	0
REJ	0	0	0	0
Unnumbered:				
SABM	0		1	
DISC	0		0	
DM		0		0
UA		1		0
FRMR		0		0
Information:				
I	1280		2551	

	TX	RX
Other:		
Bad length		0
Unknown		0
Erroneous		0
Discarded		0
Ignored	0	0
Retransmitted	0	

Timers:
T1 0
T4 0
T4 (N2 times) 0

STATISTICS FOR WAN

Subnetwork : 0
Link State : HDLC_ESTB
WAN:

2371 good frames transmitted
2599 good frames received
0 transmit underruns
0 receive overruns
0 CRC/frame errors received
0 received frames with no buffer
0 received frames with no flow control

```
0  receive buffer overflows
0  receive aborts
```

NOTE T4 under “STATISTICS FOR LAPB” in the example above is only an internal parameter; it is not configurable.

The output under the heading “STATISTICS FOR WAN” is explained as follows:

Table 5-7 Statistics for WAN Output

Output on Screen	Description/Meaning
transmit underruns	Shows the number of times a transmission was aborted because the next octets to be transmitted were not provided soon enough for the level 2 firmware
receive overruns	Shows often-received octets were overwritten because they were not processed by the card
received frames with no buffer	No message available in level 1 to copy received data to
received frames with no flow control	Never used
receive buffer overflows	Count of “too long” frames received
receive aborts	Count of frames that have been aborted

Example 6: Displaying Virtual Circuit Status

```
x25stat -v -d x25_0

PER-VC STATISTICS FOR X25
-----
```

LCI	Type	VC State	Subnetwork	Local address	Remote Address
---	----	-----	-----	-----	-----
040	SVC-2way	Datatransfer	0	110	202

Note that the LCI number given in this example output is displayed in hexadecimal, not decimal.

Example 7: Displaying Current IP to X.25 Address Mapping

x25stat -a

IP Address	PktszWindow	VCs	CUG	SUB-REV	BAR-REV	X25 Address
192.25.0.12	1	1	-	y	n	0.250107..
192.25.0.22	1	1	GOO11	y	n	0.250112..
192.25.0.32	1	1	-	y	n	0.250208..

Some of the fields in the example above are:

- CUG – An example Call User Group would be *GOO11*, which means group 11.
- SUB-REV – Subscribe to Reverse charges (y=yes, n=no).
- BAR-REV – Stop Reverse charges (y=stop, n=don't stop).

x25mibstat

This is a programmatic application that can be used to display statistics for X.25 sub-systems. Refer to the `x25mibstat(1)` man pages for instructions on using this utility.

Some examples of `x25mibstat` statistics are provided in the following table.

Table 5-8 **Example Statistics for x25mibstat**

Statistic	x25mibstat Option	Remark
VC open duration	<code>-s x25CircuitEntry</code> <code>-s mioxPeerEntry</code>	Time duration in seconds Time duration of IP connection
Number of open SVCs per X.25 connection	<code>-s x25StatEntry</code>	According to VC type (that is, inbound, outbound, or 2-way)
Clear information	<code>-s x25statEntry</code> <code>-s mioxPleEntry</code>	About clear initiator About refused calls
Clear information	<code>-s lapbFlowEntry</code>	Number of LAPD-B state changes

6 PAD Services

Introduction

This section describes X.25/9000 PAD (Packet Assembler/Disassembler) Services which enable HP 9000 computers to connect and communicate with remote systems over a Packet Switching Network (PSN).

NOTE

Refer to “Configuring PAD Services” in Chapter 3 for information on configuring PAD Services with SMH.

PAD Services include the following commands and functions:

- **x29server** – for PAD support for remote terminals:
A daemon process that allows a local HP 9000 system to function as a host for (real or emulated) terminals attached to a remote PAD.
- **x29printd** – for remote PAD printer support:
A daemon process that allows local HP 9000 computers to print at printers attached to a remote PAD.
- **x29uucpd** – for PAD-UUCP connectivity:
A daemon process that allows HP 9000 computers to originate UNIX-to-UNIX copy services over an X.25 Switched Virtual Circuit (SVC).
- **padem** – for local PAD emulation:
A user command that allows a local HP 9000 system to emulate both a terminal and a PAD for connection with remote systems over a PSN.

CCITT Recommendations


X.25/9000 PAD Services are compliant with the X.25, X.28, X.29, and X.3 CCITT Recommendations of 1984.

Recommendation X.28 defines the exchange of messages between PAD terminals and the PAD. A superset of the commands defined by this protocol are performed by padem.

Recommendation X.29 is the protocol for the exchange of messages between the host and PADs.

Recommendation X.3 defines a set of parameters that control PAD operation. The following illustration shows the relationship between each of these recommendations.


Figure 6-1 **PAD Support Protocols**



PAD services and the HP 9000 host

All of the PAD services can be seen as a pipe through which data is passed from X.25 to the PTY (Pseudo Type) terminal and vice versa (see the illustration below). Terminal data is not modified, but the X.25 headers are stripped before data reaches the PTY.

Figure 6-2 **PAD Services as a Pipe**




Remote PAD Support (x29server)

Overview

The `x29server` user-level process provides support for communications with terminals attached to a remote PAD. This process accesses X.25 level 3 through Berkeley Sockets (programmatic interface) and has an interface to PTYs (see illustration below).

Figure 6-3 Remote PAD Support



The `x29server` remote PAD support provides capabilities for:

- Managing call acceptance.
- Launching applications automatically.
- Ensuring system security.
- Monitoring access and data transfers.

When `x29server` begins execution, it examines the PAD support section (`pad_spt`) of the `/etc/x25/x29hosts` file. The PAD support section contains user-configurable parameters for all devices. See Appendix B, X.25 Configuration Files and Examples, for an example of the `x29hosts` file.

Call Acceptance Mechanism and System Security


The `x29server` process operates in conjunction with devices declared in the set of `pad_spt` (PAD support) entries contained in the `x29hosts` file. It continually “listens” to the network and initializes communications channels at the user level when a call request is received. `x29server` can handle a large number of calls because each communication channel is managed by an independent process.

The `x29server` process employs Berkeley Sockets (at X.25 level 3) to set up dedicated listening sockets that only handle calls arriving at a particular subsystem. Addressing information contained in incoming call request packets enables the listening process to determine if the call should be accepted.

When a call request packet arrives `x29server` looks in the `pad_spt` entries to verify the following:

- **Legal PID in the incoming call request packet** – The PID must conform to the X.29 standard to ensure support on all X.25 networks. `x29server` only verifies that the PID begins with 01 and that it is 4 bytes in length as illustrated below.

Figure 6-4



- **Correct interface_name** – If there is an entry in the `interface_name` field in the `pad_spt` section (optional), it must contain the name of the interface over which the call has arrived.
- **Correct address** – If there is an entry in the `local_x121` field in the `pad_spt` section (optional), this entry must match the called address specified in the call request packet. Furthermore, the `local_x121` field entry must contain the complete address (that is, *both* the address and subaddress of the local interface).

If all of the above conditions are met, the call is connected and `x29server` does the following:

- parses the `x29hosts` file to find the *first* previously accepted `pad_spt` entry whose `remote_x121` field matches the calling address contained in the call request packet,
- and, if there is a `pty_slave_fname` field in the selected `pad_spt` entry, `x29server` verifies that the corresponding PTY master/slave pair exists and is available.

If the last two items are completed successfully, the call is accepted; otherwise, `x29server` rejects the call.

NOTE

See the man pages for `x29server` for its syntax and parameters.

Supported Remote PAD Terminals

- 700/41, 700/92, 700/94, 700/22
- 2392A
- 2393A
- Vectra with AdvanceLink Terminal Emulation

Configuring Remote PAD Support

You can configure remote PAD support with SMH or by editing configurable parameters in the `/etc/x25/x29hosts` and `/etc/x25/x3config` files. The `x29hosts` file contains general parameters for each remote device and the `x3config` file contains X.3 communications profile parameters for each device declared in the `x29hosts` file. See Appendix B, X.25 Configuration Files and Examples, for examples of the `x29hosts` and `x3config` files.

Configuring `pad_spt` Parameters

Remote PAD support parameters are specified in the `pad_spt` section of the `x29hosts` file. An example `pad_spt` section with parameter values is shown below.

```
pad_spt {  
  
    interface_name    interface0  
    remote_x121       408555120801  
    local_x121        1235451  
    pty_slave_fname   ptynb01  
    application       /bin/login2  
    cud               yes  
    logging           1  
    reverse_charge    disable  
    size_parity       8_none  
    x3                hp_padsrvr  
}
```

pad_spt Parameters

This section describes the remote PAD support parameters shown in the above example:

interface_name **Optional.** This is a character string (maximum 12 characters) with no wildcards allowed. If this field is not present, x29server will listen on all X.25 interfaces.

remote_x121 **Mandatory** (no default value). This is the calling address (the address of the remote system).

There are three ways of expressing addresses:

- exact address: the complete, exact address
- wildcard address: partially or completely composed of legal wildcards
- special address: for PADs with no local address

Legal characters include the digits 0 through 9, the capital letter “F”, the question mark (?), and the asterisk (*). The (?) is a legal wildcard (substitute) for values 0 through 9. The (*) is a legal wildcard for any character. You can mix wildcards and characters.

The special address is FFFFFFFFFF which maps to a null calling address. This feature is supported for PADs that have no local addresses.

local_x121 **Optional.** Specified with a maximum of 16 digits (no wildcards allowed). This must be the complete address (including *both* the subscription address of the interface and a subaddress).

The complete address protects the interface from being activated by calls arriving at other addresses.

pty_slave_fname **Optional.** Specifies the file containing the name of the slave PTY driver that will provide terminal services for user applications. The name of this file (maximum 14 characters) must begin with “pty” (format: *pty [filename]*) and the file must be located in the /dev/pty/ directory.

The name of the corresponding master PTY driver must also exist in a file beginning with “ptym” (format: *ptym [filename]*) located in the */dev/ptym/* directory:

Wildcards are not allowed in these file and path names.

If the *pty_slave_fname* field contains an entry, *x29server* considers any communication initiated by this entry to be restricted to exclusive use by the TTY/PTY (master/slave) pair. The call is refused if the TTY/PTY pair does not exist, is already in use, or cannot be accessed (permission should be set to 666).

logging

Optional. Specifies the logging level for each call. Log information is stored in the file */var/x25/log/x29server/x29logXXXXX*, where *XXXXX* is the process ID of the current *x29server* child process. Logging can be at levels 0, 1, 2, or 3. Level 0 is no logging and the default is level 1 (error logging). Level 2 is error and warning logging. Level 3 is error, warning, information, and status logging.

reverse_charge

Optional. Specifies reverse charge options for the calling address. Possible settings are: *disabled* (or *disable*), *enabled* (or *enable*). With the default value (*disable*), reverse charge calls will not be accepted. When reverse charging is enabled and is requested by the remote PAD or system, the call is accepted and is charged to the local system. You must also configure the X.25 interface card to allow reverse charging (refer to “Configuring Remote System Access” in Chapter 3 for instructions on how to use SMH to enable reverse charging) in order for reverse charging to work with PAD services.

size_parity

Optional. Legal values are *8_none* (the default), *7_even*, and *7_odd*. Specifies the character size and parity setting of the remote PAD and terminal. This parameter is useful when the asynchronous port of the PAD cannot be configured in 8 bits. In this case, this parameter must be set to match the remote PAD and terminal settings. *x29server* will set the PTY pair correctly so that 7-bit PAD users can log in without

problems. Note that size and parity processing will only be performed on input from the PAD to the system.

<i>x3</i>	Optional. This is the X.3 configuration set name for this x29server session. If this entry is included in the <i>/etc/x25/x29hosts</i> file, the configuration name and its set of X.3 parameters must also be specified in the <i>/etc/x25/x3config</i> file. If more than one X.3 configuration set with the same name exists in <i>x3config</i> , the first one is used. X.3 parameters are not downloaded unless <i>both</i> the X.3 configuration set name <i>and</i> the parameters are given.
<i>application</i>	Optional. Used with <i>cud</i> to specify the full path name of the application to be launched when the connection is established (maximum 80 characters, no wildcards). See “Launching applications automatically” below for more information.
<i>cud</i>	Optional. Specifies a yes or no condition. Legal values for this field are: <i>enable</i> (or <i>yes</i>), <i>disable</i> (or <i>no</i>). See “Launching applications automatically” below for more information on this.

Launching Applications Automatically

A user-level application can be launched automatically by configuring the *application* and *cud* fields in the *pad_spt* section of the *x29hosts* file.

The *application* parameter specifies the name of the user application (or script) to be automatically launched when the connection is established. The *cud* parameter is used like an on/off switch to enable or disable the use of Call User Data (CUD) instructions.

If you are using a UNIX script, it must contain the character string *#!/bin/ksh* at the beginning of the first line. If this string is not included, the system will return an error code.

If the *application* and *cud* fields do not appear in the *pad_spt* file, the */bin/login* (default) program is automatically launched.

CAUTION

Use extreme caution when specifying applications other than the default (*login*) application. Since the *x29server* process is started with *superuser* privileges, it gives root privileges to applications triggered by incoming calls.

You can automatically launch a user application by:


- configuring the *application* field with the relevant application name as its value without specifying the *cud* field. The application name must be the full path name of the application to be launched.
- configuring the *application* field with the application name and setting the *cud* field to *yes*. In this case, the *cud* field is considered as the argument to the application. The application name must be the full path name of the application to be launched.
- not including the *application* field and setting the *cud* field to *yes*. This allows the application to be defined by the incoming Call Request Packet.

The first four bytes of the CUD field (in call request packets) are *NOT* part of the application's full path name. The first four bytes are used for protocol ID as explained in the section "Call acceptance mechanism and system security."

Remote PAD Printer Support (x29printd)

Overview

The *x29printd* user-level program provides support for printers attached to remote PADs. It accesses X.25 level 3 through Berkeley Sockets (programmatic interface). It also has an interface to special PTYs (see illustration below).

Figure 6-5 Remote Printer Support

When `x29printd` begins execution, it examines the `/etc/x25/x29hosts` file for all PAD devices configured with a PAD type printer. For each of these configured devices, `x29printd` monitors all print requests sent to the spooling system (see Appendix B, X.25 Configuration Files and Examples, for an example of the `x29hosts` file).

When `x29printd` detects a print request, it establishes an SVC with the remote PAD printer specified in the remote X.121 address. `x29printd` then transmits the print data to the remote PAD printer, closes the SVC, and waits for another print request.

System Requirements

Because each printing device requires system resources, HP recommends that the kernel parameters be set to following values (or greater):

- `MAX_PAD_PR` – is the number of PAD printers to be configured.
- `NPTY` – is $60 + \text{MAX_PAD_PR}$
- `MAXURPC` – is $50 + (3 \times \text{MAX_PAD_PR})$
- `NPROC` – is $20 + ((8 \times \text{MAXUSERS}) + \text{NGCSP} + (6 \times \text{MAX_PAD_PR}))$

The following kernel parameters should not be modified and should retain the values indicated below:

- $NFILE = (16 \times (NPROC + 16 + MAXUSERS) / (10 + 32 + (2 \times NPTY)))$
- $NINODE = ((NPROC + 16 + MAXUSERS) + 32 + (2 \times NPTY) + (SERVER_NODE \times 18 \times NUM_CODES))$

For more information on dependencies, refer to your *System Administration Tasks* manual.

NOTE

See the man pages for x29printd for its syntax and parameters.

Configuring Remote PAD Printers

You must configure each remote PAD printer by specifying parameters in the printer section of the `/etc/x25/x29hosts` file (see Appendix B, X.25 Configuration Files and Examples, for an example `x29hosts` file). An example printer section is shown below.

```
printer {
    device      printer1
    name        interface0
    remote_xl2l  408555111201
    cud         dbad
    cug         02
    logging     1
    reverse_charge enable
    x3          hp_printer
}
```

device

Mandatory. This is the name of the device file that will be located in `/dev/x29/`. It is created by `x29printd` and will be symbolically linked to a slave PTY in `/dev/pty/`. The device file must also be configured in the spooler system using `lpadmin` and the `-v` option (see “Configuring the UNIX Line-printer Spooler for x29printd” below).

<i>name</i>	Mandatory. This is the name of the programmatic interface that will be used for call setup. There is no default for this entry. This name must match the programmatic access name (also called <i>name</i>) specified in the <code>x25init</code> X.25 configuration file.
<i>remote_x121</i>	Mandatory (no default). This is the X.121 address of the PAD device plus the subaddress of the printer. This address is required for calls to be initiated. Only digits 0 through 9 are legal.
<i>cud</i>	Optional. This is the Call User Data (CUD) appended to the protocol ID (0x01000000) for any call request packets sent to this printer. Only strings of 12 characters or less are permitted.
<i>cug</i>	Optional. This is the Call User Group (CUG) that will be allowed access to the printer. Only integers are permitted.
<i>logging</i>	<p>Optional (default = 1). This is the logging level used for each printer device. Printer device logging can be set to 0, 1, 2, or 3 where the respective values are:</p> <ul style="list-style-type: none"> 0 – No logging (do not create a log file). 1 – Minimum session error logging. 2 – Error and warning logging. 3 – Error, warning, information, and status logging. <p>HP recommends logging level 0 or 1 for normal operation. Logging levels 2 and 3 should only be used for troubleshooting for short periods of time.</p> <p>Logging messages for <code>x29printd</code> provide descriptions of what the messages mean and the actions required to correct any errors that may occur. The log file is written to</p> <p><code>/var/x25/log/x29printd/[device_name][child_process_id].</code></p>
<i>reverse_charge</i>	Optional (default = <i>disabled</i>). Specifies the reverse charge option for the call setup for the particular printer address. It can be <i>disabled</i> (or <i>disable</i>), <i>enabled</i> (or <i>enable</i>).

x3 **Optional.** This is the X.3 configuration set name for this x29server login session. If used, the configuration set name (and X.3 parameter set) must also exist in /etc/x25/x3config. If more than one X.3 configuration set with the same name exists, the first one found in the file is used.

If there is no configuration set name in /etc/x25/x29hosts or no matching X.3 configuration set name in /etc/x25/x3config, default values are used.

Configuring the UNIX Line-printer Spooler for x29printd

The remote PAD printer must also be configured in the spooler system in order for remote printing to work with the standard UNIX LP commands. To configure a remote PAD printer in the spooler system, execute the following command:

```
lpadmin -v <device name> -p <printer name> -m <printer model>
```

-p Printer name is the name given to this printer at the user level. This is the same name specified with the lp command's -d option (used when you print a file to a printer).

-v Device file name is /dev/x29/[*device name*]. The value for device name is the same character string as the one entered in the device entry in the /etc/x25/x29hosts file.

-m Printer model is the HP printer model name (for example, *thinkjet*, *laserjet*, *hp2563a*, etc.).

The lpadmin command associates the printer name with the device file name in /etc/x25/x29hosts and maps this name to the remote X.121 address of the printer.

Examples

x29printd and lpsched Operation

For this example, a printer (a RuggedWriter) is connected on port 5 (or B1 on HP 2335a PADs) to a PAD whose address is 4085551203. The address of the printer in this case would be 408555120305. In the PAD device local configuration, port 5 must be downloaded with:

```
parm_no: parm_value;1:0; 2:0; 3:0; 4:10; 5:0; 6:0; 7:0;  
8:0; 9:0; 10:0; 11:14; 12:1; 13:0; 14:0; 15:0; 16:8;  
17:24; 18:0; 19:1; 20:0; 21:0; 22:0
```

which is profile 21 on HP 2335a.

On the host side, the printer name is *foo*. This means that when a user types **lp -d foo /tmp/file**, the file */tmp/file* will be printed on this printer. The X.25 interface on the host is **interface0**.

Printer Configuration

To configure a printer (foo in the examples below) for use with the standard UNIX LP spooler system and x29printd, follow these steps:

Step 1. Edit the */etc/x25/x29hosts* file to include:

```
printer {  
    device          x29printer1  
    name            interface0  
    remote_x121     408555120305  
    x3              default_printer  
    logging         3  
}
```

x29printd uses */etc/x25/x29hosts* to configure remote PAD printers.

Step 2. Execute */usr/sbin/x29printd* with the *-l3* option.

After */usr/sbin/x29printd* starts, it creates a device file named */dev/x29/x29printer1*. You can verify that this device file exists with the command: **ll /dev/x29**.

x29printd creates the device file by linking it to a slave PTY. This master/slave PTY pair is the interface for lpsched and x29printd (see the *pty(7)* man pages for information about UNIX PTYs). The device file for printer *foo* will be written to */dev/x29/x29printer1*.

Step 3. Configure the printer in the spooler system with the following commands:

```
lpshut
lpadmin -v/dev/x29/x29printer1 -pfoo -mruggedwriter
lpsched
accept foo
enable foo
```

`lpshut(1M)` is necessary since `lpadmin` will not execute when `lpsched` is running. You must restart LP scheduler after `lpadmin`. `lpsched(1M)` schedules requests taken by `lp(1)` for line printing. After a printer is configured in the spooler, you must enable it to accept printing requests.

Verifying the Configuration

After you complete the steps above, check the configuration as shown below:

- `lpstat -t` should display the following (assuming that only this printer is configured in the spooler system and you did these steps on January 23, 11:00 am):

```
scheduler is running
no system default destination
device for foo: /dev/x29/x29printer1
foo accepting requests since Jan 23 11:00
printer foo is idle.  enabled since Jan 23 11:00
fence priority : 0
```

- `ps -ef` should show that both `lpsched` and `x29printd` are running.
- `/var/x25/log/x29printd/x29printd.log` should have been created and should contain information on the configuration of `/dev/x29/x29printer1`.
- `/var/x25/log/x29printd/x29printd.log` should not contain any configuration error messages.

UUCP Support (x29uucpd)

Overview


x29uucpd provides UUCP connectivity on X.25 networks using CCITT Recommendations X.3 and X.29. With x29uucpd, users on HP 9000 host systems with X.25 access and UUCP can execute UUCP subsystem commands to other systems running X.25, PAD support, and UUCP. x29uucpd interfaces with the X.25 subsystem through BSD Sockets to initiate call request packets to remote systems on X.25. When a call request arrives at a destination system, it is received by the PAD support service.

NOTE

x29uucpd creates device files in the `/dev/x29/` directory. The device files must be configured in the UUCP subsystem in order for UUCP to interface with x29uucpd.

The x29uucpd user-level program provides support for UUCP file transfers. It accesses X.25 level 3 through Berkeley Sockets (programmatic interface) and uses PTY pairs for the terminal interface to UUCP (see the following illustration).

Figure 6-6 Remote Printer Support



When x29uucpd is executed, it examines the `/etc/x25/x29hosts` file for all PAD devices that are configured for UUCP.

When x29uucpd receives a copy request, it establishes an SVC with the remote host specified by the X.121 address and transfers the data.

If the remote host is an HP 9000, the x29server process monitors that system for incoming calls. x29server and x29uucpd cooperate to handle all SVC requirements while the UUCP processes on each system perform the UUCP operations.

When the UUCP data transfer is complete, the UUCP processes terminate. x29server and x29uucpd then terminate the SVC connection.

Configuring UUCP PAD Support

To configure PAD support for UUCP services, the `x29hosts` file and other system and device files must contain the appropriate references and parameters. This section provides information on configuring these files. See Appendix B, X.25 Configuration Files and Examples, for examples of the `x29hosts` and `x3config` files.

NOTE See the man pages for `x29uucpd` for full details on syntax and parameters.

Table 6-1

File	Contents
<code>/etc/x25/x29hosts</code> <code>pad_uucp</code>	parameters for each remote host
<code>/etc/passwd</code>	uucp entry
<code>/etc/x25/x3config</code>	optional X.3 parameters
<code>/usr/lib/uucp/Systems</code>	remote system's name
<code>/usr/lib/uucp/Permissions</code>	remote system's login name
<code>/usr/lib/uucp/Devices</code>	device file name

Configuring the `x29hosts` file

The `/etc/x25/x29hosts` file must contain a separate `pad_uucp` section for each remote site. An example `pad_uucp` section is shown below.

```
pad_uucp {
    device      x25uucp
    name        interface0
    remote_x121 4085551113
    cud         abc
    cug         2
    logging     3
    reverse_charge enable
    x3          hp_uucp
}
```

`pad_uucp` Parameters

device **Mandatory.** This is the device file name located in the `/dev/x29` directory. It is created when `x29uucpd` is executed and is used for communication between UUCP and `x29uucpd`. This device file must also exist in `/usr/lib/uucp/Devices` file for the UUCP system.

<i>name</i>	Mandatory. This is the name of the programmatic interface that will be used for call setup. There is no default for this entry. If this entry does not exist, the call setup will not be completed and file transfer will not take place. This name must match with the programmatic access name (also called name) specified in <code>x25init</code> .
<i>remote_x121</i>	Mandatory. This is the X.121 address of the X.25 interface card of a host system where the PAD support program (for example, <code>/usr/sbin/x29server</code>) is running. This address is required for calls to be initiated. There is no default for this address.
<i>cud</i>	Optional. This is the Call User Data (CUD) appended to the protocol ID (0x01000000) for any call request packets sent to this device. Strings of 12 characters or less are permitted.
<i>cug</i>	Optional. This is a the Call User Group (CUG) number (a positive value between 0 and 99) embedded in the call request packet sent to this device.
<i>logging</i>	Optional (default = 1). Specifies the logging level for each UUCP connection to this device. The log file is <code>/var/x25/log/x29uucpd/[device_name][child_pid]</code> . Logging levels for this UUCP device are 0, 1, 2, or 3 where: 0 – No logging (no log file is created). 1 – Error logging. 2 – Error and warning logging. 3 – Error, warning, information, and status logging for troubleshooting. HP recommends using log level 0 (no logging) for normal operation.
<i>reverse_charge</i>	Optional (default is <i>disable</i>). Specifies the reverse charge option for call setup at this address. Possible settings are <i>disabled</i> (or <i>disable</i>) and <i>enabled</i> (or <i>enable</i>). When reverse charge is enabled, <code>x29uucpd</code> sends out call request packets with reverse charge requested.

x3 **Optional.** This is the X.3 configuration set name for UUCP file transfers. If this entry is used in `/etc/x25/x29hosts`, the configuration set name with its set of X.3 parameters must be specified in `/etc/x25/x3config`. All legal X.3 parameters contained in the `x3config` file are downloaded at connection time. If there is more than one X.3 configuration set with the same set name in `/etc/x25/x3config`, the first one is used.

If there is no configuration set name in `x29hosts` or matching X.3 configuration set name in `x3config`, the default parameters are downloaded (see “X.3 Parameter Descriptions” for information on X.3 parameters). `x29uucpd` operates in line mode only.

Configuring System and Device Files for UUCP

The following example describes the configuration procedure for `cu`, `uucp` and `uucico` transfers between two systems. In this example, the local system is called “*dave*” and the remote system is called “*bill*.” The two systems are configured to handle file transfers originating from the local system (*dave*) and received by the remote system (*bill*).

NOTE

Refer to the man pages for information on `x25uucp` device entry parameters.

At the “dave” system:

Step 1. Make sure that the directory `/var/spool/uucp/LCK..x29` exists. If it doesn’t exist, create it.

Step 2. Configure the `usr/lib/uucp/Systems` file as follows:

```
bill Any;5 dev_bill, f 19200 - "" \r\d\r\d\r login: -BREAK
-logon: uucp word: test
```

where:

`bill` – is the name of the destination system (7 characters maximum).

Any – indicates that *bill* can be called at any time.

5 – is the retry duration (*dave* will try again to connect to *bill* in 5 minutes).

dev_bill – is the name of the remote system declared in *dave*'s Devices file.

f – is the file transfer protocol. HP recommends using *f* rather than *g* for better performance.

19200 – is the transfer rate (it must be set at the same speed as that specified in the *dave*'s Devices file).

"" \r\d\r\d\r login: -BREAK -login: uucp word: test – is login information declaring **uucp** as the user for uucp and uucico processes, with the password "**test**". The password creates a link to the entry in the */etc/passwd* file of *bill*.

Step 3. Make sure that the following entry appears in the */usr/lib/uucp/Devices* file:

```
dev_bill x29/bill - 19200 direct
```

x29/bill has a maximum of 14 characters. The **x29/bill** entry creates a link with the **pad_uucp** entry in the *x29hosts* file.

Step 4. Add the following lines to the */usr/lib/uucp/Permissions* file:

```
MACHINE=bill \  
  
SENDFILES=yes REQUEST=yes CALLBACK=no \  
  
READ=/  
  
WRITE=/  
  
COMMANDS=ALL
```

NOTE

You can verify current permissions with the `uucheck -v` command.

Step 5. Create the following entry in the */etc/x25/x29hosts* file:

```
pad_uucp {
    device      bill
    name        interface0
    remote_x121 [bill's X.121_address]
    logging     3
    x3          default_x3
}
```

Refer to “Configuring the x29hosts file” earlier in this section for the definitions of these parameters.

Step 6. Launch `/usr/sbin/x29uucpd` at the HP-UX command prompt.

At the “bill” system:

Step 7. Make the following modifications to the `pad_spt` section of `/etc/x25/x29hosts` file:

```
pad_spt {
    remote_x121 [dave's X.121_address or
                "*" for all addresses]
    logging     3
    x3          hp_padsrvr
}
```

Refer to “Configuring the x29hosts file” earlier in this section for the definitions of these parameters.

Step 8. Launch the `x29server` process with `/usr/sbin/x29server -l3` for example.

Step 9. Verify the contents of `/etc/passwd` (this file is linked with *dave's* Systems file) which should look like this:

```
uucp::5:3::/var/spool/uucppublic:/usr/lib/uucp/uucico
```

At the terminal prompt, assign the password “test” to the `uucp` user:

```
bill# passwd uucp
```

Step 10. Add the following lines to the `/usr/lib/uucp/Permissions` file:

```
LOGNAME=uucp \

SENDFILES=yes REQUEST=yes CALLBACKI=no \
```



```
READ=/ \
```

```
WRITE=/ \COMMANDS=ALL
```

where the **LOGNAME** parameter creates a link with *dave's* Systems file.

Step 11. Test the X.25 connection using:

```
bill# x25server  
dave# x25check [bill's X.121 address]
```

If successful, you will receive the message "Remote connection succeeded."

Step 12. Test the files: x29hosts, x3config (at *bill*) using:

```
dave# padem [bill's X.121 address]
```

If successful, you will receive the "login" message and you will be able to enter your details.

Step 13. Test the files: x29hosts, x3config, Systems, Devices (at *dave*) using:

```
dave# cu -d9 bill
```

If successful, you will receive an output something like:

```
Autodialing - please wait  
call dial(1761259328)  
baud=19200, speed=19200, line=(null), telno=-  
call find_dev(15076527500)  
baud=19200, speed=19200, line=(null), telno=-  
nomodem is 0  
fixline(6, 19200)  
fixline - direct  
MDTR was not set  
gdial(direct) called  
call mode(1)  
Connected  
transmit started  
receive started  
Generic-Sys (generic) [HP Release A.B9.04]
```

```
login:
```

If you don't see the "login:" prompt, type **dave# uusnap**. You should receive the following output:

```
x29 --- --- --- LOCKED (pid 57602)
```

```
bill --- --- --- [error message]
```

Refer to the UUCP section in Chapter 9 of the *Remote Access: User's Guide* (part number B2355-90037) for more information on UUCP error messages.

Step 14. Test the file permissions of both *bill* and *dave* using:

```
dave# /usr/lib/uucp/uucico -r1 -x9 -sbill
```

where **-r1** indicates that *dave* is the “master” (for UUCP purposes) and **-x9** is the highest debugging level.

If successful, you should receive output similar to:

```
mchFind called (bill)
list (rmail) num = 1
list (/) num = 1
list (/) num = 1
list (ALL) num = 1
_Request (TRUE), _Switch (TRUE), _CallBack (FALSE), _MyName
(dave),
_Commands ALL
chdir(/var/spool/uucp/bill)
conn(bill)
ProtoStr = f
Device Type dev_bill wanted
mlock x29/bill succeeded
fixline(5, 19200)
fixline - direct
gdial(direct) called
/* X.25 connection established*/
getto ret 6
expect: ("")
got it
sendthem (^MDELAY
^MDELAY
^M^M)
expect: (ogin:)
/* reception of "bill"'s banner*/
^MGeneric-Sys (generic) [HP Release A.B9.04]^J^M^J^Mlogin:got it
sendthem (uucp^M)
enter ub_sst, status is : 0
Rmtname: bill
img > ^M^M^Jlogin: ^M^M^Jlogin: ^M^M^M^Jlogin: ^M^Jlogin:
uucp^M^M^JPlease wait
..checking for disk quotas^M^J^PShere=bill^@Login Successful: System=bill
```

```
imsg >^PROK^@msg-ROK
Rmtname bill, Role MASTER, Ifn - 6, Loginuser - root
rmsg - 'P' imsg >^PPgfdx^@got Pgfdx
wmsg 'U'f
Proto started f
/*the f protocol for UUCP is selected*/
*** TOP *** - role=1, setline - X
gtwvec: dir /var/spool/uucp/bill
wmsg 'H'
got HY- 'H' enter frdmsg:HY
PROCESS: msg - HY
HUP:
wmsg 'H'Y
cntrl - 0
send OO 0,imsg >HY^M^POOOOOO^@exit code 0
Conversation Complete: Status SUCCEEDED
```

If you receive an error such as “RETRY TIME NOT REACHED,” you can delete the status file as follows:

```
dave# rm /var/spool/uucp/.Status/bill
```

If you receive the message “SUCCEEDED,” your uucp/X.25 connection is operating correctly.

Step 15. Test file transfers using:

```
dave# uucp -r /tmp/filename bill!/tmp/filename
```

where you’re transferring a file from *dave* to *bill* and the *-r* option puts the request in the queue.

To launch the file transfer correctly, now use:


```
dave# /usr/lib/uucp/uucico -r1 -x9 -sbill
```

This completes the testing procedure.

Local PAD Emulation (padem)

The `padem` program provides local PAD emulation to enable a local terminal (real or emulated) to connect to a remote system over an X.25 PSN. `x29server` handles the connection on the remote host side. The remote system can be specified upon execution or with subsequent `padem` commands issued during operation (see illustration below).

Figure 6-7



The `padem` program operates in either command or data transfer mode. The operating mode depends on whether an X.121 address or a symbolic address is specified when `padem` is launched.

Command Mode

If the X.121 address or symbolic address of the remote host is not specified, `padem` begins execution in command mode and prompts the user for commands with `x28>` (the `padem` prompt).

In command mode, `padem` receives X.28 PAD commands from users. Any `padem` command can be entered at the prompt. Once `padem` establishes an SVC with a remote host, it switches to data transfer mode.

Data Transfer Mode

If the X.121 address or the symbolic address of the remote host is specified, `padem` begins execution in data transfer mode.

In data transfer mode, typed text is sent to the remote host and text received from the remote host is displayed at the local terminal. You can re-enter command mode to issue a `padem` command by pressing **Ctrl P**.

If the VC is cleared at any time (by the remote host or by the X.25 network), `padem` returns to command mode or exits if the remote host address was at the HP-UX prompt.

Configuring Local PAD Emulation

NOTE

See the man pages for `padem` for its syntax and parameters.

You can configure local PAD emulation by modifying parameters in the `pad_em` and `host_table` sections of the `/etc/x25/x29hosts` file.

Examples of these sections are given below. See Appendix B, X.25 Configuration Files and Examples, for an example of the `x29hosts` file.

```
pad_em {
    remote_x121      4085551111
    name             interface0
    logging          3
    reverse_charge    enable
    profile           0
}
host_table {
    Gale             4085551111
    Tornado          4085551113
    Deepthought      4085551115
}
```

Parameter Descriptions

<code>remote_x121</code>	Mandatory. This is the X.121 address of the remote system. Only numbers 0 through 9 are legal; wildcards or special address types are not allowed. If this entry exists, any call to the remote X.121 address will use the associated fields (<i>logging</i> , <i>reverse_charge</i> , <i>profile</i> , and <i>name</i>).
--------------------------	--

<i>name</i>	Optional. This is the name of the programmatic interface used for call setup. If this entry does not exist, the default name associated with <code>/dev/x25_0</code> is used. This name must match the programmatic access name (also called <i>name</i>) in the X.25 configuration file.
<i>logging</i>	Optional. Specifies the logging level that applies to all calls made during this session. The log file is <code>\$HOME/plog.aXXXXX</code> , where the last five characters are from the process ID of <code>padem</code> . If this parameter is not specified, the logging level is set to the default level of 0 (no logging). Logging levels are: 1 = error logging, 2 = error and warning logging, 3 = error, warning, information, and status logging.
<i>reverse_charge</i>	Optional. Specifies the reverse charge option for call setup. Possible settings are: <i>disabled</i> (or <i>disable</i>) and <i>enabled</i> (or <i>enable</i>). The default value is <i>disabled</i> . When reverse charge is enabled, <code>padem</code> sends a reverse charge request with all call request packets.
<i>profile</i>	Optional. Describes the X.3 configuration for the login session. The X.3 default values are defined in the code (programmatically) and cannot be altered by users. These default parameters comply with the 1984 <i>profile 0</i> specification for a PAD device. If <i>profile X</i> is in <code>x29hosts</code> and <i>profile Y=X</i> is in <code>x3config</code> , <code>padem</code> uses <i>profile X</i> . If there is no profile in <code>x29hosts</code> , and <code>x3config</code> contains <i>profile 0</i> , <code>padem</code> uses <i>profile 0</i> . In all other cases <code>padem</code> uses the hard-coded default values. <code>padem</code> only operates in line mode for X.3 configuration.
<i>host_table{ }</i>	Optional. Defines symbolic host names for remote X.121 addresses. The first entry defines the symbolic name and the second entry is the remote X.121 address. If an X.121 address is given, it must also exist in the <i>remote_x121</i> field in the <i>pad_em</i> section of the <code>x29hosts</code> file.

NOTE

You do NOT need to have `pad_em { }` entries in the `x29hosts` file. You can specify all of the above parameters at the command line when you run `padem`.

Command line options are given priority over those in the `x29hosts` file. If options are not specified at the command line or in the `x29hosts` file, the programmatic access name associated with `/dev/x25_0` is used for call setup, the logging level is set to 1, the reverse charge option is *disabled*, and the default X.3 profile values are used.

PAD Commands

PAD command signals are grouped into the X.28 PAD command set (defined by CCITT X.28 recommendations) and include an extended command set providing additional functionality.

X.28 PAD Command Set

clr

Clears a virtual circuit (VC), disconnecting the VC from the remote host.

int

Transmits an interrupt to the remote host.

par?

Displays all of the X.3 parameters and their current values. The format for the display is:

X.3 parameter number: current value

prof [profile_id]

Interprets a prepared set of command signals from a profile. Profiles must be placed in the file `/etc/x25/x3config`.

reset

Resets a virtual circuit (VC). When a VC is reset, all data received (but unread) is lost, and all X.3 parameters are set to the default values (as they were defined before the VC was established).

set n:v [,n:v]

Sets the X.3 parameter *n* to value *v*. If there is a syntax error, padem responds with an ERR service signal and updates the diagnostic text. All changes take effect when a new VC is established, or immediately if one is already established.

set? n:v [,n:v]

Sets the X.3 parameter *n* to value *v* and displays the current setting of all parameters. This command is a combination of the `set` and `par?` commands.

stat

Displays status information of a VC. `padem` responds with “FREE” if no VC is established or with “ENGAGED” if there is a VC established.

[r,g[n[n]]-] x121_address [subaddress] [P/Dd..d

Performs a virtual call to the remote host defined by its X.121 address. *x121_address[subaddress]* can be replaced with “|**symad**|” where **symad** is defined in the file `/etc/x25/x29hosts`. **P** specifies the packet size negotiation. **D** specifies the Call User Data (CUD).

Extended Command Set

aprof

Lists all profile IDs known to `padem`. The profile IDs are contained in the `x3config` file.

help

Displays a complete list of all `padem` commands with a short description of each.

ifname [string]

Displays or sets the programmatic access name of the interface to which `padem` is (or will be) connected.

If this command is entered with a programmatic access name specified in *string*, `padem` sets the programmatic access name for the interface. If the command is entered and *string* is not specified, `padem` displays the programmatic access name for the interface.

list

Lists all symbolic names for remote hosts that are accessible to the user. The symbolic reference names are contained in the `/etc/x25/x29hosts` file.

lprof

Displays the last loaded profile ID.

quit

Terminates `padem`. If the SVC is still connected, it is cleared.

sleep s

Suspends `padem` for *s* seconds (maximum 3600).

verbose

Puts padem in verbose display mode. When padem operates in verbose display mode, it displays CAUSE, EFFECT, and ACTION messages in addition to the standard diagnostic message.

NOTE

Certain parameters may be changed automatically during the session as a result of PTY reconfigurations by the application at the other side of the connection. These changes will temporarily alter the original defaults set by the PAD Services. The PAD terminal user may also change PAD parameters at any time with X.28 commands. However, this may result in unpredictable behavior from the application being processed.

Configuring X.3 Profile Parameters

X.3 PAD parameters are used to specify how certain I/O operations are performed between Data Terminal Equipment (DTE) and the remote host PAD. These parameters are used to ensure that the local DTE and the remote PAD use the same communications profile.

Each of the 22 parameters has an identifier known as the parameter reference. This identifier is an integer value from 1 to 22. Each parameter has a defined range of possible values as specified by the X.3 recommendations.

X.3 parameters are specified in one or more configuration sets contained in the `/etc/x25/x3config` file. Each configuration set includes:

- X.3 configuration set name and profile number
- Parameter number
- Parameter value for line mode (value1) and raw mode (value2)
- Comment lines starting with “#”

See Appendix B, X.25 Configuration Files and Examples, for an example of the `x3config` file.

Configuration Set Syntax

The syntax for an X.3 configuration set is shown in the following example:

```
config_name : profile_number {  
    # <X.3 parameter_no>    <value1>    <value2>  
    1                        1            1  
    2                        1            1  
    .                        .            .  
    .                        .            .  
    .                        .            .  
    22                       0            0  
}
```

An X.3 configuration set is a string which embodies the group of X.3 parameters and parameter values beginning with “{” and ending with “}”. Each configuration set is identified by a configuration set name (*config_name*) and an optional profile number (*profile_number*).

Parameter Values

- config_name* **Mandatory.** Specifies the configuration set name, a character string that identifies the X.3 parameter set. Each *config_name* must be unique. This is a required parameter for all PAD services if user-defined X.3 parameters are to be used. This name must match the *x3* value given in the *x29hosts* file for *pad_spt*, *printer*, or *pad_uucp* entries. Since X3 has no effect on **pad_em** entries, a dummy string for *config_name* together with a profile number should be entered for *padem* profile parameters.
- profile_number* **Optional.** Applies only to the *padem* configuration. This is a number that must match the number entered for *profile* in the **pad_em { }** section of the *x29hosts* file. If the profile entry exists and is assigned a value in the *x29hosts* file, it must also appear in the *x3config* file.
- X.3_parameter _no* **Mandatory.** This is an integer value from 1 to 22. See “X.3 parameter descriptions” later in this chapter for a full description of each X.3 parameter.
- value1, value2* **Mandatory.** These are the values to be used in X.3 configuration. Each value is defined for a specific X.3 parameter: *value1* is for line-mode configuration; *value2* is for raw-mode configuration. Only *x29server* implements raw-mode data transfer and only parameters 3 and 4 are used for raw-mode data transfer. *x29printd*, *x29uucpd*, and *padem* do not use *value2*.

Modifying Parameters

Initial parameter settings can be changed at any time during a call. This occurs when *x29server* detects an *ioctl()* call to configure the PTY for a PAD terminal. This system call could be issued by the UNIX login process, by a shell initialization script such as *.login*, or by an application.

Each *ioctl()* request is examined by the server. If a mapping exists between the terminal I/O parameter and X.3, the terminal I/O value is checked against the current X.3 setting. If the request calls for a change,

the current X.3 setting is overwritten on the server. A set command is sent to reset the parameter in the remote PAD. If `x29server` cannot map the terminal I/O parameter to X.3, the request is processed as a normal terminal I/O `ioctl()`.

When `x29printd` and `x29server` transform terminal I/O parameters into X.3 parameters, they intercept the `ioctl(tcseta)` call and send an X.29 set command with new X.3 parameter values if necessary. The related X.3 parameters are: 2 (echo), 3 (data forward), 4 (idle timer), 5 (device control), 12 (flow control), 15 (editing), 16 (character delete), and 17 (line delete).

The `x29server` process downloads only those X.3 parameters that are specified in the `x3config` file for a particular remote system. The `x29print` process always downloads a set of X.3 parameters (if they exist in the `x3config` file) at the beginning of a connection, or the default X.3 parameters (given in the preceding table) if the X.3 parameters do not exist in the `x3config` file.

The X.3 parameters for `padem` can be changed by an X.29 set message from the remote host or by the terminal operator with a set command.

Default X.3 Parameters

If the `x3config` file does not have a definition for a particular device, the defaults (listed in the next section) are used. See Appendix B, X.25 Configuration Files and Examples, for an example of the `x3config` file.

X.3 Parameter Descriptions

The following pages contain a description of X.3 parameters 1 through 22. The default X.3 parameters vary for each PAD service.

X.3 Parameter Descriptions**NOTE**

Parameters 1 to 18 are available for networks using either the 1980 or 1984 standard. Parameters 19 through 22 only apply to the 1984 standard.

Table 6-2**X.3 Parameter Descriptions**

X.3 Parameter	Description
1 - ESC/Data Transfer	Specifies whether or not the terminal user will be allowed to escape from data transfer mode in order to send PAD command signals. 0 indicates escape is not allowed, 1 permits escape from data transfer mode with Ctrl-P , 32 to 126 permits escape from data transfer mode with the defined character.
2 - Echo	Specifies whether or not the PAD echoes to the local terminal all the characters received from that device. 1 turns echoing on; 0 turns echoing off.
3 - Data Fwd Signal 1	Specifies one of the defined sets of characters for use as a data forwarding signal. When one of the characters in the set is received from the terminal, the PAD terminates the assembly of a packet and forwards it to the remote host. The possible values are listed below.

Table 6-3

Value	Meaning
0	No data forwarding character.
1	Alphanumerics.
2	Carriage Return only. (This is the default.)
4	ESC, BEL, ENQ, and ACK only.
8	DEL, CAN, and DC2 only.

Table 6-3 (Continued)

16	ETX and EOT only.
32	HT, LT, VT, FF only.
64	NUL, SOH, STX, BS, LF, CR, SO, SI, DLE, DC1, DC3, DC4, NAK, SYN, ETB, EM, SUB, FS, GS, RS, and US (all other characters in the first two columns of the International Alphabet #5).
126	All characters, except alphanumerics.
127	All characters are data forwarding.

NOTE

The values listed for parameter 3 may be combined by specifying the sum of the values. For example, specifying 10 is the same as specifying 2 and 8.

Table 6-4

X.3 Parameter	Description
4 - Idle Timer	Specifies a timer duration interval in units of 1/20 of a second. If the time between characters entered at the terminal exceeds the specified timer value, the packet being assembled by the PAD is automatically transmitted. The range is 0 through 255. If 0 is specified, there is no idle timer and packets will never be transmitted due to a time-out.
5 - Anc Device Control	The ancillary device control parameter permits flow control toward the terminal by the PAD. The PAD indicates its readiness to receive characters from the terminal by transmitting X-ON (DC1) or X-OFF (DC3) to the terminal. 0 indicates that flow control by the PAD is not operational, and 1 permits flow control by the PAD.

Table 6-4 (Continued)

6 - Service Signals	Specifies that the terminal is to receive the PAD service signals that are received by the PAD. PAD service signals are described in X.25: <i>The PSN Connection</i> . 0 indicates that no PAD service signals are received by the terminal, and 1 indicates that the terminal will receive PAD service signals.
7 - On Break	Specifies the action to be taken by the PAD when it receives a break signal from the terminal. The possible values are shown below.

Table 6-5

Value	Meaning
1	Transmit interrupt packet.
2	Reset.
4	Transmit indication of break (PAD message)
8	Escape from data transfer mode.
16	Discard output to terminal.

NOTE

The values listed for parameter 7 may be combined by specifying the sum of the values.

Table 6-6

X.3 Parameter	Description
---------------	-------------

Table 6-6 (Continued)

8 - Discard Output	This parameter restores data delivery to the terminal after the reception of the break character and value 16 has been specified for X.3 Parameter 7. This value may be modified by the reception of the break character. 0 indicates normal data delivery, and 1 indicates that data is discarded.
9 - Number of CR Padding Chars	Specifies the number of buffer characters to be added following a carriage return. This is used for hard copy terminals to allow time for the carriage to return to the left side of the page. The range is 0 through 7.
10 - Chars per Line/Wrap-Around	Specifies the number of printing characters to be transmitted before the PAD inserts a carriage return in the data stream. This parameter is not needed on terminals with auto-wrap-around. The range is 0 through 255.
11 - Baud	This parameter specifies the terminal access speed (Baud rate). <code>x29server</code> does not allow users to change the Baud rate. It defaults to the terminal Baud rate, which is usually 9600. The possible values and their associated Baud rates are listed below.

Table 6-7

Value	Baud Rate
0	110
1	134.5
2	300
3	1200
4	600
5	75

Table 6-7 (Continued)

6	150
7	1800
8	200
9	100
10	50
11	75 from terminal, 1200 to terminal
12	2400
13	4800
14	9600
15	19200
16	48000
17	56000
18	64000

Table 6-8

X.3 Parameter	Description
12 - Flow Control	Specifies whether the terminal can control the flow of data from the PAD to the terminal. 0 indicates no flow control by the terminal, and 1 indicates that flow control by the terminal may be used.
13 - Line Feed	Specifies whether the PAD inserts a line feed when a carriage return is detected. The possible values are shown below.

Table 6-9

Value	Meaning
--------------	----------------

Table 6-9 (Continued)

1	Line feed inserted after carriage return in data stream to the terminal.
2	Line feed inserted after carriage return in data stream from the terminal.
4	Line feed inserted after carriage return when echoed to the terminal.

NOTE

The values listed for parameter 13 may be combined by specifying the sum of the values. For example, specifying 3 is the same as specifying 1 and 2.

Table 6-10

X.3 Parameter	Description
14 - Line Feed Padding	Specifies the number of padding characters to be added following a line feed. This is used for hard copy terminals to allow time for the paper to be moved up. The range is 0 through 7.
15 - Editing	Specifies whether data editing is allowed from the terminal during data transfer (for example, character delete and line delete). 1 indicates that editing is allowed; 0 indicates that no editing is allowed.
16 - Character Delete	When editing is allowed, specifies which character to use for character delete. The range is 0 through 127.
17 - Line Delete	Specifies which character to use for the line delete character (when editing is allowed). The range is 0 through 127.

Table 6-10 (Continued)

18 - Line Display	Specifies which character to use for the line display character (when editing is allowed). The range is 0 through 127.
19 - Edit Service Signals	Specifies whether and how PAD service signals can be edited. This parameter is valid when the setting of X.3 Parameter 6 is not 0. The possible values are shown below.

Table 6-11

Value	Meaning
0	No editing permitted.
1	Editing permitted for printing terminals.
2	Editing permitted for display terminals.
8 OR 32 to 126	Editing permitted using specified character.

NOTE

If you specify a value greater than 7, that value specifies the editing character. This parameter is available only for networks using the 1984 standard.

Table 6-12

X.3 Parameter	Description
20 - Echo Mask	This parameter specifies which characters will not be echoed. X.3 Parameter 2 - Echo takes precedence over this parameter. The possible values are shown below.

Table 6-13

Value	Meaning
-------	---------

Table 6-13 (Continued)

1	Do not echo carriage return.
2	Do not echo line feed.
4	Do not echo VT, HT, and FF.
8	Do not echo BEL and BS
16	Do not echo ESC and ENQ.
32	Do not echo ACK, NAK, STX, SOH, EOT, ETB, and ETX.
64	Do not echo characters specified in X.3 Parameters 16, 17, and 18.
128	Do not echo NUL, SO, SI, DLE, DC1, DC4, SYN, CAN, EM, SUB, FS, GS, RS, US, and DEL.

NOTE

The values above may be combined by specifying the sum of the values. For example, specifying 3 is the same as specifying 1 and 2. This parameter is available only for networks using the 1984 or 1988 standards.

Table 6-14

X.3 Parameter	Description
21 - Parity	Specifies how parity should be treated. The possible values are shown below.

Table 6-15

Value	Meaning
0	No parity checking or generation.
1	Parity checking.
2	Parity generation.

X.3 Parameter Descriptions**Table 6-15 (Continued)**

3	Parity checking or generation.
---	--------------------------------

NOTE

This parameter is available only for networks using the 1984 or 1988 standards.

Table 6-16

X.3 Parameter	Description
22 - Number of Chars Before Page Wait	Indicates whether an end of page wait should occur and, if so, the number of lines per page. The range is 0 through 255. This parameter is available only for networks using the 1984 standard.

7 Tracing and Logging Utilities

Introduction


This chapter describes the use of the X.25 tracing and logging utilities provided with your X.25 link. These utilities are briefly described in the following table. Refer to Chapter 8, Troubleshooting, if you need help deciding which utility to use.

Table 7-1 Available Tracing and Logging Utilities

Utility	Description	Refer to:
netttl	Creates a user-defined log file containing frame and packet trace information from X.25 packet and LAP-B levels.	man page and this chapter for examples
netfmt	Formats trace information contained in the user-defined log file that was generated with the netttl command	man page and this chapter for examples
strace	Creates a log file of event messages for X.25 levels 2 and 3, and IP over X.25.	man page and this chapter for examples
strerr	Receives error messages from the Streams log driver.	man page and this chapter for examples

The following diagram shows the areas of the X.25 product covered by the network event logging and network tracing utilities.

Figure 7-1 The Scope of X.25 Tracing and Logging Utilities



nettl

Use this command to create an X.25 trace file. The description below is limited to the context of X.25 and assumes that `nettl` is already operating on your system. For more information and examples for this command, refer to your man pages.

NOTE

Before you can use the `nettl` command, your X.25 connection must be operating (launched with the `x25init` command).

Syntax

```
nettl [-traceon kind [kind...]] [-entity subsystem
[subsystem...] [-file name] [-card dev name] [-size limit]
[-tracemax maxsize] [-m bytes]
```

```
nettl [-traceoff] [-entity subsystem [subsystem...]]
nettl [-status info]
```

Parameters

-traceon(-tn) Starts tracing on the specified subsystem(s). The *traceon* argument must be accompanied by the *-entity* and *-card* options. The *kind* (parameter) mask must also be specified. All operations on specified subsystems are recorded when there is a match to the *kind* mask.

-tn kind

The *kind* parameter defines the masks (keywords with associated mask values) used by the tracing facility before recording messages.

You can use any of the following keywords and mask values:

Table 7-2 **Tracing Masks**

keyword ^a	mask
<i>hdrin</i>	0x80000000
<i>hdrout</i>	0x40000000
<i>pduin</i>	0x20000000
<i>pduout</i>	0x10000000

- a. Use *hdrin* or *hdrout* when you only want packet header information displayed. Use *pduin* or *pduout* when you want both the packet header AND the data displayed.

You can specify masks separately or combine them into a single number. For example, to enable tracing for both *pduin* and *pduout* (all packets coming in and out of the node) use the value *0x30000000*.

- entity (-e)* Enter **-e SX25L2** for level 2 tracing or **-e SX25L3** for level 3 tracing.
- file (-f)* Use this option to specify an output file for tracing information (mandatory unless tracing has already been started on another interface). Use the *-traceon* option the first time you run *nettl* to specify an output file.

NOTE

The *.TRCX* suffix is automatically appended to the output file where X starts at 0 and changes to 1 when the file becomes full. Traces are always written to the *.TRC0* file.

- card(-c)* This option is required with the *traceon* command to specify the X.25 subsystem interface (port) name. The X.25 device is specified with *x25_npx* which identifies the interface defined in your X.25 configuration file.

NOTE

The device file must be called `x25_npx`, where *n* represents the mandatory card instance number (range 0 to 255). The card instance number is the number reported by the `ioscan -f` command output (in the “I” column). The (lower case) *p* is a place holder and *x* represents the port number (1 or 2). *p* and *x* are required only for systems with dual-port cards.

`-traceoff (-tf)` This option turns tracing, specified with the `-entity` option, off.

`-status(-ss) trace` Use this option to get a report on the tracing/logging status.

Examples

To turn tracing on at Level 3 for device `x25_1` (interface number 1) and receive packet header AND packet data information:

```
nettl -tn pduin pduout -e SX25L3 -c x25_1 -f /tmp/tracex25
```

To turn tracing off at Level 3 for the device `x25_1`:

```
nettl -tf -e SX25L3 -c x25_1
```

netfmt

Use this command to format the trace file that was created with `nettl`. Refer to the man pages for `x25trace` for more information and examples on this command

Syntax

```
netfmt [-c filter file [-p]] [-F] [-t records] [-N] [-v] [-l]
[-l[LT]] [[-f] file_name]
```

Parameters

-c filter file

Specifies the name of the file containing the filter configuration commands. You create this file with your text editor. If this option is omitted, filter configuration commands are read from the `$HOME/.nettr` file if it exists. Refer to “Creating a filter file” at the end of this section for an explanation of filter file syntax.

-p

The parse input option lets you do a syntax check on the configuration file specified with the *-c* option. If the syntax is correct, `netfmt` terminates with no output or warnings.

-F

The follow input file option causes `netfmt` to keep the input file open when it reaches the end of the file. The file is kept open and `netfmt` continues to read from it as new data arrives. This option is useful for troubleshooting because it lets you monitor events in real time.

-t records

Lets you specify how many records you want to format from the end of the file. This enables you to get the most recent information. The maximum number of records is 1000. By default, all records are formatted.

-f file_name

- Use this option to specify the binary file containing the log or trace data. This is the name of the .TRC0 file that was specified when nettl was run the first time with the *-traceon* and *-file* options. By default, data is read from standard input.
- v** Enables “verbose” mode, but also gives the full data output for each packet header (see *Examples* section below).
- N** Enables “Nice” formatting of output. Only packet headers and the first few lines of the main data output are displayed. Only the data length is provided in addition to the packet header to make the output easier to read (see *Examples* section below).
- 1** (one) Enables “terse” (short) mode formatting of each traced packet on a single line. Output lines will be more than 80 characters long if the *-L* and/or *-T* options are used (see *Examples* section below).
- l** (small letter “l”) Use this option when you send formatted trace data to a line printer to turn off inverse video highlighting of all trace fields.

Examples

To format the file /tmp/tracex25.TRC0 in “verbose” mode (packet headers plus full data output for each header) with no filtering:

```
/etc/netfmt -v -f /tmp/tracex25.TRC0 | more
```

The output will resemble the following:

```
vvvvvvvvvvvvvvvvvvvvvvvvvvvvLAN/X.25NETWORKINGvvvvvvvvvvvvvvvvvvvvvvvvvvvv
Timestamp : Wed Sep 28 1994 10:16:19.696042
Process ID      : 10          Subsystem           : SX25L3
User ID ( UID ) : 0          Trace Kind          : 0x10000000
Device ID      : 0          Path ID           : -1
Connection ID  : 0
Location       : 00123
Tx board: 0 at Wed Sep 28 1994 10:16:19.689181 Data Packet lci 64
  Q-bit : 0          D-bit : 0          M-bit : 0
  P(R)  : 0          P(S)  : 0
  User Data = 20 bytes
```

```

0: 00 00 00 01 61 61 61 61 61 61 61 61 61 61 61 61 ...aaaaaaaaaaaa
16: 61 61 61 61 -- -- -- -- -- -- -- -- -- -- -- -- -- -- -- aaaa.....

```

To format the file `/tmp/tracex25.TRC0` in “Nice” mode (output is mainly packet headers) with no filtering:

```
/etc/netfmt -N -f /tmp/tracex25.TRC0 | more
```

The output will be:

```

Tx board: 0 at Wed Sep 28 1994 10:16:19.689181 Data Packet lci 64
  Q-bit : 0          D-bit : 0          M-bit : 0
  P(R)  : 0          P(S)  : 0
  User Data = 20 bytes

```

To format the file `/tmp/tracex25.TRC0` in “terse” (short) mode, with no filtering:

```
/etc/netfmt -1 -f /tmp/tracex25.TRC0 | more
```

The output will be:

```
Tx board: 0 at 10:16:19.689181 Data Packet lci 64 PR: 0 PS: 0
```

Creating a Filter File

You can use a filter file to filter information according to various criteria. This enables you to apply system-level filtering to get information such as a time stamp for a specific subsystem.

You create a filter file with your text editor by entering the filter configuration commands in predetermined fields on the same line. The filter commands are: **type**, “!” (not), and **value**.

The values specified in the filter file are compared against the input values. When there is a match, the information is recorded. It is possible to create specific filters for all configured subsystems.

Refer to the man pages for `netfmt` for a complete explanation of the format file syntax.

Filter File Syntax

Each line (filter) in the system level filter file begins with the keyword `FORMATTER FILTER` (for system level filters) or `SX25L3` (for subsystem level filters, level 3 only). Entries are not case-sensitive, and spaces and tabs are ignored. The syntax is shown below:

```
FORMATTER FILTER [type][!] [value]
```

or

SX25L3 [type][!] [value][value]...

The *value* field specifies the value for the given *type*. By default, this value is on (applies as a filter), but can be set to off with the “!” (not) prefix. The value used with SX25L3 can be a list of consecutive values, or a range of values.

The permitted *values* for the *types* are given in the table below. See the man pages for netfmt for examples.

Table 7-3 Filter File Options

System/subsystem level	Type	Value
FORMATTER FILTER (system level)	kind	all, hdrin, hdrout, pduin or pduout
	time_from	12:54:22 (hr:min:sec) 7/25/94 (month/day/year)
	time_through	12:54:22 (hr:min:sec) 7/25/94 (month/day/year)
	subsystem	SX25L3 (level 3)
SX25L3 (subsystem level)	lci	decimal number between 0 and 4095 (this can be a list or range of values)
	packet	call, callc, clear, clearc, data, rr, rnr, interrupt, reset, resetc, restart, restartc, diagnostic, registration, reject
	family (refer to Table 7-4 below)	connect, disconnect, data, fctl, network

The following table lists the packet types displayed for each *value* combined with *family*.

Table 7-4 Filter File family Options

family	Packet types displayed	
	from DTE to DCE	from DCE to DTE
connect	CALL REQUEST CALL ACCEPTED	INCOMING CALL CALL CONNECTED
disconnect	CLEAR REQUEST CLEAR CONFIRMATION	CLEAR INDICATION CLEAR CONFIRMATION
data	DATA DTE INTERRUPT DTE INTERRUPT CONFIRMATION	DATA DCE INTERRUPT DCE INTERRUPT CONFIRMATION
fctl	DTE RR DTE RNR RESET REQUEST DTE RESET CONFIRMATION	DCE RR DCE RNR RESET INDICATION DCE RESET CONFIRMATION
network	RESTART REQUEST DTE RESTART CONFIRMATION	DIAGNOSTIC RESTART INDICATION DCE RESTART INDICATION REGISTRATION

Filter File Examples

The following examples illustrate the use of filter configuration commands within the filter file.

Starts formatting at 10:55:21 on 7/16/94, finishing 3 minutes later:

```
FORMATTER FILTER time_from 10:55:00 7/16/94  
FORMATTER FILTER time_through 10:58:00 7/16/94
```

Filters data only on lci numbers 1, 3, 4, 5:

```
SX25L3 lci 1 3-5  
SX25L3 packet data
```

After you have created the filter file, check its syntax with:

```
netfmt -p -c filter_file
```

and then run:

```
netfmt -v -c /tmp/filter -f /tmp/tracex25.TRC0 | more
```

strace

The `strace` command collects logging event messages from X.25 level 3 and X.25 level 2 STREAMS modules and writes them to standard output. `strace` runs until terminated by the user. See the man pages for `strace(1)` for a more detailed description.

Running `strace` with several sets of arguments can impair STREAMS performance. Also, some messages may be lost if too many are logged at one time.

HP recommends that you run `strace` as a background process with output directed to a file.

NOTE

Only one process can run the STREAMS log driver at a time.

Syntax

```
strace [mod sub pri] ...
```

Parameters

mod Specifies the STREAMS module identifier for:

- X.25 level 3, *mod* should have a value of 200
- X.25 level 2, *mod* should have a value of 201
- X.25 level 1, *mod* should have a value of 210
- IP over X.25, *mod* should have a value of 208
- BSD over X.25, *mod* should have a value of 2503

sub X.25 subnetwork identifier. Use *all* the first time to get subnetwork identifiers (afterwards, you can enter the identifier for a specific subnetwork/interface).

For single-port cards, the code for the *sub* option is the decimal equivalent of $30 + n$ (both expressed in hexadecimal), where *n* is the card instance number. For example, for the interface defined by the device file

`x25_1`, the *sub* would be 49 ($48 + 1 = 49$). See the table below for more examples of the codes to be used for specific interfaces.

Table 7-5 **Single-port Subnet Interface Codes**


Card	Calculation (hexadecimal)	Sub code (decimal)
First card = 0 (<code>x25_0</code>)	$30 + 0 = 30$	48
Second card = 1 (<code>x25_1</code>)	$30 + 1 = 31$	49
Third card = 2 (<code>x25_2</code>)	$30 + 2 = 32$	50

For dual-port cards, the *sub* code is the decimal equivalent to the four-digit hexadecimal composite of the place holder code (70) + the card instance number + 30. The example below shows the calculation for the interface defined by the device file `x25_0p1`.

NOTE

The *sub* code for dual-port cards will be the same for both ports.

Figure 7-2



A simple way to think of dual-port *sub* codes is as the decimal equivalent of $7030 + n$ (expressed in hexadecimal), where *n* is the card instance number. For example, for the device file `x25_1p2`, the *sub* in hexadecimal would be

$$7030 + 1 = 7031$$

which, when converted to decimal gives you **28721**. Some sample calculations of the *sub* code for dual-port cards are provided in the table below.

NOTE

When specifying the name of device files in systems with dual-port cards, you must use the form

`x25_npx`

where *n* represents the card number (0 to 15, and the first card must be zero), the letter *p* is a place holder (for port), and *x* represents the interface (port) number (1 or 2).

Table 7-6

Dual-port Subnet Interface Codes

Interface	Calculation (hexadecimal)	Sub code (decimal)
<code>x25_0p1</code> , <code>x25_0p2</code>	$7030 + 0 = 7030$	28720
<code>x25_1p1</code> , <code>x25_1p2</code>	$7030 + 1 = 7031$	28721
<code>x25_2p1</code> , <code>x25_2p2</code>	$7030 + 2 = 7032$	28725
<code>x25_5p1</code> , <code>x25_5p2</code>	$7030 + 5 = 7035$	28725

pri

Specifies the logging priority level. Collects messages from the level equal to or less than the value given by *pri*. Values 1 to 6 are allowed for X.25 level 3, 1 to 4 for level 2, and 1 to 5 for IP over X.25.

The value *all* can be used for any argument in the command line to indicate that there are no restrictions for that argument.

Table 7-7 Output Format

X.25 level 3 (mod=200)	pri^a1	Call/Call Conf (CALL In/Out, CAA)
	pri 2	Clear/Clear Conf (CLR In/Out, CLC)
	pri 3	Reset/Reset Conf (RST In/Out, RSC: Reset Conf)
	pri 4	Restart/Restart Conf (REST In/Out, RESTC)
	pri 5	Interrupt/Int Conf (INT In/Out, INTC)
	pri 6	Data (DATA In/Out)
X.25 level 2 (mod=201)	pri 1	Link Up/Down
	pri 2	Link reset events (LINK Rst)
	pri 3	Frame Reject, Reject (FRMR In/Out, REJ In/Out)
	pri 4	Busy conditions (LINK Bsy)
IP over X.25 (mod=208)	pri 0	IP over X.25 fatal error (call your HP representative)
	pri 1	IP over X.25 error (check configuration or addresses)
	pri 2	IP over X.25 warning (unexpected event)
	pri 3	IP over X.25 info (IP over X.25 Up/Down)
	pri 4	IP over X.25 trace (internal procedures tracing)
	pri 5	IP over X.25 Data (datagram tracing)

a. pri = Logging priority level

Priorities 4 and 5 for IP over X.25 can only be used if IP over X.25 has been started with the *ifconfig debug* option set

The following table describes the parameters displayed for the various packet types at level 3.

Table 7-8

Packet Type	Parameters Displayed
CALL In/Out	lci number, gfi number
CAA	lci number, gfi number
CLR In/Out	lci number, cause/diagnostic
CLC	lci number
RST In/Out	lci number, cause/diagnostic
RSC:Reset Conf	lci number
REST In/Out	cause/diagnostic
REStC	no parameter displayed
INT In/Out	lci number
INTC	lci number
DATA	lci number, N(R)/N(S)

The following table describes the parameters displayed for the various frame types at level 2.

Table 7-9

Frame Type	Parameters Displayed
LINK Up	No parameter displayed
LINK Dwn	“Local” means DISC frame sent. “Remote” means DISC frame received.
LINK Rst	“Local” means SABM/UA exchanged, local initiated. “Remote” means SABM/UA exchanged, remote initiated.
FRMR In	No parameter displayed

Table 7-9 (Continued)

FRMR Out	“Rsn 1” means the control field received was not defined or not implemented. “Rsn 3” means the control field received was invalid. “Rsn 4” means the information field received was too long. “Rsn 8” means the control field received contained an invalid variable.
REJ In/Out (level 2)	“N(XX)” is an internal variable of no importance or meaning.
LINK Bsy (level 2)	“Local” means that the RNR has been sent. “Remote” means that the RNR has been received.

Table 7-10 Output Format

X.25 level 1 (mod=210)	pri ^a 0	Baud control (tx and rx counter)
	pri 0	Baud control (threshold exceeded)
	pri 0	Baud control (number of times threshold exceeded)

a. pri = Logging priority level

Examples of the strace Command

To display all event messages from X.25 level 3 for *all* interfaces, use:

```
strace 200 all all
```

To display all event messages from X.25 level 3 for interface 0, use:

```
strace 200 48 all
```

To display event messages from X.25 level 3 with priority levels 1 to 3, and from X.25 level 2 with priority levels 1 and 2, use:

```
strace 200 all 3 201 all 2
```


Examples of strace Output

The command:

```
strace 200 48 all
```

gives the following output:

```
324112 14:59:16 33683766 1 ... 200 48 CALL Out:'30' lci 400 gfi 1
324115 14:59:16 33683776 1 ... 200 48 CAA In:'30' lci 400 gfi 1
324116 14:59:16 33683776 6 ... 200 48 DATA Out:'30' lci 400 ns/nr 0000
324119 14:59:16 33683778 6 ... 200 48 DATA In:'30' lci 400 ns/nr 0001
324124 14:59:16 33683781 2 ... 200 48 CLR Out:'30' lci 400 C/D 00f2
324127 14:59:16 33683782 2 ... 200 48 CLC In:'30' lci 400
```

Column labels to help you interpret the output are shown in the following table:

Table 7-11

record num	time	tics	pri	ind	mod	sub	data
324112	14:59:16	33683766	1	...	200	48	CALL Out

The command:

```
strace 200 49 all
```

gives the following output:

```
324191 14:59:59 33688076 1 ... 200 49 CALL In:'31' lci 400 gfi 1
324192 14:59:59 33688086 1 ... 200 49 CAA Out:'31' lci 400 gfi 1
324195 14:59:59 33688087 6 ... 200 49 DATA In:'31' lci 400 ns/nr 0000
324196 14:59:59 33688087 6 ... 200 49 DATA Out:'31' lci 400 ns/nr 0001
```

strace

```
324203 14:59:59 33688091 2 ... 200 49 CLR    In:  '31' lci 400 C/D 00f2
```

```
324204 14:59:59 33688091 2 ... 200 49 CLC    Out:  '31' lci 400
```

The command:

```
strace 201 48 all
```

gives the following output:

```
324790 15:06:17 33725841 1 ... 201 48 LINK Up  :  '30'
```

The command:

```
strace 201 49 all
```

gives the following output:

```
324893 15:07:18 33731984 1 ... 201 49 LINK Dwn:  '31' [Remote]
```

NOTE

The last example indicates a remote disconnection. '30' and '31' in the examples above are the hexadecimal code for subnetworks 48 and 49 (decimal) respectively.

strerr

Receives error messages from the STREAMS log driver.

The `strerr` daemon receives error messages from the STREAMS log driver (see the man pages for `strlog(7)`). By default, additions to the STREAMS error log files (`error.dd-mm`) are in the STREAMS error log directory (`/usr/adm/streams`).

When first called, `strerr` creates the log file `error.mm-dd`. This is a daily log file where `mm` indicates the month and `dd` indicates the day of the logged messages. `strerr` then appends error messages to the log file as they are received from the STREAMS log driver.

NOTE

`strerr` should always be used as a background process as it does not return the prompt to the user (the only way to stop it is to kill the process).

Refer to the man pages for `strerr(1)` for a detailed description of the output format.

Syntax

```
strerr [-a sys_admin_mail_name] [-d log_directory]
```

Parameters

`-a sys_admin_mail_name`

Specifies the name of the user who will receive error message by electronic mail.

`-d log_directory`

Specifies the directory that will contain the error log file. The default is `/usr/adm/streams`.

8 Troubleshooting

Troubleshooting Your X.25 Link

This section describes troubleshooting procedures for checking your X.25 link up to X.25 level 3. It also provides information on troubleshooting IP over X.25, as well as procedures for diagnosing switching problems. To use these procedures you should be familiar with the following commands:

Table 8-1 **Troubleshooting Commands**

Command	Purpose	Refer to...
x25init	Initializes X.25 interface and software. Superuser only.	man pages and examples at the end of Appendix B, X.25 Configuration Files and Examples,
x25stop	Safely shuts down the interface. Superuser only.	man pages
x25stat	Reports on X.25 status. Some options are for superuser only.	man pages and Chapter 5, Diagnostic Utilities, for examples
x25check x25server	Tests connectivity up to X.25 Level 3 between local and remote nodes.	man pages and Chapter 5, Diagnostic Utilities, for examples
ping	Tests IP to IP connectivity.	man pages
x25ping	Checks that X.25 interface can reach the remote server.	man pages
nettl	Traces and logs X.25 at X.25 packet and LAP B levels	man pages and Chapter 7, Tracing and Logging Utilities, for examples
netfmt	Formats trace information collected by nettl.	man pages and Chapter 7, Tracing and Logging Utilities, for examples

Table 8-1 Troubleshooting Commands (Continued)

strace	Logs X.25 event messages.	man pages and Chapter 7, Tracing and Logging Utilities,
strerr	Receives error messages from the Streams log driver.	man pages
netstat	Displays configured IP interfaces	man pages
ifconfig	Displays IP interface status	man pages

If you still have problems after using the troubleshooting procedures in this section, ask the System Administrator of the remote host to check the X.25 link using the same procedures.

If you have difficulties with high-level network software, refer to the appropriate troubleshooting manual for the particular software product.

This section includes the following troubleshooting flowcharts:

- Hardware check
- X.25 configuration check
- IP over X.25 check


This section also includes information on recovering from a power failure.

Troubleshooting Flowcharts and Procedures

The following pages provide flowcharts and procedures for troubleshooting common problems. Begin with Flowchart 1. If you are running IP over X.25, you should also refer to flowchart 5.

Troubleshooting procedures begin with the `x25stat` command. If `x25stat -d [devices] -f` returns a level 2 link state other than “normal,” there is a problem.

Figure 8-1 **Flowchart 1**



Flowchart 2 – Procedures and Notes

Use these procedures to verify that your X.25 link is correctly initialized. Read the following notes before carrying out the initialization check procedures in Flowchart 2.

Note 2-1 – **x25stat**

Level 2 is down if **x25stat -d [device] -f** returns a level 2 link state other than “normal.”

Note 2-2 – **eisa_config**

Sometimes **x25init** does not recognize the dual-port EISA interface (J2815A) after a first-time installation. When you reboot your system after installing the dual-port EISA interface, you may receive a message similar to:

Device `/dev/x25_0p1` is not configured in the kernel

If this problem occurs, you can work around it by running the `eisa_config` utility in interactive mode as shown below.

Step 1. At the EISA prompt, type:

```
add !HWP19A0.CGF <slot number>
```

where *<slot number>* is the number of the EISA slot in which the interface card is installed.


Step 2. Then type:

```
save
```

```
quit
```

Step 3. Reboot your system.

Figure 8-2 **Flowchart 2 – Initialization Check**



Flowchart 3 – Procedures and Notes


Use these procedures to verify that your hardware is properly connected and operating correctly. Read the following notes **before** running the hardware check procedures in Flowchart 3.

Note 3-1 – Hardware Check

Check the following:

- Interface cable
- Modem
- Network configuration
- Status light (for single port cards only)

Figure 8-3 **Flowchart 3 – Hardware Check**



Flowchart 4 – Procedures and Notes

This flowchart describes how to run a loopback test using `x25check` on the local node. This checks that your X.25 link to the network or X.25 switch is working correctly.

Note 4-1 – `x25check`

You do a loopback test using the `x25server` and `x25check` commands. The `x25server` process is only used to accept and echo back an X.25 packet coming from an `x25check` process. To run the loopback test, you need:

- 2 virtual circuits (either 1 one-way inbound and 1 one-way outbound, or 2 two-way),
- if you are connected to a private X.25 switch (rather than connected directly to a network), then the switch must be configured to return a call packet.


Note 4-2 – Exit

Your local X.25 configuration is correct. You can use `x25check` to verify connections to the remote host only if the remote host is running and:

- has X.25 initialized,
- is running `x25server`,
- has an X.25 configuration that is compatible with the local host's configuration.

If you still experience problems, contact the System Administrator at the remote host and ask them to check their X.25 configuration.

Figure 8-4 **Flowchart 4 – X.25 Configuration Check**



Flowchart 5 – Procedures and Notes

Use these procedures to verify your IP addressing and remote host connection.

Note 5-1 – ping

Use `ping` on your own IP over X.25 address, for example:

```
ping 195.25.0.13
```

Do not use aliases (for example, as defined in `/etc/hosts`), since this may introduce other errors.

Use the **Break** key or **Ctrl-C** to terminate `ping` if you have not set the number of packets with the `-n` option.

Note 5-2 – Checking your IP over X.25 Configuration

If `ping` returns errors such as “100% packet loss,” or “Network Unreachable,” use `x25stat -a` to check your address configuration. The most likely causes of problems are:

- No IP address was specified when X.25 was initialized (either in the X.25 configuration file or as a command line option to the `x25init` command).
- IP to X.121 address mapping has not been initialized (using the `-a` option with the `x25init` command).
- The IP address is incorrect.
- The mapping of your IP address to your X.121 address is incorrect. Check the IP to X.121 map table file (the default file is `/etc/x25/ip_to_x121_map`).

If no IP communication is possible (`ping` to a local IP address fails) and `netstat -a` shows no entries despite the fact that `x25init` reported a successful IP mapping, the likely cause is:

- the `device=x25_card_device` parameter has not been added to the `/etc/x25/ip_to_x121_map` file. See the section, “IP-to-X.121 Address Mapping Table” in this chapter.

You can also use the `netstat` command with the `-r` option to get information about IP addresses associated with a particular interface.

Note 5-3 – Exit


Your local IP over X.25 configuration is correct. You can use `ping` to verify connections if the remote host:

- is operational,

- has X.25 initialized,
- is compatible with IP and ICMP protocols,
- and has an entry for your node in its map table (can map your IP address to your X.121 address).

If you still experience problems, ask the remote host System Administrator to check the IP over X.25 configuration on the remote side of the connection.

Figure 8-5 **Flowchart 5 – IP Over X.25 Check**



Recovering From a Power Failure

For Systems With a Backup Power Supply

If your site is equipped with a backup power supply, system memory will be preserved in the event of power failure. However, because your X.25 hardware does not have backup capability, any on-board RAM-based memory is lost.

Recovery from a power failure is automatic when the `/etc/powerfail` script is invoked by `/etc/inittab`. Otherwise SMH (or `x25init`) must be used to manually re-initialize the interface after a power failure.

The recovery mechanism informs the X.25 driver of the power failure. The X.25 driver then “marks” the interface as “down” and a DISCONNECT INDICATE is received on all open SVCs.

For Systems With No Backup Power Supply

If your system does not possess the battery backup option, both system memory and interface card memory are lost. You must reboot your system.

Reporting Problems

If you have a service contract with HP, ask your service representative to document the problem as a Service Request (SR).

Include the following information where applicable:

- A detailed description of the problem. Describe the events leading up to the problem and the symptoms of the problem. Include information on HP-UX commands, communication subsystem commands, job streams, result codes, and error messages (the exact wording).
- A record of the output from `x25 stat -c` or a copy of the configuration file for each node. Record the output from `netstat`.
- A printout of the existing configuration files.
- A copy of the `ipmap` file.
- A copy of the PSI upload file.
- The version, update, and fix information for all software. From this information HP can determine if the problem is already known and if the correct software is installed at your site.
- Use the `what` command to check your X.25 version.

NOTE

Your host node should be running HP-UX Release 10.0 or later. To check the version of your kernel, execute `uname -r`.

-
- Any network log files produced using the `netfmt` command (see Chapter 7, Tracing and Logging Utilities, for details of `netfmt`), and formatted copies of any X.25 trace files that were active when the problem occurred.
 - A short description of your application and how it should work.
 - **In the event of a system failure, take a full memory dump.** Use the HP-UX utility `/etc/savecore` to save a core dump. Refer *Debugging Streams/UX Modules and Drivers - Streams/UX for the HP 9000 Reference Manual* for details.

- For PAD Problems:
 - Copies of the `x29hosts` and `x3config` files.
 - A copy of the output from the `ls -l /dev/x29` command if you are running `x29printd` or `x29uucpd`.
 - Identify which PAD utility is encountering the error (PAD services, PAD emulation, Remote PAD printer, or UUCP). Include all files relative to that service (for example, `.login`, profile ID, `/usr/spool/lp/*`, or `/usr/lib/uucp/*`).
 - Include log files for the PAD services.
 - Provide a detailed description of the problem.

For more information about files related to PAD services see Chapter 6, “PAD Services.”

NOTE


If you do not have a service contract with HP, you can still follow the procedure described above, but you will be billed accordingly for time and materials.

Back-to-back Configuration on the Same Host

Systems with multiple X.25 interfaces can use back-to-back configurations to perform diagnostics. If you suspect that a switch might be the source of your connection problem, you can set up a back-to-back configuration to test the circuit without the PAD switch.

To set up a back-to-back connection on a single host, you connect one card to another card on the same host through a modem eliminator, as shown below. The modem eliminator provides the necessary clocking for the DCE. The most common modem eliminators are RS-232 and V.35.

Figure 8-6



In order for two cards (on the same host) to communicate, one card must be configured as the DTE and the other card as DCE.

To set up a card as DCE, use the `x25init` command and enter `DCE_80`, `DCE_84` or `DCE_88` (according to the standard you are using) in the `networktype` parameter.

You must also make sure that the two cards are using compatible level 2 parameters.

Once both cards are initialized, you can run `x25check` and `x25server` to verify the connections. If `x25check` completes successfully in this setup but does not complete successfully with the switch in place, the switch is incorrectly configured. Check with your network provider for correct switch configuration.

Configuration and Troubleshooting Commands

This section provides a brief summary of X.25 commands and indicates where further information can be found. Examples of `x25init` and the syntax for IP over X.25 mapping are provided at the end of the section.

Command Summary

NOTE

You can use the `x25message` utility to get an explanation of an error message. Enter the command at the HP-UX prompt followed by the text of the message, and the system will display an explanation of the cause along with recommendations for corrective action.

x25init

Initializes your X.25 link (requires Superuser privileges). See your man pages and the examples later in this section.

x25stop

Gracefully shuts down an X.25 link (requires Superuser privileges). See your man pages.

x25check and *x25server*

Together, these commands can be used to test connectivity between two nodes up to the X.25 access level (level 3). See your man pages and the examples in Chapter 5, “Diagnostic Utilities.”

x25stat

Displays X.25 link status, configuration information, and virtual circuit statistics. See your man pages and the examples in Chapter 5, “Diagnostic Utilities.” Some options require Superuser privileges.

x25mibstat

Utility with programmatic interface that allows users to get additional X.25 statistics.

x25ping

Checks if a remote host can be reached via the X.25 interface. See your man pages.

ping

Tests connectivity to a remote host up to the Internet Protocol (IP) level (level 3). See your man pages.

route

Used to add a host or network to the network routing table. See your man pages.

proxy

The Probe proxy table is the NS equivalent of the Internet/Berkeley Services */etc/hosts* file. See your man pages.

netstat

Displays network statistics and information about network connections. See your man pages.

x25trace

Protocol level tracing facility. See your man pages.

x25upload

Dumps the interface card memory into a file. See your man pages.

nettl

Creates a user-defined log file containing frame and packet trace information from X.25 packet and LAP-B levels. See your man pages for *x25trace* and the examples in Chapter 7, "Tracing and Logging Utilities."

netfmt

Formats trace information contained in the user-defined log file that was generated with the *nettl* command. See your man pages for *x25trace* and the examples in Chapter 7, "Tracing and Logging Utilities."

strace

Collects and writes X.25 logging event message. See your man pages and the examples in Chapter 7, “Tracing and Logging Utilities.”

strerr

Receives error messages from the STREAMS log driver. See your man pages and the examples in Chapter 7, “Tracing and Logging Utilities.”

ifconfig

Configures network interface parameters. See your man pages.

Examples of x25init

The following example shows a valid `usr/sbin/x25init` command (provided that the programmatic access name has been specified in the configuration file `x25config_0`):

```
x25init -c x25config_0 4085551111 -a
ip_to_x121_map
```

Alternatively, the IP-to-X.121 map table can be specified in a separate `x25init` command:

```
x25init -c x25config_0 4085551111
x25init -a ip_to_x121_map
```

NOTE

If `x25init` fails, you can look at the `/usr/adm/x25/x25init.log` log file for troubleshooting information.

IP-to-X.121 Address Mapping Table

The IP-to-X.121 address mapping table is used to enable IP to route through X.25 networks by mapping a host's IP address to its X.121 address. The table is used for both inbound and outbound packets.

The IP-to-X.121 address mapping table is a kernel table created from an ASCII file containing one entry per line. It is created using `x25init` with the `-a` option. Each line describes the destination X.121 address used to

reach a host with a particular IP address. Reverse mapping reverses the order of translation. The default file name and directory for the mapping table is `/etc/x25/ip_to_x121_map`.

When the packet is outbound, the IP address is mapped to the X.121 address that is associated with it in the IP map file. When the packet is inbound, the X.121 address is mapped to the IP address of the same destination host. This is called “reverse mapping.” The table is not used when IP packets are transmitted to X.25 over DDN. In this case, the DDN-specific mapping algorithm is used instead. See *DDN X.25 Host Interface Specification (BBN83)*.

There must be an entry in the mapping table for each host you want to communicate with over a direct-connect X.25 network. If the host is connected through a gateway, you only need an entry for the gateway (containing the IP and X.121 addresses of the gateway).

NOTE

If the destination host is only reachable through a gateway, you must have a route to that host (a host or a net route).

The IP address in the table must belong to the same IP subnet as a configured card in your system, and this card must be already started when you initialize IP routing with the command:

```
/usr/sbin/x25init -a /etc/x25/ip_to_x121_map
```

If the IP address does not correspond to a configured card, the X.25 product does not know which interface to use to send packets. Therefore, you must place this information in your `/etc/x25/ip_to_x121_map` file by adding the `x25_card_device` parameter as shown in the syntax example below. **This is a manual procedure that cannot be done in SMH.**

Syntax for SVCs

```
IP_address X.121_address [{+URC|-URC}][{+ARC|-ARC}] device=x25_card_device,  
packet_size, window_size [CUG=n]
```

Syntax for PVCs

```
IP_address X.121_address pvc=n name=prog_access_name
```

NOTE

If you do not include the *packet_size* and *window_size* values, and the *x25_card_device* is the last field, the default values will be applied to the *packet_size* and *window_size* fields.

Example

```
15.128.174.04 12345 -URC -ARC
30.0.0.2 34567 -URC -ARC device=x25_0,256,7
```

In this example, a card has been configured with a device equal to *x25_0*, a packet size of 256, and a window size of 7.

You can then use the *gated* or *route add* command to send datagrams to the IP address, 30.0.0.2, routed through your X.25 network to the address, 34567. These packets will be sent out through the X.25 card that corresponds to the device *x.25_0*.

File Mapping Parameters

<i>IP_address</i>	Specifies a valid IP address in standard dot notation form: <i>n.n.n.n</i> where <i>n</i> is a number from 0 to 255 inclusive.
<i>X.121_address</i>	Specifies the corresponding X.121 address for the host with the above IP address.
<i>pvc=n</i>	Specifies which permanent virtual circuit should be used for the X.121 destination. The value <i>pvc=</i> is a keyword set to <i>n</i> , which is an integer variable indicating the lci of the permanent virtual circuit. This keyword/variable pair is specified only when a permanent virtual circuit is to be used for IP access. When it is not specified, the default value of a two-way SVC is assumed. The following information is provided for reference only.

Because *pvc* describes a permanent circuit for a particular interface, that interface must have been initialized prior to the initialization of the address map table. If the interface or the specified PVC does not exist, an error is reported.

*prog_access
_name* Specifies the card's programmatic access name.

NOTE

For Series 712 workstations this is always
name=interface0.

+URC Specifies that outbound calls to this IP address will Use Reverse Charging (URC).

-URC (Default) Specifies that outbound calls to this IP address will not Use Reverse Charging (URC).)

+ARC Specifies that inbound calls to this IP address will Accept Reverse Charging (ARC).

-ARC (Default) Specifies that inbound calls to this IP address will not Accept Reverse Charging (ARC).

x25_card_device A device configured for one of your existing X.25 cards. This information is used by the IP_to_X25 software to identify the interface port through which the outbound packets will be sent.

CUG=n Specifies the Closed User Group index number used for placing calls to this IP address. The index number is a two- or four-digit number. Two digits corresponds to the basic format, and four digits corresponds to the extended format of the CUG selection facility.

You can put comments in your IP mapping table by including the # character at the beginning of the line. Note that you cannot add comments after a table entry.

NOTE

For non-DDN configured interfaces, all remote hosts must have entries in the IP-to-X.121 address map table. Remote hosts not on your X.25 network (that is, on the other side of gateways) do not need to have map table entries. For more information, refer to the routing description in this section.

A Using Non-English Subscription Forms

Subscription Form Translations

This appendix lists the English (SMH dialog field) equivalents for terms that appear on your French, Italian, German or Spanish subscription form. Use this information to locate the English SMH dialog field equivalents of these terms. Terms are listed in order of appearance. Online help (using the **Help** button) is available for each field.

Table A-1

French TRANSPAC Subscription Form

English on SMH dialogs	French on subscription form
X.25 Address	No Transpac
Network Carrier Type	TRANSPAC
Permanent - <i>Quantity</i>	Nombre V.L. CVP
Switched (inbound) - <i>Quantity</i>	Nombre V.L. CVC Arrivée
Switched (two-way) - <i>Quantity</i>	Nombre V.L. CVC Mixte
Switched (outbound) - <i>Quantity</i>	Nombre V.L. CVC Départ
Fast Accept Selected	Acceptation sélection rapide
Flow Control Negotiation	Nég. taille Paquet et Fenêtre
Reverse Charge Accepted	Acceptation, PVC (TAD)
Default Packet Size - <i>Inbound & Outbound, Switched VC Flow Control</i>	Longueur paquet
Default Window Size - <i>Inbound & Outbound, Switched VC Flow Control</i>	Taille de la fenêtre
Packet Size - <i>Permanent VC Flow Control</i>	Longueur paquet
Switched VC Default - <i>Inbound & Outbound</i>	Choix classe de débit
Switched VC Negotiated	Négociation classes de débit

Table A-1 French TRANSPAC Subscription Form (Continued)

k - Level 2 Window Size (frames)	Fenêtre
T1 - Retransmission Timer (ms)	Temporisateur

Table A-2 Using Your ITAPAC (Italian) Subscription Form

English on SMH dialogs	Italian on subscription form
X.25 Address	Indirizzo X.25
Network Carrier Type	ITAPAC
Permanent - <i>Quantity</i>	Circuiti permanenti-numero
Switched (inbound) - <i>Quantity</i>	Circuiti commutati unidirezionali in entrata - numero
Switched (two-way) - <i>Quantity</i>	Circuiti commutati bidirezionali in entrata - numero
Switched (outbound) - <i>Quantity</i>	Circuiti commutati unidirezionali in uscita- numero
Fast Accept Selected	Selezione rapida
Flow Control Negotiation	Negoziazione dei parametri di controllo di flusso
Reverse Charge Accepted	Accettazione delle tasse al chiamato
Default Packet Size - <i>Inbound & Outbound, Switched VC Flow Control</i>	Dimensione di default del pacchetto - uscente, controllo di flusso VC commutato
Default Window Size - <i>Inbound & Outbound, Switched VC Flow Control</i>	Dimensione di default della finestra - uscente, controllo di flusso VC commutato
Packet Size - <i>Permanent VC Flow Control</i>	Dimensione del pacchetto - controllo di flusso VC permanente

Table A-2 Using Your ITAPAC (Italian) Subscription Form (Continued)

Switched VC Default - <i>Inbound & Outbound (Modify Throughput Class Setting)</i>	Classe di throughput di default in entrata & in uscita
Switched VC Negotiated (<i>Modify Throughput Class Setting</i>)	Classe di throughput negocia
k - Level 2 Window Size (frames)	k - Dimensione di finestra a livello 2
T1 - Retransmission Timer (ms)	T1 - Timer di ritrasmissione (ms).

Table A-3 Using your DATEX-P (German) Subscription Form

English on SMH dialogs	German on subscription form
X.25 Address	Rufnummer des Wählanschlusses
Network Carrier Type	DATEX-P
Permanent - <i>Quantity</i>	Feste virtuelle Verbindungen
Switched (inbound) - <i>Quantity</i>	Nur ankommende
Switched (outbound) - <i>Quantity</i>	Nur abgehend
Switched (two-way) - <i>Quantity</i>	Abgehend und ankommend
Reverse Charge Accepted	Möglichkeit der Verbindungsgebühreüber nahme bei ankommenden gewählten Ruf
Default Window Size - <i>Inbound & Outbound, Switched VC FlowControl</i>	Fenstergrösse w Senden Fenstergrösse w Empfangen

Table A-4 Using your IBERPAC (Spanish) Subscription Form

English on SMH dialogs	Spanish on subscription form
X.25 Address	NRI (Número Red IBERPAC)
Network Carrier Type	Tipo de Red (IBERPAC)

Table A-4 Using your IBERPAC (Spanish) Subscription Form (Continued)

Permanent - <i>Quantity</i>	Canales Lógicos Permanentes - cantidad
Switched (inbound) - <i>Quantity</i>	Canales Lógicos Unidireccionales Entrante - cantidades
Switched (two-way) - <i>Quantity</i>	Canales Lógicos Bidireccionales - cantidad
Switched (outbound) - <i>Quantity</i>	Canales Lógicos Unidireccionales Salientes - cantidad
Fast Accept Selected	Selección Rápida
Flow Control Negotiation	Negociación del Control de Flujo
Reverse Charge Accepted	Cobro Revertido
Default Packet Size - <i>Inbound & Outbound, Switched VC Flow Control</i>	Tamaño de Paquete por defecto - entrante y saliente, control de flujo en CV conmutados
Default Window Size - <i>Inbound & Outbound, Switched VC Flow Control</i>	Tamaño de Ventana por defecto - entrante y saliente, control de flujo en CV conmutados
Packet Size - <i>Permanent VC Flow Control</i>	Tamaño de Paquete - control de flujo en CV permanentes
Switched VC Default - <i>Inbound & Outbound (Modify Throughput Class Setting)</i>	CV conmutados por defecto - entrantes y salientes (Negociación de la Clase de Caudal)
Switched VC Negotiated (<i>Modify Throughput Class Setting</i>)	Clase negociada en CV conmutado (<i>Negociación de la Clase de Caudal</i>)
k - Level 2 Window Size (frames)	k - Tamaño de Ventana en Nivel 2 (tramas)
T1 - Retransmission Timer (ms)	T1 - Temporizador de Retransmisión (ms)

B X.25 Configuration Files and Examples

X.25 Configuration Files

This section lists X.25 configuration and addressing files.

Table B-1 */etc/x25 directory*

x25config_0	ASCII file containing X.25 parameters. This file can be used by the <code>x25init</code> command when initializing the card. It is created automatically if you configure X.25 using SMH. To configure X.25 manually, copy and edit either <code>x25init_def</code> or <code>x25init_smpl</code> .
x25init_def	Contains default X.25 configuration parameters and example configuration parameters for parameters that have no default. The listing for this file is shown later in this chapter. This file is read-only.
x25init_smpl	Contains example X.25 configuration parameters. The listing for this file is shown later in this chapter. This file is read-only.
ip_to_xl2l_map	Mapping table between X.25 and IP addresses. See “Configuration and Troubleshooting Commands” in Chapter 8, Troubleshooting, for more information on this file.
x25_networks	Contains information describing several canonical network types. The listing for this file is shown later in this chapter. This file is read-only.

Table B-2 */etc directory*

hosts	Associates Internet addresses with official host names and aliases. See the man page for <code>hosts</code> .
hosts.equiv (optional)	Security file which authorizes remote hosts and users on local host. See the man page for <code>hosts.equiv</code> .

Table B-2 **/etc directory (Continued)**

networks	Contains information regarding known networks.
----------	--

Table B-3 **/var/x25/log/x25server directory**

x25server.log	Log file of output from x25server process.
---------------	--

Table B-4 **/var/x25/log directory**

x25init.log	Log file of output from x25init command.
-------------	--

Table B-5 **Home directory**

.rhosts (optional)	Security file which authorizes remote hosts and users on local host. See the man page for hosts.equiv.
.netrc (optional)	Contains login and initialization information used by the ftp auto-login process. See the man page for netrc.

Example Files

This section provides example file listings for of the `x25init_def`, `x_25init_smp1`, `x3config`, `x29hosts`, and `x25_networks` files.

The `x25init_def` File

Table B-6

```
#
# Likely runstring: x25init -c x25init_def
# This sample X.25 configuration contains default values

# Mandatory parameter - X.121 address
# X.121 4085551202

# Typically the address on the packet is identical to X.121
# packet address except for some networks like TransPac which
# require that we put null address on the packet.

# X.121_packet ''      # use a null (i.e. length 0) packet

# Mandatory parameter - interface name for Level 3 access
# name interface0

# Mandatory parameter - device to initialize
# device x25_0pl

# Level 2 Parameters

t1 3000                # frame retransmission timeout; 3 seconds

t3 60000               # Level 2 idle timer; 60 seconds

# The frame size varies depending on flow-control negotiation
# and whether you subscribe for fast-select feature or not.
# max Level 2 transmission size (octets) [n1/8] for packet size
# 128 with fast select disabled is 149.

framesize 149          # n1/8 octets
n2 20                  # number of retransmissions allowed
k 7                    # Level 2 window
```

Table B-6 (Continued)

```
# Level 3 Parameters

# Mandatory Parameters - virtual circuit parameters
# logical channel id, start num [1-4095], type, how many
# At least one lci type (PVC, incoming, two-way or outgoing SVC)
# needs to be configured.

#lci 1 pvc 5           # 5 permanent VCs starting at LCI 1
#lci 255 insvc 5       # 5 one-way incoming SVCs starting at LCI
#lci 2048 svc 6        # 255
#lci 3072 outsvc 6     # 6 two-way switched SVCs starting at LCI
                        # 2048
                        # 6 one-way outgoing SVCs starting at LCI
                        # 3072

networktype DTE_84    # CCITT 1984, DTE (see
fast_select disabled  # /etc/x25/x25_networks)
reverse_charge        # disallow incoming calls with call user
disabled              # data
                      # disallow incoming calls requesting
                      # reverse changes

def_inpacketsize 128  # default packetsize
def_outpacketsize 128 # default packetsize
def_inwindow 2      # default window size
def_outwindow 2     # default window size
# def_inthruputclass # default thrupt class
19200                # default thrupt class
# def_outthruputclass
19200

flowcontrol off      # flow control negotiation not allowed
neg_inpacketsize 128 # offered pkt size if using flow control
neg_outpacketsize 128 # negotiation
neg_inwindow 2       # offered pkt size if using flow control
neg_outwindow 2      # negotiation
                      # offered wndw size if using flow control
                      # negotiation
                      # offered wndw size if using flow control
                      # negotiation

thruputclass off
```

Example Files**Table B-6 (Continued)**

```

# neg_inthruputclass  # offered thruput class if using thruput
19200                 # class negotiation
# neg_outthruputclass # offered thruput class if using thruput
19200                 # class negotiation

pvc_inpacketsize 128  # packetize for PVCs
pvc_outpacketize 128  # packetize for PVCs
pvc_inwindow 2      # window size for PVCs
pvc_outwindow 2      # window size for PVCs

# These set of parameters are specified only if you wish to run
IP over X.25.
# IP Related Parameters

# IP 15.4.64.120
255.255.248.0        # IP address and subnet mask
# mtu 2048            # max transmission unit 2048 octets for
# mtu 1007            standard
hold 300             # max transmission unit 1007 octets for
idle 600             DDN
                     # 5 minute hold timer
                     # 10 minute idle timer#

```

The x25init_smpl File

Table B-7

```
#
# Likely runstring: x25init -c x25init_smpl

X.121 4085551202      # X.121 address
X.121_packet ''      # use a null (i.e. length 0) packet
                        # address (TransPac addressing)
name interface0      # interface name for Level 3 access
device x25_0p1       # device to initialize

# Level 2 Parameters

t1 3000              # frame retransmission timeout; 3
t3 12000             # seconds
framesize 263        # Level 2 idle timer; 12 seconds
n2 3                 # max Level 2 transmission size
k 7                  # (octets) [n1/8]
                        # number of retransmissions allowed
                        # Level 2 window

# Level 3 Parameters

# virtual circuit parameters
# logical channel id, start num [1-4095], type, how many

lci 1 pvc 5          # 5 permanent VCs
lci 255 insvc 5       # 5 one-way incoming SVCs
lci 2048 svc 6        # 6 two-way switched VCs

networktype TRANSPAC # CCITT 1984, DTE (see
fast_select enabled   # /etc/x25/x25_networks)
reverse_charge        # allow incoming calls with call user
enabled              # data
                        # allow incoming calls requesting
                        # reverse changes

def_inpacketsize 128  # default packetsize
def_outpacketsize 128 # default packetsize
def_inwindow 7       # default window size
def_outwindow 7      # default window size
def_inthruputclass   # default thruput class
19200                # default thruput class
def_outthruputclass
19200
```

Example Files**Table B-7****(Continued)**

flowcontrol on	# flow control negotiation allowed
neg_inpacketsize 128	# offered pkt size if using flow
neg_outpacketsize 128	control negotiation
neg_inwindow 7	# offered pkt size if using flow
neg_outwindow 7	control negotiation
	# offered wndw size if using flow
	control negotiation
	# offered wndw size if using flow
	control negotiation
thruputclass on	
neg_inthruputclass	# offered thrupt class if using
19200	thruput class negotion
	# offered thrupt class if using
neg_outthruputclass	thruput class negotiation
19200	
pvc_inpacketsize 128	# packetize for PVCs
pvc_outpacketsize 128	# packetize for PVCs
pvc_inwindow 7	# window size for PVCs
pvc_outwindow 7	# window size for PVCs
# IP Related	
Parameters	
IP 15.4.64.120	
255.255.248.0	# IP address and subnet mask
mtu 2048	# max transmission unit 2048 octets
hold 300	# 5 minute hold timer
idle 600	# 10 minute idle timer

The x3config File

```
hp_printer {  
    1      0  
    2      0  
    3      0  
    4     10  
    5      1  
    6      0  
    7      0  
    8      0  
    9      0  
   10      0  
   11     14  
   12      1  
   13      0  
   14      0  
   15      0  
   16      8  
   17     24  
   18      0  
   19      1  
   20      0  
   21      0  
   22      0  
}  
hp_uucp {  
    1      0  
    2      0  
    3      0  
    4     10  
    5      1  
    6      0  
    7      0  
    8      0  
    9      0  
   10      0  
   11     14  
   12      1  
   13      0  
   14      0  
   15      0  
   16      8  
   17     24  
   18      0  
   19      1
```

Example Files

```

        20      0
        21      0
        22      0
    }
    hp_padsrvr {
        1      1      1
        2      1      1
        3      94     127
        4      0      0
        5      1      1
        6      5      5
        7      21     21
        8      0      0
        9      0      0
        10     0      0
        11     14     14
        12     1      1
        13     0      0
        14     0      0
        15     1      0
        16     8      8
        17     24     24
        18     0      0
        19     1      1
        20     0      0
        21     0      0
        22     0      0
    }
    hp_profile : 0 {
        1      1
        2      1
        3      127
        4      0
        5      1
        6      5
        7      21
        8      0
        9      0
        10     0
        11     14
        12     1
        13     0
        14     0
        15     1
        16     8
        17     24
    }

```

```
18      0
19      1
20      0
21      0
22      0
}
```

Example Files**The x29hosts File****Table B-8**

```

# for x29printd
printer {

    device      printer1
    name        hptndxk0
    remote_x121 408555111201
    x3          hp_printer
    reverse_charge enable
    logging     1

}

# for x29uucpd
pad_uucp {

    device      x25uucp
    name        hptndxk0
    remote_x121 4085551113
    x3          hp_uucp
    reverse_charge enable
    logging     3

}

# for padem
pad_em {

    name        hptndxk0
    remote_x121 4085551111
    reverse_charge enable
    profile     0
    logging     3

}

host_table {

    Gale        4085551111
    Tornado     4085551113
    Typhoon     4085551115

```

Table B-8 (Continued)

```
}

# for x29server
pad_spt {

    remote_x121      408555120801
    x3                hp_padsrvr
    logging           1
    reverse_charge    disable

}
```

The Network Type File (x25_networks)

The network type file describes standard network types. If the network to which you are subscribing does not meet any of the network descriptions specified in this file, use one of the generic entries (DTE_80, DTE_84 or DTE_88). The network type file is read-only.

The value in the first column of the file is an alias assigned to the network type. This is the value that you specify for the *networktype* configuration parameter in the *x25init* configuration file. The value in the second column is the actual network type. The value in the third column is the version of the CCITT X.25 Recommendation with which the network complies: 1980, 1984, or 1988.

Example Files

The delivered X.25 networktype file, /etc/x25/x25_networks is shown below:

Table B-9

DTE_80	L3_DTE	1980
DTE_84	L3_DTE	1984
DTE_88	L3_DTE	1988
DCE_80	L3_DCE	1980
DCE_84	L3_DCE	1984
DCE_88	L3_DTE	1988
AUSPAC	AUSPAC	1984
DATANET1	DATANET1	1984
DATAPAC	DATAPAC	1980
DATEXP_AUSTRIA	DATEXP_AUSTRIA	1984
DATEXP_DEUTSCHE	DATEXP_GERMANY	1980
DCS	DCS	1980
DDN	DDN_NET	1980
DDXP	DDXP	1980
HPPPN	HPPPN	1984
ITAPAC	ITAPAC	1980
LUXPAC	LUXPAC	1980
PSS	PSS	1980
TELENET	TELENET	1980
TRANSPAC	TRANSPAC	1984
TYMNET	TYMNET	1980

An alias associated with a network type chosen from this file is used to identify the network type during the configuration process.

C Diagnostic Messages

Introduction

This appendix describes the diagnostic codes and messages which are a subset of the list defined by the International Standards Organization (ISO) in *IS-8202:1987(E)*. Only those diagnostics supported on X.25 for HP 9000 systems are listed. Each message is listed in numerical order by its diagnostic code and includes an ISO description and explanation.

Refer to Appendix D of the *X.25 PSN Connection* for a complete list of diagnostic codes and messages, and to *ISO IS-8202:1987(E)* for a list of the corresponding cause codes and messages.

Diagnostic Message Example

An example diagnostic message generated by the network from a CLEAR REQUEST packet is shown below:

```
Clear request
LCGN: 0          LCN : 32
Clearing Cause [0] : DTE originated.
Diagnostic [241] :
```

In the example above, LCGN is the Logical Channel Group Number and LCN is the Logical Channel Number (the number denoting the logical association between a DTE and DTE connected by a VC). Refer to the discussion below for more information on cause codes.

Diagnostic codes are generated by the network and may appear in octet 5 of RESTART INDICATION, RESET INDICATION, or CLEAR INDICATION packets. If a diagnostic field is not present in a CLEAR INDICATION or RESET INDICATION packet, 0 is returned as the diagnostic code.

A cause code and message is usually returned from the network with each diagnostic. Diagnostic codes and messages are usually displayed only when tracing or logging is on, the `x25check` utility is run, or cause and diagnostic codes are printed in level 3 application programs. Refer to the listing of diagnostic codes later in this appendix for more information.

In the descriptions in the diagnostic listing, a REQUEST or ACCEPTED packet refers to a packet generated by the local application and an INDICATION or CONFIRM packet refers to a packet received from the network. The requests in which a diagnostic code can be found are shown after the numeric code of the diagnostic.

Once the application specifies CLEAR or RESET cause and diagnostic codes, this code combination is used for all RESET REQUEST packets generated by the application. This combination is also used for the CLEAR REQUEST generated when the application calls `close()` or `shutdown()` on a given socket.

Cause Code Settings

X.25 automatically resets (silently forces) the network-generated cause code of CLEAR or RESET REQUEST packets to comply with the applicable *CCITT X.25 Recommendation*.

- 1980 – The cause is silently forced to zero.
- 1984 – The cause is left at zero or OR'ed with 128 if it is not zero.
- 1988 – The cause is left at zero or OR'ed with 128 if it is not zero.

X.25 does not guarantee that the cause, diagnostic, facility, or clear user data fields of a CLEAR REQUEST or a RESET REQUEST are delivered to the remote destination because these fields may be altered by the network, the X.25 implementation (under certain circumstances) or both. In particular, X.25 discards the clear user data and facility fields of a CLEAR REQUEST when the facility field is found to be invalid for the given system configuration or when any other error occurs. When an error occurs on a CLEAR REQUEST, the cause and diagnostic fields delivered to the network are silently set according to the error.

Packet Codes

RESTART Packet Codes

When the system receives a RESTART INDICATION packet, the received CLEAR INDICATION or RESET INDICATION packet contains a cause code of 0 and the diagnostic code used in the RESTART.

RESET/CLEAR Packet Codes

The system may generate a RESET/CLEAR because of an error, lack of memory, or other condition. When this occurs, a RESET/CLEAR INDICATION is delivered to the application and a RESET/CLEAR REQUEST packet is sent to the network. The cause code is always zero as dictated by ISO in the IS-8208 standard, and the diagnostic is one of the codes in this appendix. Both the REQUEST and the INDICATION carry the same cause/diagnostic combination.

X.25 Diagnostic Messages

Table C-1 **No Additional Information**

Diagnostic	ISO Description	Explanation
1 (RESET)	Invalid P(S).	DATA packet received from network with P(S) invalid or outside of allowable window.
2 (RESET)	Invalid P(R).	DATA packet received from network with P(R) invalid.

Table C-2 **Packet Type Invalid**

Diagnostic	ISO Description	Explanation
17 (RESTART, CLEAR, RESET)	Packet type invalid for state R1.	Invalid packet received with interface in state R1 (packet level ready). RESTART REQUEST is sent on network. Invalid packet is probably RESTART CONFIRMATION.
20 (CLEAR)	Packet type invalid for state P1.	Invalid packet received on VC in state P1 (Ready).
21 (CLEAR)	Packet type invalid for state P2.	Invalid packet received on VC in state P2 (DTE CALL REQUEST).
22 (CLEAR)	Packet type invalid for state P3.	Invalid packet received on VC in state P3 (DCE Incoming Call).
23 (CLEAR, RESET)	Packet type invalid for state P4.	Invalid packet received on VC in state P4 (Data Transfer).
24 (CLEAR)	Packet type invalid for state P5.	Invalid packet received on VC in state P5 (Call Collision).

Table C-2 Packet Type Invalid (Continued)

25 (CLEAR)	Packet type invalid for state P6.	Invalid packet received on VC in state P6 (DTE Clear Request).
27 (RESET)	Packet type invalid for state D1.	Invalid packet received on VC in state D1 (Flow Control Ready).
29 (RESET)	Packet type invalid for state D3	Invalid packet received on VC in state D3 (DCE Reset Indication).

Table C-3 Packet Not Allowed

Diagnostic	ISO Description	Explanation
33 (RESTART, CLEAR, RESET)	Unidentifiable packet.	Packet that cannot be identified (3rd byte of the level 2 information field not defined in <i>CCITT X.25 Recommendation</i> received). REJECT or REGISTRATION packet received.
34 (CLEAR)	Call on one way logical channel.	If configured as DTE, CALL INDICATION received with logical channel identifier (LCI) corresponding to one-way logical channel outgoing. If configured as DCE (DXE), CALL INDICATION received with logical channel identifier (LCI) corresponding to one way logical channel incoming.
38 (RESTART, CLEAR, RESET)	Packet too short.	Received packet is less than minimum length. It may be a CALL INDICATION packet without address length or facility length fields, CLEAR or RESET INDICATION without cause field, or the packet length may be insufficient to hold address or facility fields.

Table C-3 Packet Not Allowed (Continued)

39 (RESTART, CLEAR, RESET)	Packet too long.	Received packet exceeds maximum length. The packet may be larger than allowed by the configuration and negotiations (i.e., fast select), or contain a field (i.e., call/clear user data) that is larger than the allowed size.
41 (RESTART, CLEAR, RESET)	RESTART or REGISTRATION packet with non-zero LCI.	RESTART REQUEST sent because RESTART INDICATION arrived with logical channel identifier other than 0.
42 (CLEAR)	Packet type not compatible with facility.	CALL ACCEPTED or CONFIRMATION packet received when CALL INDICATION or REQUEST had fast select with restriction on response facility.
43 (RESET)	Unauthorized interrupt confirmation.	INTERRUPT CONFIRM packet received when no matching INTERRUPT had been sent.
44 (RESET)	Unauthorized interrupt.	Sequence of two INTERRUPT INDICATIONs received and system sent no INTERRUPT CONFIRMATION packet.

Table C-4 Timer Expired

Diagnostic	ISO Description	Explanation
48 (CLEAR)	Timer expired (generic).	IP circuit is disconnected because it was inactive for more than the configured minimum time limit and the system must free the circuit to complete CALL REQUEST.
49 (CLEAR)	Timer expired for INCOMING CALL or DTE timer expired for CALL REQUEST.	CALL CONFIRM not received within the T21 time limit (set at approximately 200 seconds) after transmission of CALL REQUEST.

Table C-4 Timer Expired (Continued)

50 (CLEAR)	Timer expired for CLEAR INDICATION (or DTE timer expired or retransmission count surpassed for CLEAR REQUEST).	CLEAR CONFIRM not received within T23 time limit (set at approximately 180 seconds) after transmission of CLEAR REQUEST. After a certain number of CLEAR retries, system places logical channel in state P1 (Ready).
51 (CLEAR, RESET)	Timer expired for RESET INDICATION (or DTE timer expired or retransmission count surpassed for RESET REQUEST).	RESET CONFIRM not received within T22 time limit, set at approximately 180 seconds, after transmission of RESET REQUEST. After a certain number of RESET retries, the system places logical channel in state D1 (Flow Control Ready) if PVC, or in state P6 (DTE Request) by sending CLEAR REQUEST if SVC. Count of RESET retries has been surpassed. CLEAR REQUEST has been sent.
52 (RESTART)	Timer expired for RESTART INDICATION (or DTE timer expired or retransmission count surpassed for RESTART REQUEST).	RESTART CONFIRM not received within T20 time limit (set at approximately 180 seconds) after transmission of RESTART REQUEST. SABM frame received while in state R2 (DTE RESTART REQUEST). RESTART REQUEST is transmitted.

Table C-5 Call Setup, Call Clearing, or Registration Problem

Diagnostic	ISO Description	Explanation
------------	-----------------	-------------

Table C-5 Call Setup, Call Clearing, or Registration Problem (Continued)

65 (CLEAR)	Facility/ registration code not allowed.	<p>Packet size negotiation, Window Size Negotiation or Throughput Class Negotiation facility codes found in the facility field of the call setup packet when corresponding negotiation had not been configured. In CALL REQUEST, condition results in error returned to user instead of generation of CLEAR.</p> <p>If facility checking was configured, a facility code not allowed by configured level (1980 or 1984) was found before the first facility marker. In CALL REQUEST, this condition results in an error returned to user instead of generation of CLEAR.</p> <p>If facility checking was configured along with rejection of duplicate facilities, a combination of invalid facility codes was detected.</p> <p>The combination may indicate that the basic and extended format of given facility are present or that both the Closed User Group and Closed User Group with Outgoing Access facilities are present. In CALL REQUEST, this condition results in an error instead of a CLEAR.</p> <p>Facility marker 00 3B (hex) found, which corresponds to “internal” facilities. This facility marker is not allowed by either application or network. In CALL REQUEST, this condition results in an error returned to the user instead of CLEAR.</p>
------------	---	--

Table C-5 Call Setup, Call Clearing, or Registration Problem (Continued)

66 (CLEAR)	Facility parameter not allowed.	<p>Parameter field of a packet size negotiation, window size negotiation or throughput class negotiation facility in a call setup packet has been found to be invalid because it contains values not allowed by the configured level (1980 or 1984).</p> <p>Parameter field of a packet size negotiation, window size negotiation, or throughput class negotiation facility in a CALL ACCEPTED or CALL CONFIRM packet has been found to be invalid because it contains values outside of the allowed range specified by the configuration and previous call setup packet.</p> <p>For DDN configured interfaces, the parameter field of the DDN standard or DDN precedence facility in a call setup packet has been found to be invalid because it contains values not allowed by the <i>DDN X.25 Host Interface Specification (BBN83)</i>.</p>
67 (CLEAR)	Invalid called address.	<p>Unknown called address.</p> <p>Called address contains a non-BCD digit (i.e., a half byte with a value other than 0 through 9).</p>
68 (CLEAR)	Invalid calling address.	<p>Calling address contains a non-BCD digit (i.e., a half byte with a value other than 0 through 9).</p> <p>Last digit of address field is not 0 and the total number of digits present in address field is odd.</p>

Table C-5 Call Setup, Call Clearing, or Registration Problem (Continued)

69 (CLEAR)	Invalid facility/ registration length.	<p>Length of the facility field is greater than the maximum allowed by the configured revision level of <i>CCITT X.25 Recommendation</i> (63 for 1980, 109 for 1984). The condition will result in an error returned to the user instead of generation of CLEAR if it is detected in CALL REQUEST.</p> <p>No combination of facilities can equal the value indicated in the packet's facility length field. If this condition is detected in the CALL REQUEST packet it produces an error instead of a CLEAR.</p> <p>System could not add negotiation facilities without the facility field becoming larger than allowed by the configured revision level of the <i>CCITT X.25 Recommendation</i> (63 for 1980, 109 for 1984). This can happen only if the configured negotiation facility codes are not present in the facility field.</p>
70 (CLEAR)	Incoming call barred.	Configuration and status of interface disallows the opening of new inbound connection.
71 (CLEAR)	No logical channel available.	<p>No VC suitable for placing a connection in READY (P1) state. Generated when CALL REQUEST cannot be completed successfully. ENOSPC was returned to the caller if condition was detected in synchronous manner.</p> <p>The number of internal connections prohibits new connections being allocated for CALL INDICATION.</p>
72 (CLEAR)	Call collision.	When configured as DCE, CALL INDICATION was received on logical channel where CALL REQUEST had been sent. CALL REQUEST was cleared because the CALL INDICATION has priority.

Table C-5 Call Setup, Call Clearing, or Registration Problem (Continued)

73 (CLEAR)	Duplicate facility requested.	Same facility code appeared twice in the facility field. Error is returned to caller if condition was detected in CALL REQUEST. CLEAR was not generated.
76 (CLEAR)	Facility not provided when expected.	When system was configured to handle IP over X.25 as per DDN specifications, CALL INDICATION for IP did not have DDN standard selection facility code.

Table C-6 CATEGORY - Miscellaneous

Diagnostic	ISO Description	Explanation
83 (CLEAR)	Inconsistent Q bit setting.	The connection was cleared due to an inconsistent Q bit found in the packet.

Table C-7 International Problem and Maintenance

Diagnostic	ISO Description	Explanation
113 (CLEAR)	Remote network problem.	The remote network is not operational.
115 (CLEAR)	International link out of order.	Connection to the PSN is not currently available (network not operational).
121 (CLEAR)	Unknown called DNIC.	The CALL could not be routed because the DNIC in the called address is unknown.
122 (CLEAR, RESET)	Maintenance action.	System administrator shut down specific VC or the entire interface.

Table C-8 DTE-Specific Signals

Diagnostic	ISO Description	Explanation
------------	-----------------	-------------

Table C-8 DTE-Specific Signals (Continued)

160 (CLEAR, RESET)	DTE-specific signal (generic).	<p>CALL INDICATION with reverse charge requested has been received, and reverse charge is configured to be rejected by system.</p> <p>CALL INDICATION with reverse charge requested has been received by IP and reverse charge is configured to be rejected for that IP/X.121 address pair. Check is done via IP to X.121 address map table.</p> <p>CALL INDICATION with reverse charge requested has been received by IP and no entry in the IP-to-X.121 address map table exists for this X.121 address. Internal problem which may be generated by components of X.25/9000 architecture.</p>
161 (RESTART)	DTE operational.	Level 2 is coming up or a SABM frame is received. System sends RESTART REQUEST indicating host is up.
162 (CLEAR, RESET)	DTE not operational.	<p>Either level 3 or level 2 detected as down. Request delivered when network interface was not operational. Condition usually results in an error returned to the application instead of CLEAR. Diagnostic is used when RESTART INDICATION has been received by interface. Interface is going down. RESTART REQUEST was sent on network.</p>
163 (CLEAR, RESET)	DTE resource constraint.	Lack of memory to establish, reset, or clear a call, to process data, expedite data or acknowledgments, or to perform internal operation. This may indicate lack of network memory, or resource constraints on card. When resource constraint appears on connected circuit, CLEAR will be sent only if no recovery is possible.

Table C-8 DTE-Specific Signals (Continued)

164 (CLEAR)	Fast select not subscribed.	CALL INDICATION requiring fast select facility has been received and fast select is not configured. Results in error when detected on CALL REQUEST.
225 (CLEAR)	Disconnection (transient condition).	X.25 subsystem is down when X.25/9000 to IP subsystem is servicing CALL CONFIRMATION or incoming DATA.

Table C-9 OSI Network Service Problem

Diagnostic	ISO Description	Explanation
227 (CLEAR)	Connection rejection. Cause unspecified (transient condition).	Due to internal constraints at high levels other than lack of network memory, CALL INDICATION cannot be serviced.
224 (CLEAR, RESET)	OSI Network Service problem.	OSI network service not operational.
228 (CLEAR)	Connection rejection. Reason unspecified. (Permanent condition) (Transient condition).	X.25 to IP subsystem clears incoming CALL INDICATION which has calling address not present in IP to X.121 mapping table. If call were accepted, circuit would be half-duplex enabling remote node to send and receive while local host would only be able to receive. When X.25/IP output routine has data addressed to remote node it must be able to map the IP address to the X.121 address. If it cannot do so, the IP packet is discarded. Clearing the INCOMING CALL when the remote's X.121 address is not in the map table prevents a half-duplex circuit from being established.

Table C-9 OSI Network Service Problem (Continued)

231 (CLEAR)	Connection rejection. NSAP unreachable (transient condition).	No listen socket capable of servicing CALL INDICATION. X.25 subsystem is down when X.25-to-IP subsystem is servicing CALL INDICATION.
232 (CLEAR)	Connection rejection. NSAP unreachable (permanent condition).	CALL INDICATION with first byte of call user data other than CC (hex) received on system which does not have X.25/9000 programmatic access configured in kernel.
233 (RESET)	Reset. Cause unspecified.	Message (sequence of packets with the M bit set followed by packet with M bit not set) received, and size exceeds maximum size allowed by application for inbound data message. Corresponds to specific out-of-band event delivered to user. Data was received on VC without a user, that is, an IP or programmatic access application. X.25 subsystem was down when X.25 to IP subsystem serviced incoming DATA on permanent VC.
234 (RESET)	Reset. Congestion.	Error returned to the application due to network congestion condition.
235 (CLEAR)	NSAP address unknown.	CALL INDICATION was received with unknown NSAP address (first byte of call user data).
251 (RESET)	Reset. Cause unspecified.	System failed to synchronize data transfer to interface.

Table C-10 Higher Level Initiated

Diagnostic	ISO Description	Explanation
------------	-----------------	-------------

Table C-10 Higher Level Initiated (Continued)

241 (CLEAR)	Disconnection normal.	Application closed or shut down socket and did not specify cause/diagnostic combination to be used on socket. This is the default. If available, application-specified cause/diagnostic combination is used. This is not an error condition.
242 (CLEAR)	Disconnection abnormal.	Application using a socket supporting virtual connection crashed. Diagnostic, along with a cause code of 0, is used regardless of setting of cause/diagnostic combination. Related to x29server process.
243 (CLEAR)	Disconnection. Incompatible info in user data.	Application closed or shut down socket because of incompatible information in the user data field. Related to the x29server process.
244 (CLEAR)	Connection rejection. Reason unspecified (transient condition).	Application rejected the CALL for an unspecified reason. No listen socket was found. Related to the x29server process.
245 (CLEAR)	Connection rejection. Reason unspecified (permanent condition).	Application rejected the CALL for an unspecified reason. No listen socket was found. Related to the x29server process.
248 (CLEAR)	Connection rejection. Incompatible info in user data.	Application closed or shutdown socket because of a problem with the user data information. Related to the x29server process.

Table C-10 Higher Level Initiated (Continued)

250 (RESET)	Reset. User re-synchronization.	PVC is claimed by programmatic access socket. RESET is sent as part of socket initialization procedure. Code is used if the application did not specify which cause/diagnostic combination to use. Application requires RESET to be sent. No cause/diagnostic combination is specified on socket.
-------------	---------------------------------	---

Symbols

.netrc file, 227
.rhosts file, 227

A

accept reverse charge
 IP to X.121 mapping file, 217
add PAD-UUCP services, 74
add remote PAD support, 72
addresses
 IP to X.121 mapping, 214
 summary of files, 225

B

battery backup, 208
Break key, 114

C

cause code, 242
CCITT X.25 Recommendations, 237
closed user group
 IP to X.121 mapping file, 217
codes
 cause, 242
 diagnostic, 240
 RESET/CLEAR packet, 243
 RESTART packet, 243
commands
 netstat, 213
 strace, 187
 strerr, 195
 x25check, 115
 x25server, 115
 x25stat, 118
comments
 in IP to X.121 mapping file, 217
compatibility
 High Availability feature, 24
configuration
 displaying, 118
configuration file, 237
configuration parameters
 Network Type, 237
Configure Internet Address screen, 36
Configure Internet Address screen field
 descriptions, 37
configure remote PAD printer support, 73
Configure Virtual Circuits field descriptions,
 35
configuring

 internet address, 35
 local emulation, 157
 remote access, 48
 X.25 address, 31
Configuring X.25 Address screen, 32
Configuring X.25 Address screen field
 descriptions, 33
 network carrier type, 33
 programmatic access name, 33
 X.25 address, 33
 X.25 packet address, 33
configuring x.25 link, 30
CUG
 IP to X.121 mapping file, 217

D

DDN, 215
default subnet masks, 38
device file name, 114
diagnostic messages, 239–244
diagnostic utilities
 scope of, 113
 terminating, 114
 x25check command, 115
 x25server command, 115
 x25stat command, 118

E

error log files
 strerr command, 195
event messages
 tracing, 187
Exiting SAM, 47

F

failure
 power, 208
files
 .netrc, 227
 .rhosts, 227
 device, 114
 hosts, 226
 hosts.equiv, 226
 IP to X.121 mapping, 215
 ip_to_x121_map, 215
 network type, 237, 238
 networks, 227
 strerr error log, 195
 summary, 225

Index

- x25_networks, 226, 237
- x25init.log, 227
- x25init_def, 226, 228
- x25init_smpl, 226, 231
- x25server.log, 227

- Filter file, 183

G

- gateway, 215

H

- hardware requirements, 24
- High Availability feature, 24
- hosts file, 226
- hosts.equiv file, 226

I

- ifconfig
 - see man pages
- installing multiple X.25 cards, 24
- interface card
 - displaying configuration, 118
 - displaying statistics, 118
 - displaying status, 118
 - initialization, 208
 - name, 114
 - troubleshooting, 199
- interrupt signal, 114
- IP, 18
- IP address
 - mapped to X.121 address, 214
- IP over X.25
 - troubleshooting, 206
- IP routing
 - description of, 214
- IP to X.121 mapping file
 - accept reverse charge, 217
 - closed user group, 217
 - comments, 217
 - description, 215
 - parameters, 216
 - programmatic access name, 217
 - specifying PVCs, 216
 - syntax, 215
 - use reverse charge, 217
 - X.121 address, 216
- IP-to-X.121 address mapping
 - description, 214

K

- keys
 - Break, 114

L

- logging
 - priority level, 189
- logging utilities, 175
 - strace command, 187
 - strerr command, 195
- lpstat
 - verifying configuration, 145

M

- mapping X.25-to-IP
 - description, 214
- memory
 - loss during power failure, 208
- messages
 - diagnostic, 239–244
- Modify IP Over X.25 Defaults screen, 39
- Modify IP Over X.25 Defaults screen field
 - descriptions, 39
- modify PAD-UUCP services, 74
- modify remote PAD support, 72
- Modify Throughput Class Settings field
 - descriptions, 43
- Modify X.25 Throughput Class Defaults
 - screen, 43
- modify X.3 parameters
 - padem, 74
 - PAD-UUCP support, 74
 - remote PAD support, 74
 - remote printer support, 74
- modifying level 2 values, 45
- Modifying X.25 Flow Control Defaults
 - screen, 41
- Modulo-128, 41, 42, 45
- Modulo-8, 41, 42, 45
- multiple X.25 cards
 - installing, 24

N

- name
 - device file, 114
 - interface, 114
 - programmatic access, 114
- netfmt
 - see man pages
- netfmt command, 181

netstat
 see man pages
netstat command, 213
nettl
 see man pages
nettl command, 178
network carrier type, 33
network type, 237
network type file, 237
networks
 types of, 237
networks file, 227

O

online help (SAM), 31

P

packet codes
 RESET/CLEAR, 243
 RESTART, 243
PAD, 157
 call acceptance, 133
 CCITT, 130
 command sets, 160
 configuring remote printers, 141
 configuring remote support, 135
 configuring uucp support, 148
 extended command set, 161
 launching applications automatically, 138
 padem, 156
 remote PAD support, 132
 remote printer support, 139
 system security, 133
 UUCP support, 145
 uucp support, 145
 x25printd, 139
 x29server, 132
 x29uucpd, 146
PAD emulation
 add/modify, 71
pad_spt
 configuring, 135
padem, 156
 command mode, 156
 data transfer mode, 157
 modify X.3 parameters, 74
PAD-UUCP services
 add/modify, 74
PAD-UUCP support
 modify X.3 parameters, 74

parameters
 configuration, 237
Permanent VC Flow Control field
 descriptions, 42
ping
 see man pages
ping command
 troubleshooting, 206
power failure
 memory loss, 208
 recovering from, 208
priority level
 logging, 189
problems
 contacting service representative, 209
 known, 209
 power failure, 208
programmatic access name, 33, 114
 IP to X.121 mapping file, 217
 x25check command, 115
proxy
 see man pages
PVCs
 IP to X.121 mapping file, 216

R

remote PAD printer support
 add/modify, 73
remote PAD support
 add/modify, 72
 modify X.3 parameters, 74
remote printer support
 modify X.3 parameters, 74
RESET/CLEAR packet code, 243
RESTART packet code, 243
route
 see man pages

S

SAM, using, 30
service
 representative;contacting, 209
service representative
 providing information for, 209
setting window size values, 41
signal
 interrupt, 114
software requirements, 27
spooler
 configuring, 143

Index

statistics
 VCs, 118
status
 of interface card, 118
strace
 see man pages
strace command, 187
 examples, 192
 options, 187
 output format, 190
 syntax, 187
strerr
 see man pages
strerr command, 195
 description, 195
 options, 195
 syntax, 195
subnet masks defaults, 38
support
 See service representative
Switched VC Flow Control field descriptions,
 42

T

TCP/UDP, 18
throughput classes and line speeds, 44
tracing utilities, 175
troubleshooting, 198
 hardware check, 203
 ping command, 206
 X.25 configuration, 198, 205
 x25check command, 204
 x25server command, 204

U

URC option
 IP to X.121 mapping file, 217
use reverse charge
 IP to X.121 mapping file, 217
using SAM, 30
using SAM's online help, 31
utilities
 logging, 175
 tracing, 175
uucp
 configuring, 150

V

VCs
 statistics, 118

Verify Level 2 Values field descriptions, 46
Verify Level 2 Values screen, 45
verifying level 2 values, 44
verifying level 3 values, 39
Verifying Level 3 Values screen, 39
Verifying Level 3 Values screen field
 descriptions, 40
virtual circuits
 configuration with SAM, 34

X

X.121 address
 IP to X.121 mapping file, 216
 mapped from IP address, 214
X.25
 troubleshooting, 198
X.25 address, 33
X.25 configuration
 troubleshooting, 198, 205
X.25 configuration file, 166, 167, 168, 171
X.25 configuration files
 summary, 225
X.25 level 2
 event messages, 187
X.25 level 3
 event messages, 187
X.25 packet address, 33
X.25/9000
 components of, 18
 components provided with, 18
 network services supported, 18
 overview of, 18
X.28 PAD command set, 160
X.3
 default parameters, 165
 parameter descriptions, 165
X.3 profile parameters
 configuring, 163
X25 configuration
 displaying, 118
x25_networks file, 226, 237, 238
x25check
 see man pages
x25check command, 115
 description, 115
 example with parameters, 117
 running interactively, 115
 troubleshooting, 204
x25init
 examples, 214
x25init.log file, 227

- x25init_def file, 226, 228
- x25init_smpl file, 226, 231
- x25mibstat, 128
 - see man pages
- x25ping
 - see man pages
- x25printf, 139
- x25server, 132
 - see man pages
- x25server command, 115
 - description, 115
 - troubleshooting, 204
- x25server.log file, 227
- x25stat
 - see man pages
- x25stat command, 118
 - brief description of, 118
 - examples, 118
- x25stop
 - see man pages
- x25trace
 - see man pages
- x25upload
 - see man pages
- x29printf and lpsched
 - operation during configuration, 144
- x29uucpd, 146